

[manuals.plus](#) /

- › [Baby Einstein](#) /
- › [Baby Einstein Ocean Explorers Opus Musical Infant to Toddler Rocker User Manual](#)

Baby Einstein 16787

Baby Einstein Ocean Explorers Opus Musical Infant to Toddler Rocker User Manual

Model: 16787 | Brand: Baby Einstein

INTRODUCTION

The Baby Einstein Ocean Explorers Opus Musical Infant to Toddler Rocker is designed to provide a safe and engaging environment for your child from infancy through toddlerhood. This versatile product transitions from an infant rocker to a stationary seat and then to a toddler rocker, adapting to your child's growth. It features interactive music, lights, and gentle vibrations to stimulate and soothe.



Image: The Baby Einstein Ocean Explorers Opus Musical Infant to Toddler Rocker in its infant configuration, featuring an ocean-themed seat and a toy bar with lights and hanging toys.

SAFETY INFORMATION

WARNING: FALL HAZARD

- Babies have suffered skull fractures falling while in and from bouncers when not used properly.
- Use bouncer ONLY on the floor.
- ALWAYS use restraints and adjust to fit snugly.
- NEVER lift or carry baby in bouncer.

WARNING: SUFFOCATION HAZARD

- Never use this product on a soft surface (bed, sofa, cushion), as the seat can tip over and cause suffocation.
- Never leave child unattended.

WARNING: BATTERY SAFETY

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.

- Remove batteries during long periods of non-use.

SETUP

Follow these steps for proper assembly and battery installation.

Assembly

The rocker requires assembly of its frame and attachment of the seat pad and toy bar. Refer to the included visual guide for detailed steps. Ensure all components are securely fastened before use.

Battery Installation

The rocker requires two AA batteries (not included) for its musical and light features. Locate the battery compartment, typically on the underside of the main unit. Use a screwdriver to open the compartment, insert the batteries according to the polarity indicators (+/-), and securely close the cover.

OPERATING INSTRUCTIONS

The Opus Rocker offers multiple modes to engage and soothe your child.

Infant Rocker Mode

This mode is suitable for infants. The seat provides gentle rocking motion. The toy bar can be attached to provide interactive play.



Image: An infant in the Opus Rocker, actively kicking their feet and interacting with the hanging toys on the toy bar, which features colorful lights.

Baby-Activated Setting

In this setting, your baby's kicks and movements are rewarded with dancing lights, over 25 melodies, and sounds. This encourages active engagement and sensory development.

Parent-Activated Setting

This setting plays over 30 minutes of continuous music with gentle lights, providing a calming and entertaining experience for your baby. Press the designated button on the toy bar to activate.



Image: A parent gently pressing a button on the toy bar of the Opus Rocker, while an infant lies comfortably in the seat, observing the lights and sounds.

Vibration Feature

Activate the calming vibrations by pressing the button located on the side of the seat unit. This feature can help soothe and relax your infant.



Image: A happy infant in the Opus Rocker, with subtle wavy lines indicating the vibration feature is active, providing a soothing experience.

Stationary Seat Mode

As your baby grows, the infant rocker can be converted into a stationary seat. Detach the toy bar and adjust the recline position to provide a comfortable, upright seating option for older babies.



Image: An overhead view of an infant comfortably seated in the Opus Rocker, looking up at the toy bar with its colorful lights and hanging toys.

Toddler Rocker Mode

For toddlers, the seat transforms into a rocker. Ensure the toy bar is removed and the seat is adjusted to the appropriate position for a toddler to rock independently.



Image: A smiling toddler sitting comfortably in the Opus Rocker, which is now configured as a toddler seat, enjoying the rocking motion.

Toy Bar Usage

The removable toy bar features two dangling toys that can be batted and reached for by your baby. The toy bar also contains the light and music unit. To remove the toy bar, locate the release buttons on either side of the seat frame and press them while lifting the bar.



Image: A parent demonstrating how to remove the toy bar from the Opus Rocker, showing the mechanism for detachment.

Product Overview Video

Your browser does not support the video tag.

Video: An official product video showcasing the features and transformation of the Baby Einstein Ocean Explorers Kick to It Opus Musical Infant to Toddler Rocker, demonstrating its use from infant to toddler stages, including the baby-activated and parent-activated music and light modes, and the calming vibrations.

MAINTENANCE

Proper care ensures the longevity and hygiene of your rocker.

Cleaning Instructions

- **Seat pad:** Remove from frame. Wipe clean with a damp cloth and mild soap.
- **Toy bar & toys:** Wipe clean with a damp cloth and mild soap. Do not immerse in water.
- **Frame:** Wipe with a soft, clean cloth and mild soap.

General Care

Store the rocker in a dry location away from any sources of heat or direct sunlight when not in use.

TROUBLESHOOTING

If you encounter any issues with your rocker, refer to the following common solutions:

- **Music/Lights not working:** Check if the batteries are correctly installed and not depleted. Replace with fresh AA batteries if necessary.
- **Vibration not working:** Ensure the vibration button is pressed firmly. Check battery levels.
- **Rocker not stable:** Verify that all frame components are securely connected and the rocker is placed on a flat, stable surface.

SPECIFICATIONS

Product Dimensions	27.95 x 19.3 x 22.44 inches
Item Model Number	16787
Batteries Required	2 AA batteries (not included)
Maximum Weight Recommendation	40 Pounds
Material Composition	65% Metal, 24.6% Plastic, 10.4% Fabric
Item Weight	6.7 pounds

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the manufacturer's official website or contact their customer service. Keep your purchase receipt for any warranty claims.