Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Armen Living LCDO1TSU

Armen Living Donna Upholstered Accent Chair User Manual

Model: LCDO1TSU

Introduction

This manual provides essential information for the assembly, safe use, and maintenance of your Armen Living Donna Upholstered Accent Chair. The Donna Accent Chair combines style with comfort, featuring an eight-way hand-tied seat construction and a down, foam, and fiber blend seat cushion. It is designed to complement various decor styles with its coastal gray wood base and Sugar upholstery.
Please read these instructions thoroughly before assembly and use to ensure proper function and longevity of your chair.

Safety Information

WARNING: Failure to follow these safety guidelines may result in injury or damage to the product.

- Simple assembly is required for the detachable legs. Do not attempt to sit on the chair until fully assembled and all legs are securely attached.
- The maximum weight capacity for this chair is 350 pounds (158 kg). Do not exceed this limit to ensure safety and prevent structural damage.
- This chair is designed for single-person seating only. Avoid using it for purposes other than its intended use, such as standing on it or using it as a step stool.
- Keep small parts and packaging materials away from children to prevent choking hazards.
- Periodically check all connections and fasteners to ensure they remain tight. Retighten as necessary.

Setup and Assembly

The Armen Living Donna Accent Chair requires minimal assembly, primarily involving the attachment of the legs.

1. Carefully unpack all components from the packaging. Ensure all parts are present before beginning assembly.
2. Gently place the chair body upside down on a soft, clean surface to prevent scratching the upholstery or wood finish.
3. Locate the detachable legs and the corresponding attachment points on the underside of the chair.

4. Align each leg with its designated corner and securely fasten it using the provided hardware. Ensure all legs are tightened firmly. Do not overtighten.
5. Once all legs are attached, carefully turn the chair upright.
6. Place the seat cushion and back cushion into position.
7. Before use, gently test the stability of the chair by applying light pressure.




Figure 1: Dimensional diagram of the Donna Upholstered Accent Chair. This image illustrates the overall width, depth, and height, as well as specific measurements for the seat, back, and armrests, which are crucial for planning placement and ensuring proper fit in your space.

Operating Instructions

The Donna Upholstered Accent Chair is designed for comfortable single seating in various indoor settings.

- **Intended Use:** This chair is suitable for relaxing, reading, and casual use in living rooms, bedrooms, or offices.
- **Placement:** Position the chair on a hard, level surface. Avoid placing it in direct sunlight or near heat sources to prevent fading or damage to the upholstery and wood.
- **Movement:** When moving the chair, lift it rather than dragging it to prevent damage to the legs or floor.



Figure 2: The Donna Upholstered Accent Chair in a typical living room environment, showcasing its design and how it fits into a home setting.

Maintenance and Care

Proper care will help maintain the appearance and extend the life of your accent chair.

- **Upholstery Care:** The fabric upholstery should be spot cleaned only. Use a mild, water-free solvent or dry-cleaning product. Always test a small, inconspicuous area first. Do not saturate the fabric.
- **Wood Base Care:** Wipe the wood base with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Cushion Care:** Periodically fluff and rotate the seat and back cushions to ensure even wear and maintain their shape.
- **General Cleaning:** Vacuum the chair regularly using an upholstery attachment to remove dust and debris.



Figure 3: A detailed view of the chair's back cushion and armrest, highlighting the fabric texture and stitching, which are important areas for routine cleaning and inspection.

Troubleshooting

If you encounter any issues with your Donna Upholstered Accent Chair, please refer to the following common solutions:

- **Wobbly Chair:** If the chair feels unstable, check that all leg fasteners are securely tightened. Ensure the chair is placed on a level surface.
- **Squeaking Noises:** Squeaking can sometimes occur if fasteners are loose. Retighten all leg connections. If the issue persists, contact customer support.
- **Stains on Upholstery:** Refer to the "Maintenance and Care" section for spot cleaning instructions. For stubborn stains, it is recommended to consult a professional upholstery cleaner.
- **Damaged Parts:** If any part of the chair is damaged or missing upon arrival, do not proceed with assembly. Contact Armen Living customer support immediately for assistance.

Specifications

Feature	Detail

Feature	Detail
Brand	Armen Living
Model Name	Donna
Model Number	LCDO1TSU
Color	Sugar
Overall Product Dimensions (W x D x H)	35 inches x 32.5 inches x 35.5 inches
Seat Width	22 inches
Seat Depth	20 inches
Seat Height	21 inches
Cushion Thickness	5 inches
Back Height	15 inches
Arm Height	26.5 inches
Leg Height	7 inches
Item Weight	53 Pounds
Maximum Weight Capacity	350 Pounds
Material	Wood (Frame), Polyester Blend (Fabric), Foam (Fill)
Assembly Required	Yes (Simple leg assembly)
Care Instructions	Spot Clean
Indoor/Outdoor Usage	Indoor
UPC	840254340589

Warranty Information

Armen Living provides a limited manufacturer warranty for the Donna Upholstered Accent Chair.

- **Parts and Labor:** Covered for 2 years from the date of purchase.
- **Springs and Frame:** Covered for 3 years from the date of purchase.

This warranty covers manufacturing defects under normal household use. It does not cover damage resulting from misuse, accidents, unauthorized repairs, or normal wear and tear. Please retain your proof of purchase for warranty claims.

Customer Support

For further assistance, questions, or to report any issues with your Armen Living Donna Upholstered Accent Chair, please contact Armen Living customer support.

- **Manufacturer:** Armen Living

- **Online Support:** Visit the official Armen Living store on Amazon for product information and contact options:Armen Living Store

© 2026 Armen Living. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CP8TM7YV

More documents and user manuals: **https://manuals.plus/**