

FINGERTIME ANC-01

FINGERTIME ANC-01 Active Noise Cancelling Headphones User Manual

Model: ANC-01 | Brand: FINGERTIME

1. INTRODUCTION

Thank you for choosing the FINGERTIME ANC-01 Active Noise Cancelling Headphones. This manual provides essential information for the proper setup, operation, and maintenance of your headphones. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.

2. SAFETY INFORMATION

- **Hearing Protection:** Avoid using headphones at high volume levels for extended periods to prevent hearing damage.
- **Driving Safety:** Do not use headphones while driving, cycling, or operating machinery where the inability to hear ambient sounds could pose a danger.
- **Water and Moisture:** These headphones are not water-resistant. Avoid exposure to rain, moisture, or submersion in liquids.
- **Cleaning:** Use a soft, dry cloth for cleaning. Do not use harsh chemicals or abrasive materials.
- **Temperature:** Store and operate the headphones within recommended temperature ranges (typically 0°C to 45°C or 32°F to 113°F).
- **Disassembly:** Do not attempt to disassemble or modify the headphones. This will void the warranty and may cause damage.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- FINGERTIME ANC-01 Active Noise Cancelling Headphones
- USB-C Charging Cable
- 3.5mm Audio Cable
- User Manual (this document)




Image: Contents of the FINGERTIME ANC-01 headphone package.

4. PRODUCT OVERVIEW

Familiarize yourself with the various components and controls of your FINGERTIME ANC-01 headphones.




Image: Close-up view highlighting the physical features and controls of the headphones.

Key Components:

- **Power Button:** Used for powering on/off and pairing.
- **Volume Up/Down Buttons:** Adjusts audio volume.
- **Multi-function Button:** Controls playback, calls, and voice assistant.
- **ANC/Transparency Mode Button:** Toggles between noise control modes.
- **USB-C Charging Port:** For charging the internal battery.
- **3.5mm Audio Jack:** For wired audio connection.
- **LED Indicator:** Displays power, pairing, and charging status.
- **Microphone:** For hands-free calls.

5. SETUP

5.1 Charging the Headphones

Before first use, fully charge your headphones. A full charge provides up to 50 hours of playtime with Active Noise Cancellation (ANC) on, or 65 hours with ANC off. A 5-minute quick charge can provide approximately 3 hours of

playback.

1. Connect the provided USB-C charging cable to the USB-C port on the headphones.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will show charging status (e.g., red for charging, blue for fully charged).



Image: Headphones highlighting the extended playtime capability.

5.2 Powering On/Off

- **To Power On:** Press and hold the Power button for approximately 3 seconds until the LED indicator lights up.
- **To Power Off:** Press and hold the Power button for approximately 3 seconds until the LED indicator turns off.

5.3 Bluetooth Pairing

The FINGERTIME ANC-01 headphones utilize Bluetooth 5.3 for a stable wireless connection.

1. Ensure the headphones are powered off.
2. Press and hold the Power button for approximately 5 seconds until the LED indicator flashes blue and red alternately, indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.

4. Select "FINGERTIME ANC-01" from the list of devices.
5. Once connected, the LED indicator will flash blue slowly or remain solid blue.



Image: FINGERTIME ANC-01 headphones, showcasing their design.

5.4 Wired Connection

You can use the headphones with a wired connection via the 3.5mm audio cable, even if the battery is depleted.

1. Plug one end of the 3.5mm audio cable into the audio jack on the headphones.
2. Plug the other end into the 3.5mm audio output of your device.
3. Note that some features like ANC may require battery power even in wired mode, depending on the specific model's design.

6. OPERATING THE HEADPHONES

6.1 Music Playback

- **Play/Pause:** Press the Multi-function button once.

Image: Visual representation of Hybrid Active Noise Cancellation in action.

- **Transparency Mode:** Allows you to hear your surroundings while still enjoying your audio, useful for awareness in urban environments or during conversations.



Image: User demonstrating the Transparency Mode feature.

6.4 Wearing the Headphones

For optimal sound quality and comfort, adjust the headphones to fit your head properly.

- Extend or retract the headband until the earcups comfortably cover your ears.
- The multi-angle rotating earcups allow for a flexible fit to different head shapes.
- Ensure a snug fit to maximize noise cancellation effectiveness and audio performance.

Ergonomic Design

More comfortable to wear all day



Image: User wearing the headphones, highlighting the ergonomic design for comfort.

7. MAINTENANCE

Proper care ensures the longevity and performance of your headphones.

7.1 Cleaning

- Wipe the headphones with a soft, dry, lint-free cloth.
- Do not use liquid cleaners, sprays, or solvents.
- Gently clean earcups and headband with a slightly damp cloth if necessary, then dry immediately.

7.2 Storage

- Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- If not using for an extended period, charge the headphones at least once every three months to maintain battery health.

7.3 Battery Care

- Avoid fully discharging the battery frequently.
- Do not expose the battery to excessive heat or fire.

- Dispose of batteries according to local regulations.

8. TROUBLESHOOTING

If you encounter issues with your headphones, refer to the following common problems and solutions:

Problem	Solution
Headphones won't turn on	Ensure the headphones are charged. Connect to a power source using the USB-C cable.
Cannot pair with device	Ensure headphones are in pairing mode (flashing blue/red LED). Turn off and on Bluetooth on your device. Move headphones closer to the device. Clear previous Bluetooth connections on your device.
No sound or low volume	Check volume levels on both headphones and your connected device. Ensure headphones are properly paired or the 3.5mm cable is securely connected. Try playing different audio sources.
Active Noise Cancellation (ANC) is ineffective	Ensure ANC mode is activated. Adjust the headphones for a snug fit over your ears. ANC is most effective against low-frequency, constant noise.
Microphone not working during calls	Ensure the headphones are connected via Bluetooth. Check microphone settings on your device to ensure the headphones are selected as the input device.

9. SPECIFICATIONS

Technical details of the FINGERTIME ANC-01 Active Noise Cancelling Headphones:

Feature	Detail
Model Name	ANC-01
Brand	FINGERTIME
Noise Control	Hybrid Noise Cancellation
Connectivity Technology	Wired, Wireless (Bluetooth)
Wireless Communication Technology	Bluetooth 5.3
Headphones Jack	3.5 mm Jack
Audio Driver Type	Dynamic Driver (40mm DLC composite)
Frequency Range	20 Hz - 20,000 Hz
Impedance	32 Ohm
Control Type	Noise Control, Touch


Feature	Detail
Battery	1 Lithium Polymer battery (included)
Playtime (ANC On)	Up to 50 hours
Playtime (ANC Off)	Up to 65 hours
Quick Charge	5 minutes for 3 hours playback
Material	Plastic
Item Weight	0.56 Kilograms (1.23 pounds)
Color	Grey
Water Resistance Level	Not Water Resistant

10. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or visit the official FINGERTIME website. If you require technical support or have questions not covered in this manual, please contact FINGERTIME customer service through their official channels.


Related Documents - ANC-01

	<p>Fingertime Removal Service Terms and Conditions for Electrical Appliances</p> <p>Official terms and conditions for Fingertime's free removal service of used regulated electrical appliances (REE) in Hong Kong, as per the Producer Eco-Responsibility Ordinance. Includes details on service timing, location, and customer responsibilities.</p>
	<p>Fingertime ANCO1 Fashion Bluetooth Headset User Manual</p> <p>User manual for the Fingertime ANCO1 Fashion Bluetooth Headset, detailing product parameters, button operations, modes, and FCC statements.</p>
	<p>MEE audio X20 Truly Wireless ANC In-Ear Headphones Setup Guide</p> <p>Comprehensive setup guide for MEE audio X20 truly wireless active noise cancelling in-ear headphones. Learn how to charge, pair, fit, use controls, and troubleshoot your X20 headphones.</p>



[1MORE SonoFlow Active Noise Cancelling Headphones User Manual](#)

User manual for the 1MORE SonoFlow over-ear Bluetooth headphones, featuring active noise cancellation, LDAC Hi-Res audio, 70-hour playtime, and app control. Includes setup, operation, safety, and compliance information.



[Soundcore Life Q20 Wireless ANC Headphones User Manual and Specifications](#)

Comprehensive user guide for the Soundcore Life Q20 wireless active noise cancelling headphones. Learn about app features, charging, pairing, button controls, wired listening, resetting, firmware updates, and technical specifications.



[Marshall Motif A.N.C. True Wireless Active Noise-Cancelling Earbuds User Manual](#)

Comprehensive user manual for the Marshall Motif A.N.C. True Wireless Active Noise-Cancelling earbuds, covering setup, controls, charging, noise control, pairing, resetting, and cleaning.