

[Manuals.plus](#) /

› [CCLIFE](#) /

› CCLIFE Replacement Magnetic Darts Instruction Manual

CCLIFE B0CP7X16XX

CCLIFE Replacement Magnetic Darts Instruction Manual

Model: B0CP7X16XX

1. INTRODUCTION

Thank you for choosing CCLIFE Replacement Magnetic Darts. This set of 36 durable, safe plastic wing magnetic darts is designed to provide a fun and secure dart game experience for all ages. Unlike traditional darts, these feature a strong magnetic tip, eliminating sharp points and making them ideal for younger players and safer for your home environment. They are specifically designed for use with magnetic dartboards (not included).



Image 1.1: Overview of the 36-piece magnetic dart set, showcasing the variety of colors included.

Key Features:

- **Quantity:** 36 pieces per set, including 6 darts each of red, yellow, white, black, green, and blue.
- **Safety:** Magnetic tips replace sharp points, making them safe for players and walls.
- **Compatibility:** Designed for use with magnetic dartboards.
- **Durability:** Constructed from hard plastic and strong magnets for long-lasting use.
- **Dimensions:** Approximately 3.15 inches (8 cm) in length.

2. SETUP

The CCLIFE Magnetic Darts require minimal setup. They are ready for use directly out of the packaging.

1. **Unpack:** Carefully remove all 36 magnetic darts from their packaging.

2. **Inspect:** Before first use, visually inspect each dart for any signs of damage. Ensure the magnetic tip is securely attached to the plastic wing.
3. **Prepare Dartboard:** Ensure you have a compatible magnetic dartboard (not included) set up in a safe area, away from fragile objects or high-traffic zones.

3. OPERATING INSTRUCTIONS

Using the magnetic darts is straightforward and designed for enjoyment.

1. **Hold the Dart:** Grip the plastic body of the dart comfortably between your fingers.
2. **Aim:** Focus on your target area on the magnetic dartboard.
3. **Throw:** With a smooth motion, throw the dart towards the dartboard. The magnetic tip will adhere to the metallic surface of the board upon impact.

The darts adopt round magnetic head with good attractive force.

Non-hazardous, safe to use.



Image 3.1: Magnetic darts successfully adhering to a magnetic dartboard, illustrating their intended use.

Safety Information:

- While these darts are designed for safety, avoid throwing them directly at people or animals.
- Ensure the play area is clear of obstacles and other individuals.
- These darts are intended for use with magnetic dartboards only. Do not attempt to use them with traditional bristle dartboards.

Magnetic Darts are Safer for players and your walls



Image 3.2: Visual representation highlighting the safety advantage of magnetic darts over traditional sharp-tipped darts.

4. MAINTENANCE

Proper care will extend the life of your magnetic darts.

- **Cleaning:** If darts become dirty, wipe them gently with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the plastic or magnet.
- **Drying:** Ensure darts are completely dry before storing them to prevent any potential damage to the magnetic components.
- **Storage:** Store darts in a cool, dry place, preferably in their original packaging or a dedicated container, to prevent loss and protect them from dust and damage.

5. TROUBLESHOOTING

These magnetic darts are simple in design, and issues are rare. However, if you encounter any problems, consider the following:

Dart Does Not Stick to Board:

- **Check Dartboard:** Ensure you are using a magnetic dartboard. These darts will not stick to traditional bristle dartboards.
- **Inspect Dart:** Verify that the magnetic tip is still present and securely attached to the dart. If the magnet is missing or loose, the dart may be damaged and should be replaced.
- **Surface Cleanliness:** Ensure both the dart's magnetic tip and the dartboard's surface are clean and free of debris that might interfere with magnetic attraction.

6. SPECIFICATIONS



Image 6.1: Detailed view of a magnetic dart showing its approximate length.

Attribute	Detail
Brand	CCLIFE
Model Number	B0CP7X16XX
Material	Hard Plastic, Magnet
Colors Included	Red, Yellow, White, Black, Green, Blue (6 of each)

Attribute	Detail
Total Quantity	36 Darts
Dart Length	Approx. 3.15 inches (8 cm)
Item Weight	0.24 Kilograms (for the set)
Compatibility	Magnetic Dartboards (not included)

7. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your CCLIFE Replacement Magnetic Darts, please contact the manufacturer directly. While specific warranty details are not provided in this manual, most products come with a standard manufacturer's warranty against defects in materials and workmanship.

Manufacturer: CCLIFE

Please refer to your purchase documentation or the retailer's website for specific warranty terms and contact information for customer support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

