

AM.PM FXA40022

AM.PM X-Joy FXA40022 Thermostatic Shower Mixer Tap User Manual

Model: FXA40022 | Brand: AM.PM

1. INTRODUCTION

This manual provides instructions for the installation, operation, maintenance, and troubleshooting of the AM.PM X-Joy FXA40022 Thermostatic Shower Mixer Tap. Please read this manual carefully before installation and use to ensure proper function and safety.

The AM.PM X-Joy FXA40022 is a thermostatic shower mixer tap designed for precise water flow and temperature regulation, featuring a safety lock at 38°C to prevent scalding. It is constructed from solid brass and finished in black matt, offering durability and a modern aesthetic.

2. SAFETY INFORMATION

Always adhere to local plumbing and building codes during installation. If you are unsure about any part of the installation process, consult a qualified plumber.

- Ensure water supply is turned off before beginning installation or maintenance.
- The safety stop at 38°C is designed to prevent scalding. Do not bypass or modify this feature.
- Use appropriate tools and protective equipment during installation.
- Regularly check for leaks and proper function.

3. PACKAGE CONTENTS

Verify that all components are present before starting installation:

- 1 x AM.PM X-Joy FXA40022 Shower Mixer Tap (Black Matt)
- 1 x Installation Instructions (German, English)
- Rosettes (metal)

- S-connections



Image: The AM.PM X-Joy FXA40022 shower mixer tap, showcasing its black matt finish and ergonomic design.

4. SPECIFICATIONS

Feature	Detail
Model Number	FXA40022
Brand	AM.PM
Material	Brass
Finish	Black Matt
Installation Method	Wall Mount (Single Hole)
Number of Handles	2
Special Features	Thermostatic control with scalding protection at 38°C
Product Dimensions	10 x 27.7 x 6.5 cm
Item Weight	1.5 kg




Image: Technical drawing illustrating the dimensions and connection points of the shower mixer tap.

5. SETUP AND INSTALLATION

The AM.PM X-Joy FXA40022 shower mixer tap is designed for wall mounting. Follow these general steps for installation. Refer to the included installation instructions for detailed diagrams and specific guidance.

1. **Prepare the Installation Area:** Ensure the water supply is turned off at the main valve. Clear the installation area and have all necessary tools ready.
2. **Install S-Connections:** Screw the S-connections into the wall water outlets. Ensure they are level and the correct distance apart (typically 150mm +/- 15mm, as indicated in the specifications). Use thread seal tape for a watertight connection.
3. **Attach Rosettes:** Place the metal rosettes over the S-connections, flush against the wall.
4. **Mount the Mixer Tap:** Carefully align the mixer tap with the S-connections and screw it into place. Tighten securely, but do not overtighten.
5. **Check for Leaks:** Slowly turn on the main water supply and check all connections for leaks. Tighten any leaking connections as needed.
6. **Test Functionality:** Test the water flow and temperature controls to ensure proper operation.



Image: The AM.PM X-Joy FXA40022 shower mixer tap shown installed on a bathroom wall, connected to a shower hose.

6. OPERATING INSTRUCTIONS

The AM.PM X-Joy FXA40022 features two handles for controlling water flow and temperature.

- **Water Flow Control:** The handle on the left (typically marked "eco" or with dots) controls the water flow rate. Rotate it to increase or decrease the flow. The "eco" setting provides a reduced flow for water conservation.
- **Temperature Control:** The handle on the right controls the water temperature. It features a safety stop at 38°C (indicated by a red mark). To increase the temperature beyond 38°C, press the safety button and rotate the handle further.



Image: Close-up view of the left handle, indicating the 'eco' setting for water flow control.



Image: Close-up view of the right handle, highlighting the 38°C safety stop for temperature control.

The thermostatic control maintains a constant water temperature even with fluctuations in water pressure, providing a consistent showering experience.

7. MAINTENANCE AND CARE

To ensure the longevity and optimal performance of your AM.PM X-Joy FXA40022 shower mixer tap, follow these maintenance guidelines:

- **Cleaning:** Clean the surface regularly with a soft cloth and mild soap or a non-abrasive cleaner specifically designed for bathroom fixtures. Avoid harsh chemicals, abrasive sponges, or cleaners containing alcohol, ammonia, or bleach, as these can damage the black matt finish.
- **Limescale Removal:** In areas with hard water, limescale buildup may occur. Use a descaling agent suitable for brass fixtures, following the manufacturer's instructions.
- **Cartridge Maintenance:** If water flow or temperature control becomes inconsistent, the thermostatic cartridge may need cleaning or replacement. This typically requires professional assistance.

- **Check Connections:** Periodically inspect all connections for any signs of leaks or corrosion.



Design extraordinaire
Style iconique et caractère distinctif

Réalisé par GP designpartners, Autriche

Image: The shower mixer tap's black matt finish, which is designed to be durable and resistant to corrosion and fingerprints.

8. TROUBLESHOOTING

If you encounter issues with your shower mixer tap, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No water flow or low pressure	◦ Main water supply off ◦ Blocked filter/aerator ◦ Kinked hose (if applicable)	◦ Check main water supply valve ◦ Clean or replace filter/aerator ◦ Straighten hose

Inconsistent water temperature	◦ Thermostatic cartridge needs calibration or cleaning ◦ Fluctuating hot/cold water supply	◦ Consult a professional plumber to inspect/clean/calibrate the cartridge ◦ Ensure stable hot and cold water pressure
Leaks from connections	◦ Loose connections ◦ Damaged seals/washers	◦ Tighten connections (do not overtighten) ◦ Replace seals/washers

If the problem persists after attempting these solutions, contact customer support or a qualified plumber.

9. WARRANTY INFORMATION

The AM.PM X-Joy FXA40022 shower mixer tap comes with a**5-year manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use and service. Please retain your proof of purchase for warranty claims.


The warranty does not cover damage resulting from improper installation, misuse, abuse, accident, neglect, or unauthorized repairs or modifications.

Haute qualité

Le revêtement PVD mat
protège contre la corrosion
et les traces de doigts



5
Ans
de garantie



Corps en laiton



Image: Visual representation of the 5-year warranty and the product's brass body construction.

10. CUSTOMER SUPPORT

For further assistance, technical support, or warranty claims, please contact AM.PM customer service through their official website or the retailer where the product was purchased.

Manufacturer: AM.PM

Model: FXA40022

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question