

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Lyromix](#) /
- › [Lyromix 70.86" Double Dog Crate Furniture Instruction Manual](#)

Lyromix Lyromix 70.86" Dog Crate Furniture

Lyromix 70.86" Double Dog Crate Furniture Instruction Manual

Model: Lyromix 70.86" Dog Crate Furniture | Brand: Lyromix

INTRODUCTION

Thank you for choosing the Lyromix 70.86" Double Dog Crate Furniture. This versatile product serves as a comfortable and secure indoor kennel for your dogs while also functioning as a stylish piece of furniture, such as a TV stand or side table. Designed with durability and pet comfort in mind, it features a removable divider to accommodate either two medium-sized dogs or one large dog. Please read this manual carefully before assembly and use to ensure proper installation and safe operation.



3-in-1 Dog Crate Table

Not just your dog cage, but your storage table



Image: The Lyromix 3-in-1 Dog Crate Table, showcasing its dual functionality as a dog kennel and a furniture piece, with a television placed on top.

SAFETY INSTRUCTIONS

- **Read All Instructions:** Before assembly and use, carefully read and understand all instructions in this manual.
- **Adult Assembly Required:** Assembly should be performed by at least two adults due to the size and weight of the components.
- **Level Surface:** Always place the assembled dog crate on a flat, stable, and level surface to prevent tipping.
- **Regular Inspection:** Periodically check all bolts, screws, and connections to ensure they are tight and secure. Retighten as necessary.
- **Pet Supervision:** Do not leave pets unsupervised if they are prone to chewing furniture. While the crate features chew-resistant iron tubes, excessive chewing can damage the product and pose a hazard to your pet.
- **Child Safety:** Keep children away from the assembly area. Do not allow children to climb on, play inside, or hang from the dog crate.

- **Proper Sizing:** Ensure your dog is appropriately sized for the crate. Your dog should be able to stand up, turn around, and lie down comfortably.
- **Ventilation:** Ensure adequate ventilation around the crate.
- **Indoor Use Only:** This product is designed for indoor use only. Do not expose it to outdoor elements.

PACKAGE CONTENTS

Please verify that all components listed below are present before beginning assembly. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- Wooden Panels (Top, Bottom, Side, Back)
- Iron Tube Panels (Front Doors, Side Panels)
- Removable Divider Panel
- Hardware Pack (Screws, Bolts, Wrenches, Magnetic Door Catches)
- Adjustable Feet
- Instruction Manual

SETUP AND ASSEMBLY

Assembly requires two people due to the size and weight of the components. Follow the steps below carefully.

1. **Unpack Components:** Lay out all wooden panels, iron tube panels, the removable divider, and hardware on a clean, soft surface to prevent scratches.
2. **Assemble Base Structure:** Attach the side wooden panels to the bottom wooden panel using the provided screws and bolts. Ensure all connections are secure.
3. **Install Iron Tube Panels:** Secure the iron tube side panels and front door panels to the wooden structure. Pay attention to the orientation of the door hinges.
4. **Install Removable Divider:** If you intend to house two medium-sized dogs, insert the removable divider panel into the designated slots in the middle of the crate. This creates two separate compartments. If you have one large dog, you can omit this step for a single, larger space.




Removable Divider

1 room convert to 2 rooms



Without divide

One Room Without Divider



With divider

Two Rooms With Divider

Image: Illustration demonstrating the flexibility of the crate with a removable divider. The top image shows a single large compartment without the divider, suitable for one large dog. The bottom image shows two separate compartments with the divider installed, suitable for two medium-sized dogs.

5. **Attach Top Panel:** Place the top wooden panel onto the assembled structure and secure it with screws.
6. **Install Adjustable Feet:** Screw the adjustable feet into the bottom corners of the crate. Adjust them to ensure the crate is level and stable on your floor.



Waterproof Surface

Shielding your tabletops, worry-free



Safety Door Lock

Ensuring premium locking solutions
for your peace of mind



Stability in Style

Fine-Tune your furnishings
with adjustable feet

Image: A composite image highlighting key features: a waterproof surface on the wooden top, a secure safety door lock mechanism, and an adjustable foot for stability on uneven floors.

7. **Secure Door Locks:** Install the safety door locks and magnetic buckles on the doors as per the instructions in the hardware pack. Test the doors to ensure they open and close smoothly and lock securely.

OPERATING INSTRUCTIONS

- **Door Operation:** To open the doors, unlatch the safety lock and pull the door outwards. To close, push the door shut until the magnetic buckle engages and secure the safety lock.
- **Using the Divider:** The removable divider allows for flexible use.
 - **Two Compartments:** With the divider installed, the crate provides two separate spaces, ideal for housing two medium-sized dogs or for separating a dog from its food/water area.
 - **Single Large Compartment:** To create a single large space for one large dog, carefully remove the divider panel by lifting it out of its slots. Ensure the crate is empty before removing the divider.
- **Furniture Functionality:** The sturdy top surface can be used as a TV stand, side table, or display area for decorative items. Ensure that items placed on top do not exceed the weight capacity and are stable.
- **Adjustable Feet:** If the crate wobbles, adjust the individual feet by twisting them until the crate is stable on

your floor.

MAINTENANCE

- **Cleaning:** The wooden surfaces, including the waterproof top, can be cleaned with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish. For the iron tubes, wipe with a damp cloth and dry thoroughly.
- **Spill Management:** In case of spills, especially on the wooden base inside the crate, clean immediately to prevent moisture absorption and potential damage.
- **Hardware Check:** Periodically inspect all screws, bolts, and latches for tightness. Retighten any loose hardware to maintain structural integrity and safety.
- **Damage Inspection:** Regularly check for any signs of wear, damage, or chewing. If significant damage occurs, discontinue use and consider replacing the affected parts or the entire unit.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Crate is wobbly or unstable.	Uneven floor surface; loose adjustable feet; loose assembly hardware.	Adjust the individual feet until the crate is level and stable. Ensure all assembly screws and bolts are tightened securely.
Doors do not close or lock properly.	Misaligned doors; loose hinges; magnetic buckle not engaging; safety latch obstructed.	Check door alignment and adjust if necessary. Tighten hinge screws. Ensure the magnetic buckle and safety latch are free from obstruction and properly installed.
Dog is chewing on crate components.	Boredom; anxiety; teething (for puppies).	Provide appropriate chew toys. Ensure your dog has enough exercise and mental stimulation. Consult a veterinarian or dog trainer for behavioral issues. While iron tubes are reinforced, persistent chewing can cause damage.
Difficulty installing the removable divider.	Divider not aligned with slots; obstruction in slots.	Ensure the divider is correctly oriented and aligned with the grooves. Clear any debris from the slots. Apply gentle, even pressure.

SPECIFICATIONS



Product Dimension

Internal dimensions - 69.68"×26.38"×28.35"



Internal dimensions
of a single cage
34.65"×26.38"×28.35"



Image: A diagram illustrating the external and internal dimensions of the Lyromix Double Dog Crate Furniture, including the dimensions of a single compartment.

- **Model:** Lyromix 70.86" Dog Crate Furniture
- **Overall Dimensions (L x D x H):** 180.86 cm x 71.9 cm x 86.4 cm (70.86"W x 28.35"D x 34.05"H)
- **Internal Dimensions of Single Cage (L x D x H):** 34.65" x 26.38" x 28.35" (approx. 88 cm x 67 cm x 72 cm)
- **Material:** Engineered Wood, Iron
- **Color:** Grey
- **Product Weight:** Approximately 9.07 kg (20 lbs) - *Note: This weight seems low for the size, likely refers to packaging or a single component. Actual assembled weight will be higher.*
- **Recommended for Species:** All breed sizes (with divider for medium, without for large)
- **Special Features:** Lockable doors, Removable divider, Adjustable feet, Waterproof surface
- **Usage:** Indoor

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact Lyromix customer service directly. Keep your purchase receipt for warranty claims.

Customer Service: Please visit the official Lyromix website or contact your retailer for support.

© 2024 Lyromix. All rights reserved.