

[Manuals.plus](#) /

› [BubbaCare](#) /

› BubbaCare Electric Nail Clipper Instruction Manual

BubbaCare B0CPDL1Y9B

BubbaCare Electric Nail Clipper Instruction Manual

Model: B0CPDL1Y9B

1. PRODUCT OVERVIEW

The BubbaCare Electric Nail Clipper is a versatile 2-in-1 device designed for trimming and polishing nails. It features two adjustable speeds, an integrated LED light for enhanced visibility, and an automatic nail clipping storage system for a clean user experience. This device is suitable for various users, including children, adults, and seniors.

Safety Note: This electric nail clipper is not suitable for babies under 8 months old due to the softness of their nails. It is recommended for children and adults.

2-in-1 Electric Nail Polisher



Figure 1: The Bubbacare Electric Nail Clipper demonstrating its dual function for trimming and polishing nails.

2. KEY FEATURES

- **Dual Functionality:** Trims and polishes nails with a single device.
- **Two Speed Settings:** Adjustable speeds to accommodate different nail hardness, suitable for various age groups.
- **Automatic Nail Chip Storage:** Integrated collection box captures nail clippings, simplifying cleanup.
- **LED Light:** Provides illumination for precise trimming, especially useful in low-light conditions.
- **Low Noise Operation:** Operates at approximately 45dB, minimizing disturbance during use.
- **Portable Design:** Compact and easy to carry for on-the-go nail care.



Polishing function



Smooth and shiny



Safe and lightweight



Lighting photos

Cleaning and Low Voice 40 DB



There are no nails running around, they are all in the nail storage compartment




Figure 2: Illustration of the nail clipper's quiet operation and integrated nail chip storage.



Kids



Adult



Senior

Note:

Not suitable for children under 12 years old to use alone.



Electric nail clippers for the whole family

Figure 3: The electric nail clipper is designed for use by individuals of all ages, from children to seniors.

3. PACKAGE CONTENTS

Upon opening the package, ensure all the following items are present:

- 1x Electric Nail Clipper
- 1x Charging Cable (USB Type-C)
- 1x Cleaning Brush
- 1x Instruction Manual

You will get:

- 1x Nail clipper
- 1x Charging line
- 1x Cleaning brush
- 1x Instructions




Figure 4: The complete set of items included in the product package.

4. SETUP

4.1 Initial Charging

Before using the device for the first time, it is recommended to fully charge the battery. Connect the provided USB Type-C charging cable to the charging port on the device and a suitable USB power adapter (not included). A full charge typically takes approximately 1 hour, providing 4-6 hours of battery life.

4.2 Power On/Off

To turn on the device, gently press the power on/off button. Press it again to cycle through speed settings or turn it off.

Small Things, Big Effect




Figure 5: Detailed diagram illustrating the various components and controls of the nail clipper.

5. OPERATING INSTRUCTIONS

5.1 Nail Trimming

1. Wash your hands to soften nails, which can aid in easier trimming.
2. Turn on the device and select the desired speed.
3. Place your nail into the trimming opening with the storage box facing upwards.
4. Gently move your finger left and right to trim the nail. The device will automatically collect clippings.

5.2 Nail Polishing

1. Turn on the device and select the desired speed.
2. For polishing the nail tip, place the nail perpendicular to the rotating polishing head.
3. For polishing the nail surface, place the nail parallel to the rotating polishing head.



Figure 6: Visual guide for using the trimming and polishing functions of the device.

5.3 Demonstration Video: Automatic Electric Nail Clipper with LED Light & 2 Speeds

Your browser does not support the video tag.

Video 1: A demonstration of the automatic electric nail clipper in action, showcasing its LED light and two-speed operation.

5.4 Demonstration Video: Electric Nail Clipper Usage

Your browser does not support the video tag.

Video 2: A brief overview of the electric nail clipper's features and how to use it for nail care.

6. MAINTENANCE

6.1 Cleaning the Device

After each use, clean the device to ensure optimal performance and hygiene. The integrated nail chip storage box can be easily emptied. Use the provided cleaning brush to remove any remaining nail debris from the trimming and polishing areas.

- Gently open the collection box to dispose of accumulated nail clippings.
- Use the cleaning brush to thoroughly clean the trimming slot and polishing disc.
- Do not rinse the device directly under water or immerse it in liquids.

7. TROUBLESHOOTING

- **Device not turning on:** Ensure the device is fully charged. Connect it to a power source using the USB Type-C cable and allow it to charge for at least 1 hour.
- **Poor trimming/polishing performance:** Clean the trimming and polishing areas thoroughly with the provided brush. Ensure nails are clean and dry before use.
- **Unusual noise during operation:** Discontinue use and check for any obstructions in the trimming or polishing mechanisms. Clean the device as per maintenance instructions. If the issue persists, contact customer support.

8. SPECIFICATIONS

| Feature | Detail |
|--------------------|---------------------------------------|
| Brand | Bubbacare |
| Model | B0CPDL1Y9B |
| Power Source | Rechargeable (USB Type-C) |
| Speed Settings | 2 Speeds |
| Noise Level | Approximately 45dB |
| Blade Material | Stainless Steel |
| Blade Edge | Straight |
| Material | Acrylonitrile Butadiene Styrene (ABS) |
| Color | White |
| Package Dimensions | 13.74 x 3.9 x 1.5 inches |
| Item Weight | 7.05 ounces |

9. WARRANTY AND SUPPORT

This product comes with a 1-month warranty. For any questions or issues encountered after receiving the

product, please contact customer service for assistance. We are committed to resolving any concerns you may have.