

BWE 8023-S-B

BWE Matte Black Triple Function Shower Fixture (Model 8023-S-B) User Manual

Model: 8023-S-B | Brand: BWE

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your BWE Matte Black Triple Function Shower Fixture. Please read this manual thoroughly before installation and use to ensure proper function and longevity of the product. Keep this manual for future reference.



Image 1.1: BWE Matte Black Triple Function Shower Fixture installed in a modern bathroom setting.

2. SAFETY INFORMATION

Please observe the following safety precautions during installation and operation:

- Ensure all water supply lines are turned off before beginning installation.
- Wear appropriate personal protective equipment (PPE) such as safety glasses and gloves.
- If you are unsure about any part of the installation process, consult a qualified plumber.
- Do not overtighten connections, as this may damage components.
- Regularly inspect the fixture for any signs of wear or damage.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning installation. If any parts are missing or damaged, please contact customer support.

- 8-inch Rainfall Shower Head
- Handheld Shower

- Installation Hardware
- Shower Hose
- Hand Sprayer Holder
- Brass Diverter Valve
- Installation Manual



Image 3.1: Overview of included components for the BWE Shower Fixture.

4. SPECIFICATIONS

Feature	Specification
Brand	BWE
Model Number	8023-S-B
Color	Black
Material	Brass (Fixture Body), Metal (Handle)

Finish Type	Matte Black
Number of Handles	2
Mounting Type	Wall Mount
Rainfall Shower Head Size	8 inches
Product Dimensions	1 x 1 x 5 inches (overall, approximate)
Item Weight	10.02 pounds





Image 4.1: Product dimensions diagram.

5. SETUP AND INSTALLATION

Installation of this shower fixture requires basic plumbing knowledge. It is recommended to consult the included installation manual for detailed step-by-step instructions or hire a professional plumber to ensure correct and secure installation.

5.1 Key Installation Features

- **Wall Mount Design:** The fixture is designed for wall-mounted installation.
- **Adjustable Height:** The shower head height can be adjusted by sliding the shower bracket along the main pipe. A knob allows for securing the desired height.



Easily Adjust Shower Height

Image 5.1: Demonstration of shower height adjustment using the pull-out mechanism and adjustment knob.



Image 5.2: Full view of the BWE Shower Fixture with water flow.

6. OPERATING INSTRUCTIONS

The BWE Triple Function Shower Fixture offers three water outlets: a rainfall shower head, a handheld sprayer, and a tub spout.

6.1 Water Temperature and Flow Control

- Use the '**H**' (**Hot**) handle to control the hot water supply and the '**C**' (**Cold**) handle for the cold water supply. Turn counter-clockwise to increase flow.
- Adjust both handles to achieve the desired water temperature and flow rate.

6.2 Function Selection

The shower mode knob, located on the main faucet body, allows you to switch between the three functions:

- Rotate the knob to direct water to the rainfall shower head.
- Rotate the knob to direct water to the handheld sprayer.
- Rotate the knob to direct water to the tub spout.



Image 6.1: Main control unit with hot/cold handles and shower mode knob.

6.3 Rainfall Shower Head

The 8-inch rainfall shower head provides a wide, high-pressure water flow. It features 360-degree rotation for optimal positioning and self-cleaning silicone nozzles to prevent mineral buildup.

8 Inch Rain Shower Head



Image 6.2: Rainfall shower head features.

6.4 Handheld Sprayer

The handheld sprayer offers flexibility and targeted cleaning. It can be adjusted in height along the main shower pipe and features 360-degree rotation for comfortable use. The sprayer also includes a pause function to conserve water when not actively spraying.



Image 6.3: Handheld sprayer rotation and height adjustment.

6.5 Tub Spout

The tub spout provides a steady stream of water for filling a bathtub. It can be rotated 360 degrees to move it out of the way when not in use.



Image 6.4: Tub spout rotation.

6.6 Product Demonstration Video

Your browser does not support the video tag.

Video 6.1: A demonstration of the BWE Shower Fixture's various functions, including the rainfall shower, handheld sprayer, and tub spout, showcasing water flow and operational features.

7. MAINTENANCE

Proper maintenance will help preserve the finish and functionality of your BWE shower fixture.

- **Cleaning the Finish:** Clean the matte black finish with a soft, damp cloth and mild soap. Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the finish.
- **Nozzle Cleaning:** The rainfall shower head features self-cleaning silicone nozzles. Periodically rub the nozzles with your finger to dislodge any mineral deposits and maintain optimal spray performance.
- **General Inspection:** Regularly check all connections for leaks and ensure handles operate smoothly.

8. TROUBLESHOOTING

If you encounter issues with your BWE shower fixture, consider the following common troubleshooting steps:

- **Low Water Pressure:** Check if the main water supply is fully open. Ensure there are no kinks in the shower hose. Clean the shower head nozzles for mineral buildup.
- **Leaks:** Verify all connections are securely tightened. If leaks persist, especially from internal components, professional assistance may be required.
- **Difficulty Switching Functions:** Ensure the shower mode knob is fully rotated to the desired position.
- **Temperature Control Issues:** Confirm both hot and cold water supplies are active and flowing correctly.

For persistent issues or complex problems, it is recommended to contact a qualified plumber or BWE customer support.

9. WARRANTY AND SUPPORT

BWE stands behind the quality of its products. If you encounter any problems with your new shower fixture or require replacement parts, please contact BWE customer support. Refer to your purchase documentation for specific warranty terms and contact information.