

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [VOUNOT](#) /

› [VOUNOT 3x3m Pop-up Gazebo Instruction Manual](#)

VOUNOT 8766363042141

VOUNOT 3x3m Pop-up Gazebo Instruction Manual

Model: 8766363042141



INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and storage of your VOUNOT 3x3m Pop-up Gazebo. Please read all instructions carefully before use to ensure safe and correct handling of the product.


SAFETY WARNINGS

Attention:

- Ensure the gazebo is properly anchored using the provided sandbags, ropes, and stakes to prevent any risks associated with wind. Failure to do so may result in damage or injury.
- Although designed to be weather-resistant, do not use the gazebo in extreme weather conditions such as heavy rain, strong winds (above 45 km/h), or snow. Disassemble and store the gazebo during such conditions.
- The gazebo's UV protection does not replace the need for personal sun protection like sunscreen.
- Always ensure the setup surface is flat and clear of obstructions.
- Keep children and pets away from the gazebo during assembly and disassembly.

PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged.

Cadre de tente Tent frame Zeltrahmen	Sacs de tente Tent bag Zelttasche	Bâche Canopy Überdachung
		
Sac de sable / Sand bag / Sandsack x4	Panneaux de fenêtre / Window panel / Fensterplatte x2	
		Panneau de porte / Door panel / Türplatte X2

Ø5x23cm Clouages / Ø5x23cm Nail / Ø5x23cm Nägel x8
3.2M Cordes / 3.2M Rope / 3.2M Seile x4



This image displays the complete list of parts for the gazebo: the foldable tent frame, the blue canopy, a black tent bag for storage, four black sandbags, eight ground nails (stakes), and four ropes for securing the gazebo.


- 1 x Tent Frame (Foldable Steel Structure)
- 1 x Canopy (100% Polyester, Blue, Silver-coated)
- 4 x Detachable Sidewalls (Waterproof, with 6 arched windows and 1 zippered door)
- 1 x Transport Bag
- 4 x Sandbags
- 8 x Ground Stakes (Nails)
- 4 x Tension Ropes (3.2m each)

SETUP INSTRUCTIONS

The VOUNOT gazebo features a 1-touch pop-up system for quick and easy assembly. While designed for one person, two people may find initial setup easier.

AVANT

Au moins 2 personnes sont requises
At least 2 people are required
Mindestens 2 Personen sind erforderlich



APRÈS

Installation facile pour 1 personne
Easy 1 person set up
Einfache Einrichtung für 1 Person



Système breveté
Patented system
Patentiertes system



1 Touche POP UP
One-Key Pop-Up
Ein-Tasten-Pop-Up

This image illustrates the ease of setup. The 'Before' section shows two people struggling to open a traditional gazebo frame. The 'After' section demonstrates one person easily deploying the VOUNOT gazebo using its patented one-key pop-up central locking mechanism, which simplifies the process.

- Unpack and Position:** Remove the folded gazebo frame from its transport bag. Place the frame on a flat, clear surface where you intend to set it up.
- Partially Expand Frame:** Gently pull the outer legs of the frame slightly outwards, allowing the frame to partially expand.
- Engage Pop-up Mechanism:** Locate the central locking button on the underside of the canopy frame. With one hand, gently push up on the central hub until it clicks into place, fully extending the frame. This activates the 1-touch pop-up system.
- Attach Canopy:** Drape the canopy over the fully extended frame, ensuring it is centered and secured at all corners.
- Adjust Height:** Press the improved buttons on each leg to adjust the gazebo to one of the three available height settings. Ensure all four legs are locked at the same height.
- Attach Sidewalls (Optional):** If desired, attach the four detachable sidewalls using the hook-and-loop fasteners or clips provided. Position the sidewalls with windows and the zippered door as preferred.

7. **Secure Anchoring:** Fill the four sandbags with sand or other heavy material and attach them to the gazebo legs. Use the provided stakes to secure the gazebo legs to the ground. For additional stability, attach the tension ropes to the gazebo frame and stake them into the ground at an angle.



This collage provides close-up views of key functionalities. It shows the central pop-up mechanism for easy setup, the ventilation opening for air circulation, the three-level height adjustment buttons, reinforced frame joints for durability, the design of the arched windows on the sidewalls, and the compact packed gazebo fitting conveniently into a car trunk, demonstrating its portability.

OPERATING INSTRUCTIONS

Height Adjustment

The gazebo frame features three adjustable height settings. To adjust, press the improved buttons located on each leg and slide the inner leg up or down to the desired height. Ensure all four legs are securely locked at the same level for stability.

Sidewalls and Ventilation

- The four sidewalls are detachable and waterproof. They can be easily attached or removed as needed for privacy, weather protection, or an open-air feel.
- The gazebo includes 6 arched windows on the sidewalls, designed to allow soft light and light ventilation.
- One sidewall features a zippered door for quick and easy entry and exit.
- A ventilation opening is integrated into the roof to ensure efficient air circulation within the gazebo.




Utilisation recommandée/Recommended use/Empfohlene Verwendung

Pour une pluie modérée <8mm/h/For moderate rain <8mm/h/Bei mäßigem Regen <8mm/h

Pour un vent modéré <45 km/h/Pour un vent modéré <45 km/h/Bei mäßigem Wind <45 km/h



Ouverture de ventilation
Ventilation opening
Belüftungsöffnung




Imperméable et anti UV
Waterproof and anti-UV
Wasserdicht und UV-beständig



Corde de fixation
Fixing rope
Befestigungsseil



Parois avec fenêtres
Walls with windows
Wände mit Fenstern



Cadre en acier ultra renforcé
Ultra-reinforced steel frame
Ultraverstärkter Stahlrahmen



4 sacs de sable fournis
4 sandbags provided
4 Sandsäcke vorhanden



This diagram points out the main features of the gazebo. It shows the waterproof and UV-resistant canopy, a ventilation opening at the top for air circulation, fixing ropes for stability, removable sidewalls with arched windows, the robust ultra-reinforced steel frame, and the four sandbags provided for anchoring.

MAINTENANCE

- Cleaning:** Clean the canopy and sidewalls with a mild soap solution and a soft cloth or sponge. Rinse thoroughly with clean water and allow to air dry completely before storage. Do not use harsh chemicals or abrasive cleaners.
- Frame Care:** Inspect the steel frame periodically for any signs of rust or damage. Clean any dirt or debris from the frame. If rust appears, clean it and apply a rust-inhibiting paint.
- Fasteners:** Check all fasteners, ropes, and stakes regularly for wear and tear. Replace any damaged components to maintain stability and safety.

STORAGE

Proper storage extends the life of your gazebo.

- Disassembly:** Reverse the assembly steps. Carefully collapse the frame by disengaging the central locking mechanism and then pushing the outer legs inwards.
- Clean and Dry:** Ensure the canopy, sidewalls, and frame are completely clean and dry before packing to prevent mold, mildew, and rust.
- Pack:** Fold the canopy and sidewalls neatly. Place the folded frame, canopy, sidewalls, sandbags, stakes, and ropes into the provided transport bag.
- Store:** Store the packed gazebo in a cool, dry place, away from direct sunlight and extreme temperatures.



This image provides the assembled dimensions of the gazebo and its compact packed size in the transport bag, illustrating its portability.

TROUBLESHOOTING

- Difficulty in Setup/Folding:** Ensure the gazebo is on a flat surface. If the frame is stiff, gently rock it while expanding/collapsing. Applying a silicone spray to moving parts can help. While designed for one person, having two people can make the process smoother, especially during initial uses.

- **Gazebo Instability:** Always use all provided anchoring accessories (sandbags, stakes, ropes). Ensure stakes are fully driven into the ground and ropes are taut. Do not use in windy conditions exceeding 45 km/h.
- **Water Leakage:** Ensure the canopy is properly stretched and secured over the frame. While waterproof up to 1200pa, prolonged exposure to heavy rain may lead to minor seepage. Avoid using in extreme downpours.
- **Zipper Issues:** If a zipper on the transport bag or sidewalls becomes stiff, apply a zipper lubricant or a small amount of wax to ease movement. Avoid forcing zippers.

SPECIFICATIONS

Feature	Specification
Brand	VOUNOT
Model Number	8766363042141
Base Area	3 x 3 meters (9.8 x 9.8 feet)
Adjustable Height	255 cm - 275 cm (100.4 in - 108.2 in)
Frame Material	Steel Alloy
Cover Material	100% Polyester with Silver Coating
UV Protection	99%
Water Resistance	Up to 1200pa (Waterproof)
Item Weight	Approximately 17.8 kg (39.2 lbs)
Packed Dimensions	120 x 22 x 21 cm (47.2 x 8.6 x 8.3 in)
Included Accessories	4 detachable sidewalls, 4 sandbags, 8 stakes, 4 tension ropes, 1 transport bag


NOTRE MODELE / OUR MODEL / UNSER MODELL


Bouton en plastique amélioré permet un réglage sécurisé de la hauteur sur trois niveaux
Improved plastic knob allows secure three-level height adjustment

Der verbesserte Kunststoffknopf ermöglicht eine sichere Höhenverstellung in drei Stufen



Tubes supplémentaires et connecteurs renforcés augmentent la stabilité

Additional tubes and reinforced connectors increase stability

Zusätzliche Rohre und verstärkte Anschlüsse erhöhen die Stabilität



Fixations en plastique étendues et renforcées protègent le poteau de la flexion

Extended and reinforced plastic brackets protect the pole from bending

Verlängerte und verstärkte Kunststoffhalterungen schützen die Stange vor Durchbiegen



Pieds métalliques robustes agrandis avec des trous percés pour plus de stabilité et de solidité.

Enlarged sturdy metal legs with drilled holes for added stability and sturdiness.

Vergrößerte, stabile Metallbeine mit Bohrlöchern für zusätzliche Stabilität und Robustheit.


AUTRES / OTHERS/ ANDERE


La conception rugueuse risque de pincer les doigts

Rough design risks pinching fingers

Bei rauem Design besteht die Gefahr, dass man sich die Finger einklemmt



Tubes fragiles et connecteurs pas solides, facile à casser

Fragile tubes and connectors not strong, easy to break

Zerbrechliche Rohre und Anschlüsse, nicht stabil, leicht zu brechen



Sans aucune protection de renfort, facile à déformer

Without any reinforcement protection, easy to deform

Ohne Verstärkungsschutz, leicht verformbar



Pieds en plastique instables et peu solides

Unstable and flimsy plastic feet

Instabile und dünne Kunststofffüße

This image compares the superior design of the VOUNOT gazebo with typical shortcomings found in other gazebos, highlighting improved plastic knobs for secure three-level height adjustment, additional tubes and reinforced connectors for increased stability, extended and reinforced plastic brackets to prevent pole bending, and enlarged sturdy metal legs with drilled holes for added stability.

WARRANTY AND SUPPORT

Specific warranty information is not provided in the product details. For any questions regarding warranty, product defects, or support, please contact the seller or manufacturer directly through your purchase platform. Keep your proof of purchase for any warranty claims.