

GOOJODOQ SM-X210

GOOJODOQ Keyboard Case User Manual

For Samsung Galaxy Tab A9+ 11" 2023 (Models: SM-X210/X215/X216)

1. INTRODUCTION

Thank you for choosing the GOOJODOQ Keyboard Case. This product is designed to enhance your Samsung Galaxy Tab A9+ 11" 2023 experience by providing a protective cover and a detachable QWERTZ Bluetooth keyboard. This manual provides essential information for setup, operation, maintenance, and troubleshooting to ensure optimal use of your device.

1.1. Compatibility

This keyboard case is specifically designed for the **Samsung Galaxy Tab A9+ 11" 2023** models:

- SM-X210
- SM-X215
- SM-X216

Please verify your tablet's model number before use. This product is **not compatible** with the Samsung Galaxy Tab A9 8.7" 2023.



This image illustrates the compatible tablet models, specifically the Samsung Galaxy Tab A9+ 11-inch (models SM-X210, SM-X215, SM-X216). It also shows that the product is not compatible with the smaller Samsung Galaxy Tab A9 8.7-inch model.

2. PACKAGE CONTENTS

Upon opening the package, please ensure all the following items are present:

- 1 x Protective Case for Samsung Galaxy Tab A9+ 11"
- 1 x Detachable Bluetooth Keyboard (QWERTZ Layout)
- 1 x USB Charging Cable
- 1 x User Manual



This image displays all items included in the product package: the protective case, the detachable Bluetooth keyboard, a USB charging cable, and the user manual.

3. PRODUCT FEATURES

- **Detachable Bluetooth Keyboard:** The QWERTZ keyboard connects wirelessly via Bluetooth, offering a comfortable typing experience. It can be easily removed from the case for flexible use.
- **Protective Case:** Made from soft TPU material, the case provides comprehensive protection against drops and impacts, including lens protection.
- **Integrated Pen Holder:** A dedicated slot is included to securely store your stylus (stylus not included).
- **Precise Cutouts:** Ensures full access to all ports, buttons, and the camera without removing the case.
- **Multiple Viewing Angles:** The anti-slip design and three adjustable positions allow for various viewing angles, optimizing comfort for typing, watching, or drawing.



The inside of the case features a convenient pen slot, designed to securely hold your stylus and prevent loss. Please note that the stylus is not included.



This image demonstrates the precise cutouts on the protective case, ensuring full access to the tablet's ports, buttons, and camera, providing comprehensive protection.



This diagram illustrates the anti-slip design and three card slots that allow for multiple viewing angles, providing a comfortable experience for various activities.

4. SETUP

4.1. Installing the Tablet

1. Gently align your Samsung Galaxy Tab A9+ 11" with the case.
2. Insert the tablet into the soft TPU frame, ensuring all edges are securely fitted.
3. Confirm that all ports, buttons, and the camera are accessible through the precise cutouts.

4.2. Charging the Keyboard

Before initial use, fully charge the keyboard. Use the provided USB charging cable to connect the keyboard to a USB power source (e.g., computer, wall adapter). The charging indicator light will illuminate during charging and turn off when fully charged.

4.3. Connecting the Keyboard via Bluetooth

1. Ensure the keyboard is charged.
2. Turn on the keyboard by sliding the power switch to the 'ON' position. The Bluetooth indicator light will flash.
3. On your Samsung Galaxy Tab A9+, go to **Settings > Connected devices > Bluetooth**.
4. Turn on Bluetooth on your tablet.
5. The tablet will search for available devices. Select "Bluetooth Keyboard" (or a similar name) from the list.
6. If prompted, enter the pairing code displayed on your tablet using the keyboard and press Enter.
7. Once connected, the Bluetooth indicator light on the keyboard will stop flashing and remain solid or turn off, indicating a successful connection.

5. OPERATING INSTRUCTIONS

5.1. Basic Keyboard Usage

The keyboard features a standard QWERTZ layout, providing a familiar typing experience. Use it for text input, navigation, and executing commands on your tablet.



A detailed view of the QWERTZ keyboard layout, designed to match German input habits, including special characters and Android system key combinations.

5.2. Special Keys and Functions

The keyboard includes function keys and Android-specific key combinations for enhanced productivity:

- **Fn Key:** Use in combination with other keys to access special functions (e.g., media controls, volume adjustment, screen brightness).
- **Android System Keys:** Dedicated keys for Home, Back, Recent Apps, and other Android functionalities are integrated.
- **Scissor Keys:** The scissor-switch keys provide a quiet and comfortable typing experience.

5.3. Adjusting Viewing Angles

The case features multiple grooves to support your tablet at different viewing angles. Simply place the bottom edge of your tablet into one of the grooves to achieve your desired angle for typing, watching videos, or browsing.



A collage demonstrating the versatility of the keyboard case for different uses, including watching videos (leisure), studying, and conducting video calls (work).

6. MAINTENANCE

6.1. Cleaning the Case and Keyboard

- **Case:** Wipe the case with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Keyboard:** Use a soft, dry cloth to clean the keyboard. For stubborn dirt, a slightly damp cloth can be used, ensuring no moisture enters the keys or ports. Do not spray cleaners directly onto the keyboard.

6.2. Battery Care

- To prolong battery life, avoid fully discharging the keyboard battery frequently.
- Charge the keyboard regularly, even if not in constant use.
- Store the keyboard in a cool, dry place when not in use for extended periods.

7. TROUBLESHOOTING

7.1. Keyboard Not Connecting via Bluetooth

- **Check Power:** Ensure the keyboard is turned on and fully charged.
- **Re-pair:** Delete the keyboard from your tablet's Bluetooth device list and attempt to pair it again (refer to Section 4.3).

- **Restart Devices:** Restart both your tablet and the keyboard.
- **Proximity:** Ensure the keyboard and tablet are within close range (typically 10 meters or 33 feet).

7.2. Keys Not Responding

- **Check Connection:** Verify that the keyboard is properly connected via Bluetooth.
- **Recharge:** The battery might be low. Charge the keyboard.
- **Clean:** Ensure no debris is lodged under the keys.

7.3. Charging Issues

- **Cable Check:** Ensure the charging cable is securely connected to both the keyboard and the power source. Try a different USB cable or power adapter.
- **Power Source:** Verify that the USB power source is functional.

8. SPECIFICATIONS

| | |
|--------------------------------|---|
| Brand | GOOJODOQ |
| Model Number | SM-X210 |
| Compatible Devices | Samsung Galaxy Tab A9+ 11" 2023 (SM-X210/X215/X216) |
| Connectivity Technology | Bluetooth |
| Keyboard Layout | QWERTZ |
| Special Features | Detachable Keyboard, Rechargeable, Pen Holder, Precise Cutouts, Multiple Viewing Angles |
| Battery Type | Lithium-ion (included) |
| Color | Blue |

9. WARRANTY AND SUPPORT

GOOJODOQ is committed to providing high-quality products and customer satisfaction. If you encounter any issues or have questions regarding your GOOJODOQ Keyboard Case, please do not hesitate to contact our friendly customer service team. We are here to assist you.

For support, please refer to the contact information provided with your purchase or visit the official GOOJODOQ website.