

[Manuals.plus](#) /

> [VTech](#) /

> VTech Baby Animal Rhymes Storytime Interactive Book - Model 567803 Instruction Manual

VTech 567803

VTech Baby Animal Rhymes Storytime Interactive Book - Model 567803 Instruction Manual

Brand: VTech | Model: 567803

INTRODUCTION

The VTech Baby Animal Rhymes Storytime interactive book is designed to engage and entertain young children while fostering early learning. This durable book features six wipe-clean pages, a light-up button, and plays a variety of songs and melodies. It encourages interaction, develops early language skills, manual dexterity, and promotes early reading concepts.

Key Features:

- Interactive learning fun for exploration.
- Light-up button introduces animals and their sounds.
- Music button plays upbeat melodies for engaging playtime.
- Motion sensor activates nursery rhymes when pages are turned.
- Durable, hard plastic pages are easy to wipe clean.
- Includes 3 sing-along songs and 15 melodies.

PACKAGE CONTENTS

Ensure all items are present upon unboxing:

- VTech Baby Animal Rhymes Storytime Book (Model 567803)
- Quick Start Guide



Image: The VTech Baby Animal Rhymes Storytime book shown in its retail packaging, highlighting the product's appearance before unboxing.

SETUP

Battery Installation

The VTech Baby Animal Rhymes Storytime book requires 2 AAA batteries (included). To install or replace batteries:

1. Locate the battery compartment on the back of the book.
2. Using a screwdriver, loosen the screw on the battery compartment cover.
3. Remove the cover.
4. Insert 2 new AAA (Alkaline) batteries, ensuring correct polarity (+/-).
5. Replace the battery compartment cover and tighten the screw.

Note: Always use new batteries of the recommended type. Do not mix old and new batteries or different types of batteries.

OPERATING INSTRUCTIONS

Power On/Off and Volume Control

Locate the power and volume switch on the side of the book. Slide the switch to turn the unit ON or OFF, and to select between two volume levels.

Interactive Play Modes

The book features multiple interactive modes:

- **Learning Mode:** Turn the pages to hear animal names, sounds, and phrases. Press the light-up sun button to hear additional facts or questions related to the current page.
- **Music Mode:** Press the music note button to play upbeat melodies. The light-up sun button will also activate musical responses.
- **Page Turning:** Each of the six durable plastic pages features a motion sensor. Turning a page automatically triggers songs and phrases related to the animals and rhymes depicted.
- **Light-Up Button:** The prominent light-up sun button introduces animals and their sounds, enhancing visual and auditory learning.



Image: A detailed view of the interactive light-up sun button and the durable, wipe-clean plastic pages of the book.



Image: The interactive book open to a colorful page featuring a deer and a fox, illustrating the engaging visual content.



Image: The interactive book open to a vibrant page displaying sheep and a cow, showcasing another set of animal characters.

Product Overview Video

Your browser does not support the video tag.

Video: A brief product overview demonstrating the VTech Baby Animal Rhymes Storytime book's features and functionality.

CARE AND MAINTENANCE

- **Cleaning:** The hard plastic pages are designed to be wipe-clean. Use a soft, damp cloth to clean the surfaces. Do not immerse the book in water.
- **Storage:** Store the book in a cool, dry place away from direct sunlight and heat sources.
- **Battery Care:** Remove batteries if the unit will not be used for an extended period to prevent leakage.

TROUBLESHOOTING

- **No Power:** Ensure the power switch is in the ON position. Check if the batteries are correctly installed and not depleted. Replace with new batteries if necessary.
- **Sound Issues:** Adjust the volume switch. If sound is still low or distorted, replace batteries.
- **Pages Not Responding:** Ensure the book is on a flat surface and pages are turned completely. Check battery levels.

SPECIFICATIONS

Brand Name	VTech
------------	-------

Model Number	567803
Age Range Description	9-36 months
Target Gender	Unisex
Material Type	Plastic
Educational Objective	Animal Recognition, Sound Recognition
Number of Batteries	2 AAA batteries required (included)
Battery Description	Alkaline
Operation Mode	Manual
Item Weight	0.3 Kilograms
Item Dimensions	1.38 x 5.71 x 6.89 inches

WARRANTY AND SUPPORT

For warranty information or customer support regarding your VTech Baby Animal Rhymes Storytime book, please refer to the Quick Start Guide included in the package or visit the official VTech website. Contact information for customer service is typically provided in the product documentation.