

SEAGO SG-2752

SEAGO SG-2752 Electric Toothbrush User Manual

Model: SG-2752

INTRODUCTION

The SEAGO SG-2752 Electric Toothbrush is designed to provide a superior cleaning experience with advanced sonic technology. This manual provides essential information for the safe and effective use, setup, operation, and maintenance of your new electric toothbrush.



Image: The SEAGO SG-2752 electric toothbrush showcasing its ultrasonic technology and design.

SAFETY INFORMATION

Please read all safety instructions before using this product. Keep this manual for future reference.

- Keep brush heads out of reach of young children to prevent choking hazards.
- Do not disassemble or attempt to repair the device yourself.
- Ensure the charging cable and port are dry before charging.

- Consult a dentist before use if you have severe gum disease or oral surgery.

PACKAGE CONTENTS

Your SEAGO SG-2752 Electric Toothbrush package includes the following items:

- 1 x SEAGO SG-2752 Electric Toothbrush Handle
- 8 x Replacement Brush Heads (including standard and tongue cleaning types)
- 1 x Toothbrush Wall Holder
- 1 x Travel Case
- 1 x Type-C Charging Cable

Image: The included toothbrush holder and travel case for convenient storage and portability.



Image: Illustration of the two types of brush heads provided: high-density 3D cutting bristles and a silicone tongue cleaning brush head.

SETUP

Follow these steps to prepare your toothbrush for first use:

1. Unpack the toothbrush and all its components.
2. Attach a brush head to the toothbrush handle. Ensure it clicks securely into place.
3. Charge the toothbrush fully before initial use. Refer to the 'Charging' section for details.
4. Wet the brush head and apply a small amount of toothpaste.

Your browser does not support the video tag.

Video: A demonstration of unboxing and setting up the SEAGO electric toothbrush, including attaching the brush head and preparing for use.

CHARGING

The SEAGO SG-2752 Electric Toothbrush is equipped with a long-lasting lithium-ion battery.

- Connect the Type-C charging cable to the charging port at the bottom of the toothbrush handle and to a compatible USB power adapter (not included).

- A full charge takes approximately 4 hours and provides up to 30 days of use.
- The toothbrush will indicate a low battery level when charging is required.

OPERATING INSTRUCTIONS

Your toothbrush features 5 brushing modes, a 2-minute smart timer, a 30-second interval reminder, and a pressure sensor.

Power On/Off and Mode Selection

- Press the power button once to turn the toothbrush on.
- Press the power button repeatedly to cycle through the 5 modes: Clean, White, Gentle, Massage, Polish.
- Press and hold the power button for 3 seconds to turn the toothbrush off.
- The toothbrush will remember the last mode used for your next brushing session.



Image: The toothbrush handle displaying the five distinct brushing modes: Clean, White, Gentle, Massage, and Polish.

Brushing Technique

- Apply the brush head to your teeth at a slight angle towards the gum line.
- Move the brush slowly across each tooth, allowing the sonic vibrations to clean effectively.
- The 3-second gradual strength function prevents toothpaste splatter upon startup.

Your browser does not support the video tag.

Video: A user demonstrating the proper brushing technique with the SEAGO electric toothbrush.

Smart Timer and Interval Reminder

- The built-in 2-minute smart timer ensures you brush for the dentist-recommended duration.
- A 30-second interval reminder will briefly pause the brushing action, signaling you to move to a different quadrant of your mouth.



Image: Visual representation of the 2-minute smart timer and 30-second interval reminders for balanced brushing.

Your browser does not support the video tag.

Video: A short clip highlighting the integrated 2-minute timer feature of the toothbrush.

Pressure Sensor

- The intelligent pressure sensor provides an audible warning if you apply too much pressure while brushing.
- This feature helps protect your teeth and gums from damage due to excessive force.




Image: Diagram illustrating the smart pressure sensor that alerts users when brushing too hard.

MAINTENANCE

Cleaning the Toothbrush

- After each use, rinse the brush head thoroughly under running water.
- Wipe the toothbrush handle with a damp cloth. The seamless button design prevents dirt buildup, making it easy to clean.
- The toothbrush is IPX7 waterproof, allowing it to be safely rinsed or used in the shower.



Image: The toothbrush submerged in water, demonstrating its IPX7 waterproof capability.

Brush Head Replacement

- It is recommended to replace the brush head every 3 months, or sooner if the bristles become frayed.
- To replace, simply pull the old brush head off and push a new one onto the handle until it clicks.
- The included 8 replacement brush heads can last up to 24 months.

TROUBLESHOOTING

If you encounter any issues with your SEAGO SG-2752 Electric Toothbrush, please refer to the following common solutions:

- **Toothbrush not turning on:** Ensure the toothbrush is fully charged. If the issue persists, try connecting it to the charger to reset.
- **Weak vibrations:** Recharge the toothbrush. Battery levels can affect performance.
- **Toothpaste splatter:** Ensure the brush head is wet and placed in your mouth before turning on the device. Utilize the 3-second gradual strength feature.
- **Button unresponsive:** If the power button becomes unresponsive, try plugging the toothbrush into its charger. This can sometimes reset the device.

For persistent issues not covered here, please contact customer support.

SPECIFICATIONS

Model Number	SG-2752
Vibrations per Minute	Up to 40,000
Brushing Modes	5 (Clean, White, Gentle, Massage, Polish)
Battery Type	Lithium Ion (included)
Battery Life	Up to 30 days on a 4-hour charge
Waterproof Rating	IPX7
Included Components	Toothbrush handle, 8 brush heads, wall holder, travel case, Type-C cable
Handle Material	Plastic
Bristle Material	Nylon

WARRANTY AND SUPPORT

SEAGO offers a 3-year guarantee on this product. For any questions, technical support, or warranty claims, please refer to the contact information provided with your purchase or visit the official SEAGO website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question