

[Manuals.plus](#) /

> [Wodeer](#) /

> Wodeer Black 4-Drawer Dresser with LED Light (Model WDF026-BK) User Manual

## Wodeer WDF026-BK

# Wodeer Black 4-Drawer Dresser with LED Light

Model: WDF026-BK

## 1. INTRODUCTION

Thank you for choosing the Wodeer Black 4-Drawer Dresser with LED Light. This manual provides essential information for the safe assembly, operation, and maintenance of your new dresser. Please read these instructions carefully before beginning assembly and retain them for future reference.

This dresser is designed to provide ample storage and a modern aesthetic for various rooms, including bedrooms, hallways, and entryways. It features four spacious drawers, an open shelf, and integrated LED lighting.



Image 1.1: The Wodeer Black 4-Drawer Dresser with LED Light, showcasing its design and open shelf.

## 2. SAFETY INFORMATION

- Always assemble the dresser on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- **Anti-Tipping Device:** This dresser includes an anti-tipping device. It is crucial to install this device to prevent accidental tipping, especially in households with children or pets. Secure the dresser to the wall according to the assembly instructions.
- Do not overload drawers. Distribute weight evenly.
- Keep small parts and packaging materials away from children.



Image 2.1: Detail of the anti-tipping device installation point, metal corner decorations, and the smooth drawer slide mechanism.

### 3. PACKAGE CONTENTS

Before assembly, verify that all components are present. If any parts are missing or damaged, please contact customer support.

#### 3.1. Parts List

- Dresser Panels (Top, Bottom, Sides, Back)
- Drawer Panels (Front, Back, Sides, Bottom)
- Metal Handles
- Drawer Slides (Metal Runners)
- LED Light Strip with Controller
- Anti-Tipping Device

#### 3.2. Hardware and Tools

- Screws, dowels, cam locks, and other fasteners
- Allen wrench (if required)

- Instruction Manual

All necessary tools for assembly are included in the package.

## 4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly is required for this dresser. Follow the step-by-step diagrams provided in the included instruction booklet. It is recommended to have two people for assembly.

1. **Prepare the Area:** Clear a spacious, clean, and soft area for assembly to prevent damage to the dresser components.
2. **Identify Parts:** Lay out all parts and hardware, comparing them with the parts list to ensure everything is present.
3. **Assemble the Frame:** Follow the diagrams to connect the main panels of the dresser frame.
4. **Install Drawer Slides:** Attach the metal drawer slides to the dresser frame and to the drawer sides. Ensure they are aligned correctly for smooth operation.
5. **Assemble Drawers:** Construct each of the four drawers, attaching the metal handles.
6. **Insert Drawers:** Carefully slide the assembled drawers into the dresser frame.
7. **Install LED Light Strip:** Adhere the LED light strip to the designated area within the open shelf. Connect it to the power source.
8. **Attach Anti-Tipping Device:** Securely fasten the anti-tipping device to the back of the dresser and to a wall stud using the provided hardware. This step is critical for safety.

Refer to the detailed diagrams in your assembly booklet for visual guidance on each step.

## 5. OPERATING INSTRUCTIONS

### 5.1. Drawer Operation

The four drawers are equipped with smooth metal runners for easy opening and closing. To open, gently pull the metal handle. To close, push the drawer until it is fully seated.

## Large Capacity Storage Drawers



Image 5.1: Open drawers demonstrating the storage capacity for clothing and other items.

### 5.2. LED Light Operation

The integrated LED light strip offers customizable lighting options. It can be controlled via a physical button or a mobile application.

- **Button Control:** Use the button on the LED light controller to cycle through 7 different colors and various light modes.
- **Mobile App Control:** Download the designated mobile application (refer to the LED light instruction sheet for app details). The app allows for more advanced control, including color selection, brightness adjustment, music synchronization, and timing modes.

# Dressers with Adjustable RGB Light



Key Control



RGB  
Colors



Light  
Mode



Music  
Mode



Mic  
Mode



Timing  
Mode



APP Control

Lights flash to the rhythm of the music



Image 5.2: Visual representation of the LED light features, including color changes and control options.

## 6. MAINTENANCE

- **Cleaning:** Wipe the dresser surfaces with a dry, soft cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Spills:** Immediately wipe up any spills with a dry cloth to prevent moisture damage.
- **Durability:** The dresser is crafted from high-quality engineered wood, designed to be scratch-resistant and wear-resistant. However, avoid placing extremely hot or sharp objects directly on the surface without protection.
- **Fasteners:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.

## 7. TROUBLESHOOTING

### 7.1. Drawers Not Sliding Smoothly

- **Check Alignment:** Ensure the drawer slides are correctly aligned on both the drawer and the dresser frame.
- **Obstructions:** Look for any objects or debris obstructing the drawer slides.
- **Tightness:** Verify that all screws securing the drawer slides are tight.

## 7.2. LED Lights Not Working


- **Power Connection:** Ensure the LED light strip is properly plugged into a working power outlet.
- **Controller Connection:** Check that the LED strip is securely connected to its controller.
- **App Connection:** If using the mobile app, ensure Bluetooth is enabled on your device and the app is correctly paired with the LED controller.

## 7.3. Dresser Wobbles

- **Level Surface:** Ensure the dresser is placed on a flat, level surface.
- **Tighten Fasteners:** Re-tighten all assembly screws and bolts.
- **Anti-Tipping Device:** Confirm the anti-tipping device is securely installed to the wall.

## 8. SPECIFICATIONS

Feature	Detail
Brand	Wodeer
Model Name	Dresser for Bedroom with LED lights
Item Model Number	WDF026-BK
Product Dimensions (D x W x H)	13.7" x 47.2" x 29.5"
Item Weight	68.45 Pounds
Color	Black
Furniture Finish	Black
Room Type	Bedroom, Living Room, Nursery, Hallway, Kitchen
Number of Drawers	4
Drawer Type	Side Mount
LED Lighting	7 colors, button and mobile app control
Assembly Required	Yes
Product Care Instructions	Wipe with Dry Cloth
Target Audience	Adult



Net Weight:68.34LBS



Image 8.1: Detailed dimensions of the dresser and a single drawer.

## 9. WARRANTY AND SUPPORT

Wodeer is committed to providing quality products and customer satisfaction. If you experience any issues such as missing parts, quality concerns, or require assistance with assembly, please contact Wodeer customer support. We are available to provide replacement accessories or solutions to ensure your satisfaction.

For support, please refer to the contact information provided in your product packaging or visit the official Wodeer store online.