



[Manuals.plus](#) /

> [AJ ENJOY](#) /

> AJ ENJOY 30" Round Propane Fire Pit Table User Manual

AJ ENJOY B0CPHYKT98

AJ ENJOY 30" Round Propane Fire Pit Table User Manual

Model: B0CPHYKT98

Important: Read this manual completely before assembly and use.

1. IMPORTANT SAFETY INFORMATION

WARNING: For outdoor use only. Improper installation, adjustment, alteration, service, or maintenance can cause injury or property damage. Read the installation, operating, and maintenance instructions thoroughly before installing or servicing this equipment.

DANGER: If you smell gas:

1. Shut off gas to the appliance.
2. Extinguish any open flame.
3. If odor continues, keep away from the appliance and immediately call your gas supplier or fire department.

WARNING: Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

WARNING: Use in a well-ventilated area. Handle propane carefully. Follow local regulations for outdoor fire features.

Always ensure the fire pit is on a level, non-combustible surface. Keep children and pets away from the fire pit during operation.

2. PRODUCT OVERVIEW AND FEATURES

The AJ ENJOY 30" Round Propane Fire Pit Table is designed to provide warmth and ambiance for outdoor gatherings. This unit features a durable steel construction and a 50,000 BTU heat output.

Key Features:

- **50,000 BTU Heat Output:** Provides substantial warmth for outdoor spaces.
- **Durable Construction:** Made from alloy steel with a painted finish, designed for outdoor use.
- **Integrated Propane Tank Storage:** Features a curved door for discreetly storing a 20lb propane tank.
- **Easy Ignition:** Equipped with an electric ignitor for convenient startup.
- **Lava Rocks Included:** Enhances the flame appearance and heat distribution.
- **Steel Lid:** Converts the fire pit into a solid table when not in use.
- **Adjustable Flame:** Control knob allows adjustment of flame intensity.
- **Safety Features:** Includes a safety thermocouple and double insulation panels for propane tank safety.



Image 2.1: The AJ ENJOY 30-inch Round Propane Fire Pit Table in operation, showcasing the flame and overall design.



Image 2.2: The fire pit table on an outdoor deck, demonstrating its use as a centerpiece for social gatherings.



Image 2.3: A closer view of the fire pit table with lit flames and two wine glasses on the tabletop.



Image 2.4: The fire pit table positioned on a patio, complementing other outdoor furniture.



Image 2.5: The access door opened, showing the internal compartment designed to hold a standard propane tank.



Image 2.6: A detailed view of the burner assembly and lava rocks, with flames visible.



Image 2.7: The fire pit table with its steel lid partially covering the burner area, demonstrating its dual function as a table.

3. SETUP AND ASSEMBLY

This fire pit table is designed for straightforward assembly. Ensure all components are present before beginning.

Components Included:

- Steel tabletop
- Fire pan and Stainless Steel burner
- Gas regulator
- Safety thermocouple
- Lava Rocks
- Steel Lid
- User Manual (this document)

Assembly Steps:

1. Unpack all components and verify against the parts list.
2. Place the main body of the fire pit in the desired outdoor location, ensuring it is on a stable, level, non-combustible surface.
3. Open the access door and carefully place a 20lb propane tank (not included) into the designated storage space.
4. Connect the gas regulator hose to the propane tank. Ensure a secure connection.
5. Distribute the lava rocks evenly over the burner area, ensuring not to block the ignitor or burner ports.
6. Close the access door.

Refer to the included user manual for detailed diagrams and specific fastening instructions.

4. OPERATING INSTRUCTIONS

Before First Use:

- Perform a leak test on all gas connections according to the instructions in the full manual.
- Ensure the area around the fire pit is clear of flammable materials.

Lighting the Fire Pit:

1. Ensure the control knob is in the "OFF" position.
2. Open the valve on the propane tank.
3. Push and turn the control knob to the "LOW" position.
4. Press and hold the ignitor button until the burner ignites. You may need to hold the button for a few seconds to allow gas to flow.
5. Once ignited, continue to hold the control knob in for 10-15 seconds to engage the thermocouple.
6. Release the control knob. If the flame extinguishes, repeat steps 3-5.
7. Adjust the flame height by turning the control knob between "LOW" and "HIGH".

Your browser does not support the video tag.

Video 4.1: Demonstration of the fire pit table's operation, including ignition and flame adjustment. This video shows the control knob and the propane tank storage.

Shutting Down the Fire Pit:

1. Turn the control knob to the "OFF" position.
2. Close the valve on the propane tank.
3. Allow the fire pit and lava rocks to cool completely before covering or moving.

5. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your fire pit table.

Cleaning:

- **Exterior Surfaces:** Wipe with a soft, damp cloth. Do not use abrasive cleaners or harsh chemicals.
- **Lava Rocks:** Periodically inspect lava rocks for debris. Replace if they become excessively dirty or degraded.
- **Burner:** Keep the burner ports clear of insects and debris. Use a soft brush to clean.

Storage:

- When not in use, especially during inclement weather or extended periods, cover the fire pit with the provided steel lid or a suitable outdoor cover.
- Disconnect the propane tank if storing for a long duration. Store the propane tank in a well-ventilated area, away from direct sunlight and heat sources.

Inspections:

- Regularly check gas hoses and connections for signs of wear, cuts, or leaks.
- Inspect the ignitor and thermocouple for proper function.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Burner does not ignite.	<ul style="list-style-type: none">• No gas flow.• Ignitor not sparking.• Air in gas line.	<ul style="list-style-type: none">• Check propane tank valve and ensure tank is not empty.• Verify ignitor electrode is clean and properly positioned.• Purge air from the gas line by repeating ignition steps several times.
Low flame or inconsistent flame.	<ul style="list-style-type: none">• Low propane level.• Obstructed burner ports.• Gas regulator issue.	<ul style="list-style-type: none">• Replace or refill propane tank.• Clean burner ports.• Ensure regulator is properly connected and not damaged.
Gas odor detected.	<ul style="list-style-type: none">• Gas leak.	<ul style="list-style-type: none">• Immediately shut off gas. Perform a leak test. If odor persists, do not operate and contact a qualified service technician.

For issues not listed here, or if troubleshooting steps do not resolve the problem, contact customer support.

7. SPECIFICATIONS

- **Model:** B0CPHYKT98
- **Brand:** AJ ENJOY
- **Material:** Alloy Steel
- **Product Dimensions:** 30"D x 30"W x 24.8"H
- **Item Weight:** 49 Pounds
- **Fuel Type:** Liquefied Petroleum Gas (Propane)
- **Heat Output:** 50,000 BTU
- **Color:** Black
- **UPC:** 614158501748

8. WARRANTY AND SUPPORT

AJ ENJOY provides a **1-year worry-free quality assurance** for this product. For any issues or support needs, please contact our expert support team via email. We are committed to resolving issues quickly.

For further assistance, please refer to the contact information provided with your purchase or visit the official AJ ENJOY website.