

[Manuals.plus](#) /

> [iPhanmis](#) /

> iPhanmis XS15Pro 3G Mini Smartphone User Manual

iPhanmis XS15Pro

iPhanmis XS15Pro 3G Mini Smartphone User Manual

Model: XS15Pro

INTRODUCTION

This manual provides essential information for the safe and efficient use of your iPhanmis XS15Pro 3G Mini Smartphone. Please read this manual thoroughly before operating the device and retain it for future reference.



Image: Overview of the iPhanmis XS15Pro Mini Smartphone, highlighting its compact size and key features like HD screen, Android system, memory, and 3G connectivity.

PACKAGE CONTENTS

Verify that all items are present in the package:

- iPhanmis XS15Pro 3G Mini Smartphone
- Charging Cable (Type-C)
- User Manual
- SIM Ejector Tool (if applicable)

SETUP

1. Inserting SIM Cards and SD Card

The XS15Pro supports dual SIM cards for flexible network usage. It also supports an SD card for expanded storage.

1. Locate the SIM card tray on the side of the device.
2. Insert the SIM ejector tool into the small hole next to the tray to open it.
3. Place your Nano-SIM cards (up to two) and/or a microSD card into the designated slots on the tray. Ensure they are correctly oriented.
4. Gently push the tray back into the phone until it clicks into place.



Image: Illustration of the dual SIM card tray and how to insert SIM cards into the iPhanmis XS15Pro smartphone.

2. Charging the Device

Before first use, fully charge your smartphone.

1. Connect the Type-C charging cable to the charging port at the bottom of the phone.
2. Connect the other end of the cable to a compatible USB power adapter (not included) and plug it into a power outlet.
3. The battery indicator on the screen will show charging status.



Image: The iPhanmis XS15Pro smartphone connected to a Type-C charging cable, illustrating the charging process.

3. Powering On/Off

- To power on: Press and hold the Power button until the screen lights up.
- To power off: Press and hold the Power button, then select "Power off" from the options on the screen.

OPERATING INSTRUCTIONS

1. Navigating the Android 9.0 System

Your XS15Pro runs on Android 9.0, offering a user-friendly interface.

- **Touchscreen Gestures:** Tap to select, swipe to scroll, pinch to zoom.
- **Home Screen:** Access your apps, widgets, and notifications.
- **Notifications Panel:** Swipe down from the top of the screen to view notifications and quick settings.



Image: The iPhanmis XS15Pro smartphone displaying its Android 9.0 home screen with various application icons.

2. Connecting to Wi-Fi

1. Go to **Settings** > **Network & Internet** > **Wi-Fi**.
2. Toggle Wi-Fi on.
3. Select your desired network from the list and enter the password if prompted.

3. Making Calls and Sending Messages

- Open the **Phone** app to dial numbers or select contacts.
- Open the **Messages** app to send and receive SMS/MMS.

4. Using the Camera

The smartphone features front and rear cameras for photos and videos.

1. Open the **Camera** app.
2. Tap the shutter button to take a photo.

3. Switch between front and rear cameras using the icon on the screen.

Hi-def camera, quick release

Clear large film, steady out of the film

Every time you press the shutter, it shows subtle colors and moving moments of light and dark details better. As you can see, the "Mirror" is in control.

20%↑
Signal-to-noise ratio increased

15%↑
Color reduction promotion



The figure is more beautiful and charming

If you want to shoot, shoot the star

Portrait mode, how to shoot are photogenic, provide a variety of illusory style mask intelligent optimization of skin, easy to take a shot, change the style of selfie.



Capture the moment, wonderful moment

The main camera has a large aperture and micron pixels. This powerful combination enhances sensitivity in backlight or low light, so just aim and shoot to make sure your photos stay sharp and bright.





Image: Close-up of the iPhanmis XS15Pro's rear camera module, highlighting its multi-lens design for photography.

5. Managing Storage and Apps

The device comes with 2GB RAM and 16GB ROM, expandable via microSD card.

- To install apps: Use the Google Play Store.
- To manage storage: Go to **Settings > Storage**.
- To manage apps: Go to **Settings > Apps & notifications**.



Image: A visual representation of the iPhanmis XS15Pro's internal components, emphasizing its 2GB RAM and 16GB storage capacity.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the screen and body. Avoid harsh chemicals.
- **Software Updates:** Regularly check for and install system updates to ensure optimal performance and security. Go to **Settings > System > Advanced > System update**.
- **Battery Care:** Avoid extreme temperatures. Do not let the battery fully discharge frequently.
- **Data Backup:** Regularly back up important data to a computer or cloud service to prevent loss.

TROUBLESHOOTING

Problem	Solution
Device does not power on.	Ensure the battery is charged. Connect to a charger for at least 30 minutes, then try powering on again.
Cannot connect to Wi-Fi.	Check if Wi-Fi is enabled in settings. Restart your router and the phone. Verify the Wi-Fi password.
SIM card not detected.	Ensure the SIM card is correctly inserted in the tray. Restart the phone. Check if the SIM card is active with your carrier.
Apps are slow or crashing.	Close background apps. Clear app cache (Settings > Apps & notifications > select app > Storage & cache > Clear cache). Restart the phone.
Battery drains quickly.	Reduce screen brightness. Disable unused features like GPS, Bluetooth, and Wi-Fi. Close background apps. Check battery usage in Settings > Battery .

SPECIFICATIONS

Feature	Detail
Model Number	XS14pro (also known as XS15Pro)
Operating System	Android 9.0
Display Size	3.0 Inches

Feature	Detail
Resolution	1280 x 720
RAM	2GB
ROM (Internal Storage)	16GB
Expandable Storage	Yes, via MicroSD card
Cellular Technology	3G
Wireless Connectivity	Wi-Fi, Bluetooth
GPS	True
SIM Card Slot Count	Dual SIM
Audio Jack	3.5 mm
Battery Capacity	1000 Milliamp Hours
Product Dimensions	1.87 x 0.49 x 3.7 inches

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your purchase or contact the retailer/manufactureur directly. Keep your proof of purchase for warranty claims.

Manufacturer: Soyes

Brand: iPhanmis

© 2023 iPhanmis. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CPJ1NWQT>

More documents and user manuals: <https://manuals.plus/>