

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> **COMFIER** /

> **COMFIER Shiatsu Foot Massager Machine with Heat (Model CF-5003RC) - Instruction Manual**

## COMFIER CF-5003RC

# COMFIER Shiatsu Foot Massager Machine with Heat (Model CF-5003RC)

Instruction Manual

## 1. INTRODUCTION

Thank you for choosing the COMFIER Shiatsu Foot Massager Machine with Heat. This device is designed to provide a comprehensive foot massage experience, combining shiatsu kneading, air compression, vibration, and soothing heat to help alleviate foot fatigue and promote relaxation. Please read this manual thoroughly before use to ensure safe and effective operation.



*The COMFIER foot massager is designed for various users, including those with active lifestyles or those seeking relief from daily foot strain.*

## 2. IMPORTANT SAFETY INFORMATION

Please observe the following safety warnings to prevent injury or damage to the device:

- For personal use only.
- Do not use while bathing or near water.
- Unplug from outlet when not in use.

- Keep out of reach of children.
- Consult a physician before use if you have a medical condition.
- Do not use if the power cord is damaged.

### 3. PRODUCT FEATURES

- **Multifunctional Foot Massage:** Equipped with two independent rolling heads and multiple ergonomic massage nodes, combined with vibration and built-in air compression technology. Offers three intensity levels for kneading, air compression, and vibration.



*The massager provides deep kneading shiatsu and vibration massage with adjustable intensity levels.*

- **Soothing Heating Therapy:** Features a heating function with two levels (113°F - 131°F) that can be turned on or off independently. Provides warmth to help release fatigue and promote circulation.



*Experience soothing heat therapy with two adjustable levels for enhanced comfort.*

- **Air Compression Massage:** Built-in air compression technology works in conjunction with shiatsu massage to strengthen muscle tissues and reduce stiffness. Offers three adjustable intensity levels.


Gentle Warmth,  
Not Intense Heat

Feel Warmth in 3 Mins  
Reach 130°F for about 10 Mins

## 2-Level Heating Function



The soothing heat function can be controlled independently



*The air compression feature helps to relieve tight muscles and stress.*

- **Ergonomic Design:** Simulates the shape of human feet, providing a highly adaptable and comfortable massage experience. Fits up to US men's size 13.
- **Remote Control:** Includes a handy remote control for convenient adjustment of settings without bending down.



*The included remote control allows for easy adjustment of all massage functions.*

- **Detachable Washable Sleeves:** Foot sleeves are breathable and detachable for easy washing, ensuring hygiene.
- **Auto-timer & Over-heat Protection:** Features a 15-minute auto-off timer for safety and convenience. The device will activate after a 15-minute rest period by pressing the power button.

## 4. PACKAGE CONTENTS

Upon unpacking, please ensure all the following items are included:

- 1 x COMFIER Shiatsu Foot Massager Machine (Model CF-5003RC)
- 1 x Power Adapter
- 1 x Remote Control
- 1 x User Manual

## Better Foot Massager



- ✓ Remote Control
- ✓ up to men size 13
- ✓ 2-3 Min Heating Speed
- ✓ 131°F Heating Temperature



- ✗ No Remote Control
- ✗ up to men size 12
- ✗ 5-10 Mins Heating Speed
- ✗ 113°F Heating Temperature

Others



*The package includes the foot massager unit, power adapter, remote control, and user manual.*

### 5. SETUP

- Placement:** Place the foot massager on a flat, stable surface. It can be used on the floor, under a desk, or in front of a sofa.
- Connect Power:** Connect the adapter cable to the corresponding port on the massager device. Ensure the plug and interface are correctly aligned and the adapter is securely connected to a power outlet.
- Insert Feet:** Place your feet into the foot massager sleeves. Ensure they are comfortably positioned.

### 6. OPERATING INSTRUCTIONS

The massager can be operated using the control panel on the unit or the included remote control.

#### Control Panel / Remote Functions:

- **Power Button:** Press to turn the device on or off.
- **Knead (L/M/H):** Adjusts the intensity of the shiatsu kneading massage. Choose from Low, Medium, or High.
- **Air (L/M/H):** Adjusts the intensity of the air compression massage. Choose from Low, Medium, or High.
- **Vibration (L/M/H):** Adjusts the intensity of the vibration massage. Choose from Low, Medium, or High.
- **Heat (L/H):** Activates or adjusts the heating function. Choose from Low or High heat levels. This function can be turned on or off independently.
- **Pause Button (Remote Only):** Temporarily pauses the massage session. Press again to resume.



*The central control panel allows for easy selection and adjustment of all massage modes and intensities.*

### Usage Tips:

- Start with lower intensity settings and gradually increase as desired.
- The device has a 15-minute auto-off timer. To continue use after it turns off, press the power button after allowing the unit to rest for 15 minutes.

## 7. MAINTENANCE

- **Cleaning Foot Sleeves:** The internal foot sleeves are detachable and washable. Unzip the sleeves, remove them, and wash them according to the care instructions (typically machine washable). Ensure they are completely dry before reattaching.



*The foot sleeves can be easily removed and washed to maintain hygiene.*

- **Cleaning the Unit:** Wipe the exterior of the massager with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Storage:** Store the massager in a cool, dry place away from direct sunlight when not in use.

## 8. SPECIFICATIONS

Feature	Detail
Product Dimensions	13.58 x 7.36 x 15.94 inches
Item Model Number	CF-5003RC
Weight	6.72 Pounds
Power Source	Corded Electric
Material	Acrylic
Color	Black
Max Foot Size	US Men's Size 13

## 9. TROUBLESHOOTING

If you encounter any issues with your COMFIER Foot Massager, please refer to the following common solutions:

- **Device not turning on:** Ensure the power adapter is securely connected to both the massager and a working power outlet. Check if the outlet is functional.
- **Weak massage intensity:** Adjust the intensity settings (Knead, Air, Vibration) to a higher level using the control panel or remote. Ensure your feet are properly positioned within the sleeves.
- **No heat:** Verify that the Heat function is activated and set to the desired level (Low or High). Allow a few minutes for the heat to build up.
- **Unusual noises:** Discontinue use and check for any obstructions in the foot chambers. If the noise persists, contact customer support.

For further assistance, please contact COMFIER customer support.

## 10. WARRANTY AND SUPPORT

---

Your COMFIER Shiatsu Foot Massager Machine is covered by a manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions.

For product support, technical assistance, or warranty claims, please contact COMFIER customer service through the contact information provided in your user manual or on the official COMFIER website.