

## WZ140 Series Adapter

# Generic AC/DC Adapter User Manual

For Shark WZ140 Series Cordless Stick Vacuums

### Sections:

[Introduction](#) [Safety Information](#) [Setup](#) [Operation](#) [Maintenance](#) [Troubleshooting](#)  
[Specifications](#) [Warranty & Support](#)

## 1. INTRODUCTION

This manual provides essential instructions for the safe and effective use of your Generic AC/DC Adapter. This adapter is designed as a compatible replacement power supply for specific Shark WZ140 series cordless stick vacuums. It is not an original Shark product but is manufactured to be 100% compatible. Please read this manual thoroughly before using the adapter to ensure proper function and to prevent damage to the product or your device.



Image 1: The Generic AC/DC Adapter, showing the main unit with a standard US plug and the barrel connector cable.

## 2. SAFETY INFORMATION

Always follow basic safety precautions when using electrical products to reduce the risk of fire, electric shock, and injury.

- **Compatibility:** This adapter is specifically designed for Shark WZ140 V5, WZ140V5 26, WZ14026, WZ140PK, and WZ 140 models ONLY. Do not use it with any other devices, especially cellphones, as this may cause damage.
- **Power Source:** Ensure the power outlet voltage matches the adapter's input voltage range (100V-240V).
- **Protection Features:** The adapter includes Over Voltage Output Protection, Over Current Output Protection, and Short Circuit Output Protection to safeguard your device.
- **Environment:** Use the adapter in a dry environment. Avoid exposure to water, moisture, or extreme temperatures.

- **Ventilation:** Do not cover the adapter during use, as this can lead to overheating.
- **Damage:** Do not use the adapter if the cord or plug is damaged. Contact support for a replacement.
- **Children:** Keep the adapter out of reach of children.



Image 2: The adapter connected to a power strip, highlighting its premium quality components, stable output, and safety protections.

### 3. SETUP

1. **Verify Compatibility:** Before connecting, confirm that your Shark vacuum model is one of the compatible models: WZ140 V5, WZ140V5 26, WZ14026, WZ140PK, or WZ 140.
2. **Connect to Vacuum:** Insert the barrel connector end of the adapter cable firmly into the charging port of your Shark cordless stick vacuum.
3. **Connect to Power Outlet:** Plug the AC adapter into a standard wall outlet (100V-240V).
4. **Charging Indicator:** The adapter features an LED light to indicate power status. Refer to your vacuum's manual for its specific charging indicator behavior.




Image 3: This adapter features a 5-foot cable length and an integrated LED light to indicate power.

---

#### 4. OPERATION

Once connected, the adapter will begin charging your Shark vacuum's battery. The charging time will depend on the battery's current charge level and capacity. Always refer to your vacuum's user manual for specific charging instructions and battery care.

- **Charging:** Allow the vacuum to charge fully before its first use or after extended periods of non-use.
- **Unplugging:** When charging is complete, unplug the adapter from the wall outlet first, then disconnect it from the vacuum.
- **Storage:** Store the adapter in a cool, dry place when not in use.

---

## 5. MAINTENANCE

- **Cleaning:** Disconnect the adapter from the power source and the vacuum before cleaning. Wipe the adapter with a dry, soft cloth. Do not use liquid cleaners or solvents.
- **Cord Care:** Avoid bending, twisting, or crimping the power cord excessively. Do not place heavy objects on the cord.
- **Inspection:** Periodically inspect the adapter, cord, and connectors for any signs of damage, such as cuts, fraying, or loose connections. If damage is found, discontinue use and replace the adapter.

---

## 6. TROUBLESHOOTING

If you encounter issues with your adapter, please review the following common problems and solutions:

Problem	Possible Cause / Solution
Adapter not charging the vacuum.	<ul style="list-style-type: none"><li>◦ Ensure the adapter is fully plugged into both the wall outlet and the vacuum.</li><li>◦ Check if the wall outlet is functional by plugging in another device.</li><li>◦ Verify that your vacuum model is listed as compatible.</li><li>◦ <b>Battery Issue:</b> Rechargeable batteries have a limited lifespan (typically 1 to 3 years). If the vacuum's battery is old or dead, it may not accept a charge. This is a battery issue, not an adapter issue. You may need to test the battery or consult your vacuum's manufacturer for battery replacement.</li><li>◦ <b>Adapter Fault:</b> If the above steps do not resolve the issue, the adapter may be faulty.</li></ul>
Adapter feels hot during use.	<ul style="list-style-type: none"><li>◦ It is normal for adapters to become warm during operation.</li><li>◦ Ensure the adapter is in a well-ventilated area and not covered.</li><li>◦ If it becomes excessively hot to touch, disconnect it immediately and contact support.</li></ul>
LED light on adapter is off.	<ul style="list-style-type: none"><li>◦ Check power connections to the wall outlet and the adapter.</li><li>◦ Test the wall outlet with another device.</li><li>◦ The LED indicates power to the adapter. If it's off, the adapter may not be receiving power or could be faulty.</li></ul>

If you are unsure whether the battery or charger is at fault, a voltmeter can be used to test the charger's output voltage. If issues persist, please contact customer support.

---

## 7. SPECIFICATIONS

<b>Brand</b>	Generic
<b>Compatible Devices</b>	Shark WZ140 V5, WZ140V5 26, WZ14026, WZ140PK, WZ 140 (Fit these models ONLY)
<b>Input Voltage</b>	100V - 240V AC (Worldwide Compatible)
<b>Output Wattage</b>	140 Watts
<b>Output Current</b>	2 Amps
<b>Connector Type</b>	Barrel Connector
<b>Special Features</b>	Over Voltage Protection, Over Current Protection, Short Circuit Protection, LED Indicator
<b>Cable Length</b>	5 feet
<b>Color</b>	Black
<b>Product Dimensions</b>	Approximately 2 x 2 x 3 inches (adapter unit)
<b>Item Weight</b>	4 ounces
<b>Manufacturer</b>	GuyPower

## 8. WARRANTY & SUPPORT

This product is a replacement part and typically comes with a standard return policy. For specific warranty details and customer support, please refer to the seller's information on the platform where the product was purchased.

If you have questions regarding compatibility or require further assistance, please contact the seller directly through the Amazon messaging system.

**Return Policy:** The standard return policy allows for returns within 30 days for refund or replacement.