

Bellemave Daybed with Trundle and Bookcase Headboard

Bellemave Full Size Daybed with Trundle and Bookcase Headboard Instruction Manual

Model: Daybed with Trundle and Bookcase Headboard

1. PRODUCT OVERVIEW

The Bellemave Full Size Daybed with Trundle and Bookcase Headboard is designed to provide a versatile sleeping and storage solution. This bed frame features a full-size sleeping area, a pull-out twin-size trundle bed for additional guests, and an L-shaped bookcase headboard with integrated USB charging ports and an outlet plug.

Constructed from high-quality solid pine wood, MDF, and plywood, the frame ensures durability and stability. The design eliminates the need for a box spring, supporting mattresses directly on sturdy slats.

Key Features:

- **Full Size Daybed:** Provides a comfortable main sleeping area.
- **Twin Size Trundle:** A pull-out bed for accommodating guests or additional sleepers.
- **Bookcase Headboard:** L-shaped design with multiple shelves for storage and organization.
- **Integrated Charging Station:** Includes USB ports and an outlet plug for electronic devices.
- **Sturdy Construction:** Made from pine wood, MDF, and plywood with 10 bed slats for the main bed and 7 for the trundle.
- **No Box Spring Required:** Mattress support slats are included.

2. SAFETY INFORMATION

Please read and understand all safety warnings and instructions before assembly and use of this product. Failure to follow these instructions may result in serious injury.

- Always follow the assembly instructions provided with the product.
- Do not exceed the maximum weight capacity of **400 lbs** for the main daybed.
- Do not exceed the maximum weight capacity of **250 lbs** for the trundle bed.

- Keep the area around the bed clear of obstacles to prevent entrapment or injury.
- This product is not intended for use by children under 5 years old without adult supervision.
- Regularly check all bolts and fasteners to ensure they are tight. Retighten as necessary.
- Do not use replacement parts other than those authorized by the manufacturer.

3. ASSEMBLY AND SETUP

This daybed requires assembly. It is recommended that two adults assemble the product. The product will arrive in two separate boxes. Please ensure all parts are present before beginning assembly.

Required Tools (Not Included):

- Phillips head screwdriver
- Hammer (optional, for dowels)

Assembly Steps:

1. **Unpack and Identify Parts:** Carefully unpack all components from both boxes. Lay them out on a soft, clean surface to prevent scratches. Refer to the included parts list to identify each piece.
2. **Assemble the Main Bed Frame:** Follow the step-by-step instructions provided in the manufacturer's assembly manual. Pay close attention to the orientation of panels and the correct screws for each connection.
3. **Attach the Bookcase Headboard:** Secure the L-shaped bookcase headboard to the main bed frame as per the instructions. Ensure all connections are firm.
4. **Install Bed Slats:** Place and secure the wooden slats onto the bed frame. Ensure they are evenly spaced and firmly attached to provide adequate mattress support.
5. **Assemble the Trundle Bed:** Construct the trundle frame and install its slats.
6. **Insert Trundle:** Slide the assembled trundle bed into its designated position under the main daybed.
7. **Connect Charging Station:** Ensure the USB ports and outlet plug are properly connected and functional.
8. **Final Check:** Verify that all bolts and fasteners are securely tightened before placing mattresses on the bed.



Image: The daybed frame with the trundle extended, illustrating the slat system and the L-shaped bookcase headboard structure.



Image: The daybed frame with the trundle retracted, showing the compact configuration and the slat system.

4. OPERATING INSTRUCTIONS

Using the Trundle Bed:

- To extend the trundle, gently pull the front panel of the trundle bed outwards from under the main daybed. The trundle is equipped with wheels for easy movement.
- To retract the trundle, push it back into place under the main daybed until it is fully nested.
- Ensure the trundle is fully extended or fully retracted to prevent tripping hazards.

SIZE: INCH




Image: The Bellemave daybed with the twin trundle extended, ready for use, showcasing its dual sleeping functionality.



Image: The Bellemave daybed with the twin trundle retracted, demonstrating its space-saving design when not in use.

Using the Bookcase Headboard and Charging Station:

- The L-shaped bookcase headboard provides multiple shelves for storing books, decorative items, or personal belongings.
- The integrated USB ports and outlet plug are located within the headboard for convenient charging of electronic devices. Connect the bed's power cord to a standard wall outlet.
- Ensure devices are compatible with the charging station's output specifications.

5. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your Bellemave Daybed.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as these can damage the finish. For spills, blot immediately with a clean, dry cloth.
- **Dusting:** Regularly dust the bed frame and headboard shelves with a soft, dry cloth.
- **Hardware Check:** Periodically check all screws, bolts, and fasteners to ensure they are tight. Loose hardware can compromise the bed's stability and safety. Retighten as needed.
- **Avoid Excessive Moisture:** Protect the wood from prolonged exposure to moisture.
- **Weight Distribution:** Distribute weight evenly across the bed and trundle to prevent stress on the

slats and frame.

6. TROUBLESHOOTING

If you encounter issues with your daybed, refer to the following common solutions:

- **Bed feels wobbly or unstable:**
 - Ensure all assembly hardware (screws, bolts) is fully tightened.
 - Verify that all parts are correctly aligned according to the assembly instructions.
- **Trundle does not slide smoothly:**
 - Check for any obstructions under the main bed or in the trundle's path.
 - Ensure the trundle wheels are clean and free of debris.
 - Verify that the trundle frame was assembled correctly and is not warped.
- **Slats appear to be breaking or sagging:**
 - Ensure the mattress thickness is within the recommended 6 inches for both beds.
 - Verify that the weight on the bed does not exceed the specified weight capacities (400 lbs for main bed, 250 lbs for trundle).
 - Check if slats are properly secured to the frame.
- **USB ports or outlet not working:**
 - Ensure the bed's power cord is securely plugged into a functional wall outlet.
 - Check if the wall outlet itself is receiving power (test with another device).
 - Verify that the internal wiring for the charging station is properly connected during assembly.

If problems persist, please contact Bellemave customer support for assistance.

7. SPECIFICATIONS

Product Type	Daybed with Trundle
Color	Gray
Material	MDF, Plywood, Pine Wood
Size (Main Bed)	Full
Size (Trundle)	Twin
Overall Product Dimensions (L x W x H)	83.9" x 63.3" x 36.6"
Weight Capacity (Main Bed)	400 lbs
Weight Capacity (Trundle)	250 lbs
Number of Slats (Main Bed)	10
Number of Slats (Trundle)	7

Recommended Mattress Thickness	6" (for both beds)
Assembly Required	Yes



Image: Detailed dimensional drawing of the daybed and trundle, indicating all key measurements in inches.

8. WARRANTY AND SUPPORT

This Bellemave Daybed comes with a **Limited Warranty**. Specific terms and conditions of the warranty are typically included with your product packaging or can be obtained by contacting Bellemave customer service.

For any questions regarding assembly, missing parts, product defects, or warranty claims, please contact Bellemave customer support. Have your purchase receipt and product model information (B0CPJDK2XT) ready when contacting support.

You can often find contact information on the manufacturer's website or through the retailer where the product was purchased.

