

Manuals.plus /  
› WLIVE /  
› WLIVE 6-Drawer Dresser & TV Stand User Manual

WLIVE ASNG097DHS2

WLIVE 6-Drawer Dresser & TV Stand User Manual

Brand: WLIVE | Model: ASNG097DHS2

1. INTRODUCTION AND OVERVIEW

Thank you for choosing the WLIVE 6-Drawer Dresser & TV Stand. This versatile furniture piece is designed to provide ample storage and serve as a stable platform for your television. Its rustic brown finish and sturdy construction make it a functional and stylish addition to any bedroom, living room, closet, or hallway.

Key features include six spacious fabric drawers, a durable steel frame, a water-resistant wooden top, and adjustable feet for stability on uneven surfaces. For your safety, anti-tipping accessories are included to secure the unit to a wall.



Image 1: The WLIVE 6-Drawer Dresser in rustic brown, showcasing its design and potential use with decorative items.

## 2. SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.


- **Anti-Tipping Device:** It is crucial to install the included anti-tipping device to prevent the dresser from accidentally tipping over, especially in households with children or pets. Securely fasten the device to a wall stud.
- **Weight Capacity:** Do not exceed the maximum weight capacity for the top surface (100 lbs) or individual drawers (25 lbs). Overloading can compromise stability and cause damage.
- **Assembly:** Assemble the unit on a soft, clean surface to prevent scratches. Ensure all screws and fasteners are tightened securely before use.
- **Placement:** Place the dresser on a level surface. Use the adjustable feet to compensate for minor unevenness.
- **Children Safety:** Do not allow children to climb on or play with the dresser. Keep small parts and packaging materials away from children.

# STURDY STEEL FRAME

The height allow the sweeping robot work



Anti-Tilt Device



Prevent Incidents

Image 2: Illustration highlighting the sturdy steel frame, the importance of the anti-tilt device for safety, and the 4.7-inch clearance for robot vacuums.

## 3. PACKAGE CONTENTS

Before beginning assembly, please check that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

### Hardware and Tools:

- Screws (various sizes)
- Allen Wrench (if applicable)
- Anti-tipping strap and wall anchors
- Adjustable feet

## Components:

- Steel frame components (legs, crossbars)
- Wooden top board
- Fabric drawers (6 units)
- Drawer handles
- Side panels (if applicable)

## 4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly typically requires two people and takes approximately 1.5 hours. Follow the steps carefully to ensure proper construction and stability.

1. **Unpack and Identify:** Carefully unpack all components and hardware. Lay them out on a soft, clean surface to prevent scratches. Refer to the parts list to identify each piece.
2. **Assemble the Steel Frame:** Connect the steel frame components according to the provided diagrams. Ensure all connections are snug but do not fully tighten screws until the frame is complete.
3. **Attach the Wooden Top:** Secure the wooden top board to the assembled steel frame using the designated screws.
4. **Install Adjustable Feet:** Screw the adjustable feet into the bottom of the dresser legs. Once the dresser is in its final position, adjust the feet to ensure the unit is level and stable.
5. **Prepare Fabric Drawers:** Unfold each fabric drawer and insert the bottom panel to create a rigid structure.
6. **Attach Drawer Handles:** Secure the arch handles to the front of each fabric drawer.
7. **Install Anti-Tipping Device:** This is a critical safety step. Attach the anti-tipping strap to the back of the dresser and then securely fasten it to a wall stud using the provided wall anchors. This prevents accidental tipping.
8. **Insert Drawers:** Carefully slide the assembled fabric drawers into their respective compartments within the steel frame.
9. **Final Tightening:** Once the entire unit is assembled and in place, go back and fully tighten all screws and fasteners.



Image 3: Detailed view of the dresser's construction, illustrating the elegant metal handles, non-woven fabric, MDF board, quality fabric, and the 360-degree adjustable feet.

## 5. OPERATING INSTRUCTIONS (USAGE)

The WLIVE 6-Drawer Dresser is designed for multi-purpose use, offering both storage and a stable surface for your entertainment needs.

### Using the Drawers:

Each of the six fabric drawers provides ample space for organizing clothes, blankets, toys, socks, or other household items. The drawers are designed for easy pull-out and insertion. To maximize space, fold items neatly before placing them inside.

- Each drawer can hold approximately 20-24 T-shirts or 17-19 pairs of jeans.
- Maximum weight capacity per drawer is 25 lbs.



## EACH ONE CAN HOLD:



**20 - 24 T-shirts**



**17 - 19 Jeans**

Image 4: Visual representation of the storage capacity of one drawer, indicating it can hold 20-24 T-shirts or 17-19 pairs of jeans.

### Using as a TV Stand:

The sturdy wooden top surface is suitable for placing a television, making this dresser an ideal TV stand for your bedroom or living room. The top surface has a maximum weight capacity of 100 lbs.

- Supports TVs up to 70 inches in size.
- Ensure the TV base fits securely on the top surface and does not overhang excessively.



Image 5: The WLIVE dresser functioning as a TV stand, supporting a large television in a bedroom environment.

### Product Demonstration Video:

Watch this video for a comprehensive demonstration of the dresser's features and usage:

Your browser does not support the video tag.

Video 1: A demonstration of the WLIVE dresser, showcasing its drawers, storage capacity, wooden top, and suitability as a TV stand. This video also highlights the clearance for robot vacuums and the attractive wooden side board.

## 6. MAINTENANCE AND CARE

Proper care will help maintain the appearance and longevity of your WLIVE dresser.

- **Cleaning:** Wipe the wooden top and steel frame with a dry, soft cloth. For the fabric drawers, spot clean with a damp cloth and mild detergent if necessary, then air dry completely. Do not use harsh chemicals or abrasive

cleaners.

- **Regular Checks:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Avoid Moisture:** While the top is water-resistant, avoid prolonged exposure to liquids. Wipe up spills immediately.
- **Sunlight Exposure:** Avoid placing the dresser in direct sunlight for extended periods, as this may cause fading or damage to the materials.

## 7. TROUBLESHOOTING

If you encounter any issues with your dresser, please refer to the common problems and solutions below.

| Problem                                           | Possible Cause                                                                      | Solution                                                                                                                                                               |
|---------------------------------------------------|-------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Dresser is wobbly or unstable.                    | Uneven floor; loose screws; adjustable feet not properly set.                       | Adjust the leveling feet at the bottom of the dresser until it is stable. Check and tighten all assembly screws. Ensure the anti-tipping device is securely installed. |
| Drawers do not slide smoothly or fall out easily. | Drawer not fully assembled; bottom panel not inserted correctly; drawer overloaded. | Ensure the fabric drawers are fully unfolded and the bottom panel is firmly in place. Do not overload drawers beyond their 25 lbs capacity.                            |
| Missing parts or damaged components.              | Packaging error; shipping damage.                                                   | Do not proceed with assembly. Contact WLIVE customer support immediately for replacement parts.                                                                        |

## 8. SPECIFICATIONS

Detailed specifications for your WLIVE 6-Drawer Dresser & TV Stand.

| Feature                        | Detail                                         |
|--------------------------------|------------------------------------------------|
| Overall Dimensions (L x W x H) | 59.84" x 15.35" x 32.28" (152cm x 39cm x 82cm) |
| Item Weight                    | 29.5 lbs (13.38 kg)                            |
| Number of Drawers              | 6                                              |
| Drawer Material                | High-quality non-woven fabric                  |
| Frame Material                 | Sturdy steel                                   |
| Top Surface Material           | Water-resistant wooden board (MDF)             |
| Max Top Surface Capacity       | 100 lbs (45.36 kg)                             |

| Feature                    | Detail                                                     |
|----------------------------|------------------------------------------------------------|
| Max Drawer Capacity (each) | 25 lbs (11.34 kg)                                          |
| Compatible TV Size         | Up to 70 inches                                            |
| Special Features           | Adjustable feet, Anti-tipping device, Easy-to-pull handles |



Image 6: Comprehensive product size diagram, illustrating the overall dimensions and how various TV sizes (50", 60", 68") fit on the top surface.

## 9. WARRANTY AND SUPPORT

WLIVE is committed to providing high-quality products and excellent customer service. While specific warranty details are

not provided in this manual, if you have any problems, questions, or require assistance with your WLIVE 6-Drawer Dresser & TV Stand, please do not hesitate to contact our customer support team.

Please have your model number (ASNG097DHS2) and purchase information ready when contacting support to ensure a swift resolution.

You can typically find contact information on the WLIVE official website or through your original point of purchase.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

#### Name

Anonymous

#### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

#### Question

Example: How do I reset this device or fix this error?

#### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B0CPJGJ53H>

More documents and user manuals: <https://manuals.plus/>