



Manuals.plus /

- › aubor /
- › AUBOR J10 Wireless Video Doorbell Camera User Manual

aubor J10

AUBOR J10 Wireless Video Doorbell Camera User Manual

Model: J10

1. INTRODUCTION

Thank you for choosing the AUBOR J10 Wireless Video Doorbell Camera. This manual provides essential information for setting up, operating, and maintaining your device. The J10 doorbell offers advanced features such as 1080P HD video, night vision, two-way audio with voice modification, AI motion detection, and seamless integration with your smart home system.



Image 1.1: The AUBOR J10 Video Doorbell allows you to see, hear, and speak to visitors from anywhere.

2. PACKAGE CONTENTS

Please ensure all items are present in the package:

- AUBOR J10 Video Doorbell Camera
- Wireless Chime
- 3 AAA Batteries (for Chime)
- Screws & Installation Tool Kit
- Mounting Stickers
- Type-C Charging Cable
- User Manual (this document)

3. SETUP GUIDE

3.1 Charging the Doorbell

Before installation, fully charge the doorbell camera using the provided Type-C charging cable. The LED indicator will show charging status.

3.2 Installing the Chime

Insert the 3 AAA batteries into the wireless chime. Plug the chime into a standard power outlet in your desired location within your home. Ensure it is within range of the doorbell.

3.3 Mounting the Doorbell

The AUBOR J10 features a simple wire-free setup. Choose an ideal mounting location at your front door. The adjustable stand allows for angles of -45° , -22.5° , 0° , 22.5° , or 45° to optimize your viewing area. Use the provided screws and tools or mounting stickers for installation.



See, Hear and speak to visitor from anywhere

Image 3.1: The doorbell offers multi-angle adjustment for optimal viewing. Note: Supports 2.4GHz Wi-Fi only.

3.4 App Connection (CloudEdge App)

1. Download the **CloudEdge App** from Google Play Store or Apple App Store.
2. Register for an account and log in.
3. Follow the in-app instructions to add your AUBOR J10 doorbell. Ensure your smartphone is connected to a **2.4GHz Wi-Fi network** during setup. The doorbell does not support 5GHz Wi-Fi.
4. Pair the doorbell with the wireless chime through the app settings.

4. OPERATING INSTRUCTIONS

4.1 Live View and Recording

Access the **CloudEdge App** to view live 1080P HD video from your doorbell camera at any time. The 166° wide-angle lens provides a broad view of your doorstep. You can manually record video or capture screenshots directly from the live view.

4.2 Night Vision

The doorbell automatically activates its built-in IR lights to provide clear black-and-white night vision in low-light conditions or complete darkness, ensuring continuous security.

Easy to Install, Multi-angle Adjustment



Image 4.1: The doorbell provides clear visibility both day and night.

4.3 Two-Way Talk and Voice Modification

When a visitor presses the doorbell or motion is detected, you will receive an alert on your phone. Open the app to engage in real-time two-way audio communication. The voice-changing feature allows you to alter your voice for added privacy and security.



See who's there, even in the dark

Image 4.2: Utilize two-way audio and voice modification features via the app.

4.4 Smart Motion Detection and Alerts

The integrated PIR sensor detects motion and sends instant notifications to your phone. Customize motion detection sensitivity (five levels) and define specific motion zones within the **CloudEdge App** to reduce false alerts.



Motion Detection, APP Alerts

Image 4.3: Receive instant alerts on your phone when motion is detected.

4.5 Cloud Storage

The AUBOR J10 offers cloud storage for your video footage without monthly fees. Access recorded events securely through the **CloudEdge App**.

4.6 Smart Home Integration

The AUBOR J10 is compatible with Amazon Alexa and Google Assistant. Link your doorbell to these platforms through their respective apps to enable voice commands and view live feeds on compatible smart displays.

Alexa, talk to the front door



Work with Alexa and Google Home

Image 4.4: Integrate your doorbell with Amazon Alexa and Google Home for convenient control.

5. MAINTENANCE

5.1 Battery Management

The doorbell camera is powered by a rechargeable Lithium Ion battery. When the battery level is low, you will receive a notification via the **CloudEdge App**. Recharge the doorbell using the provided Type-C cable. The wireless chime uses 3 AAA batteries, which should be replaced when depleted.

5.2 Cleaning

To maintain optimal performance, periodically clean the camera lens and the doorbell's exterior with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials. The doorbell is waterproof, suitable for outdoor use.

6. TROUBLESHOOTING

- **Doorbell not connecting to Wi-Fi:** Ensure your Wi-Fi network is 2.4GHz. The doorbell does not support 5GHz networks. Check your Wi-Fi password and signal strength.
- **No motion detection alerts:** Verify that motion detection is enabled in the **CloudEdge App**. Adjust sensitivity levels and ensure motion zones are correctly configured. Check battery level.
- **Poor video quality:** Ensure the doorbell has a strong Wi-Fi signal. Move your Wi-Fi router closer or consider a Wi-Fi extender if necessary. Clean the camera lens.
- **Chime not ringing:** Check if the chime batteries are installed correctly and are not depleted. Ensure the chime is plugged into a power outlet and is paired with the doorbell via the app.
- **Two-way audio issues:** Check your phone's microphone and speaker permissions for the **CloudEdge App**. Ensure a stable internet connection for both your phone and the doorbell.

7. SPECIFICATIONS

Feature	Detail
Model Name	J10
Color	White
Video Resolution	1080p HD
Viewing Angle	166 Degrees
Connectivity	2.4GHz Wi-Fi (Does not support 5GHz)
Power Source	Battery Powered (Lithium Ion)
Special Features	Waterproof, Night Vision, Two-Way Audio, Voice Changer, AI Motion Detection, Works with Alexa
Dimensions (L x W x H)	14.48 x 5.59 x 5.59 cm (5.7 x 2.2 x 2.2 inches)
Installation Type	Wall-Mounted

8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official AUBOR website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

