

## IMGadgets KRK1

# IMGadgets Karaoke Microphone KRK1 Instruction Manual

## INTRODUCTION

---

This manual provides comprehensive instructions for the IMGadgets Karaoke Microphone, model KRK1. This versatile 5-in-1 device functions as a handheld cordless microphone, a portable speaker, a music player, a karaoke machine, and a voice recorder. It features colorful LED lights and is designed for ease of use across various age groups and settings.

## PRODUCT FEATURES

---

- **Clear Sound Quality:** Equipped with high-quality inner-magnet loudspeakers for clear and loud audio output.
- **Funny Sound Changes:** Offers 4 distinct voice modes to enhance entertainment during singing sessions.
- **Easy to Use & Multiple Connections:** Features multi-function buttons for adjusting music, echo, and volume. Supports both wired and cordless connections to smartphones, TVs, laptops, or tablets. Includes an SD card slot for music playback (SD card not included).
- **5-in-1 Multifunctional Device:** Combines the functions of a cordless microphone, cordless speaker, music player (with headphone connectivity), cordless karaoke machine, and voice recorder.
- **Long-Lasting Battery:** Integrated 1200 mAh battery provides approximately 4-6 hours of continuous music listening or singing.
- **Dynamic LED Lights:** Built-in LED lights flash in rhythm with the music, adding a visual element to performances.



Image: The IMGadgets Karaoke Microphone, highlighting its key features such as Micro SD support, 10W speaker, echo function, Bluetooth 5.0, and voice changer capabilities.

## SETUP

---

1. **Charging the Microphone:** Connect the provided USB Type-C cable to the charging port at the bottom of the microphone and to a compatible USB power source. The power indicator light will show charging status.
2. **Power On/Off:** Press and hold the power button ( ) for a few seconds to turn the microphone on or off. The LED lights will illuminate upon power-on.
3. **Bluetooth Pairing:** Once powered on, the microphone will enter Bluetooth pairing mode. On your device (smartphone, tablet, etc.), search for "IMGadgets KRK1" in the Bluetooth settings and connect. A confirmation sound will indicate successful pairing.
4. **SD Card Insertion:** For music playback directly from an SD card, insert a formatted Micro SD card into the designated slot at the bottom of the microphone.

Your browser does not support the video tag.

Video: Demonstration of powering on the IMGadgets Karaoke Microphone, showing the LED lights activating and the sound output. This video also highlights the various ports at the base of the microphone.

### Button Functions:

- **'+' Button:** Single click to increase microphone volume. Double click to increase echo effect. Long press to play the next song.
- **'-' Button:** Single click to decrease microphone volume. Double click to decrease echo effect. Long press to play the previous song.
- **Power Button ( ):**  Short press to play/pause music. Double click for duet mode (if supported). Long press to power on/off.
- **Microphone Button ( ):**  Activates voice changer effects (4 effects + no effect).
- **'M' Button:** Short press to switch between Bluetooth and TF (SD card) modes. Long press to toggle LED light effects.

### Voice Changer:

Press the microphone button ( ) repeatedly to cycle through the 4 available voice changing effects and the normal voice mode. Experiment to find your preferred effect.

### Recording Function:

When connected to a smartphone via Bluetooth, you can use a compatible karaoke app to record your singing. The microphone acts as both input and output for this function.



Image: A group of people enjoying singing with the IMGadgets Karaoke Microphone, illustrating its voice recorder capability.



Image: A diagram illustrating the control panel buttons and their functions on the IMGadgets Karaoke Microphone.

## MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the microphone. Do not use harsh chemicals

or abrasive materials.

- **Storage:** Store the microphone in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the microphone regularly, even if not in use for extended periods.

## TROUBLESHOOTING

---

- **No Sound Output:** Ensure the microphone is powered on and fully charged. Check the volume levels on both the microphone and the connected device. Verify Bluetooth connection is active.
- **Cannot Connect via Bluetooth:** Make sure the microphone is in pairing mode. Turn off and on Bluetooth on your device, then try searching again. Ensure no other devices are currently connected to the microphone.
- **LED Lights Not Working:** Check if the LED lights have been turned off using the 'M' button's long press function. Ensure the microphone has sufficient battery.
- **Poor Sound Quality:** Ensure the microphone is not too close to the speaker, which can cause feedback. Adjust echo and volume settings.

## SPECIFICATIONS

---

Feature	Detail
Product Dimensions	7 x 7 x 21 cm
Item Weight	0.32 Kilograms (320 g)
Model Number	KRK1
Brand	IMGadgets
Connectivity Technology	Auxiliary, USB (Bluetooth 5.0)
Connector Type	USB Type-C
Special Features	1-Touch Recording, Voice Changer, Volume Control, Dynamic LED Lights
Compatible Devices	Smartphone, Tablet, Television, Laptop, PC
Power Source	Battery Powered (1200 mAh)
Frequency Range	80Hz - 15KHz
Included Components	Microphone

## WARRANTY AND SUPPORT

---

The IMGadgets Karaoke Microphone KRK1 comes with a 90-day warranty. For technical support, warranty claims, or any inquiries, please contact IMGadgets customer service:

- **Phone:** +1 647-797-3804

- **Email:** [customercare@imgadgets.com](mailto:customercare@imgadgets.com)