

[Manuals.plus](#) /

> [Blooy](#) /

> Blooy FM-11510 Adjustable Fabric Guide Presser Foot User Manual

Blooy FM-11510

Blooy FM-11510 Adjustable Fabric Guide Presser Foot

User Instruction Manual

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Blooy FM-11510 Adjustable Fabric Guide Presser Foot. Please read this manual thoroughly before use to ensure proper function and longevity of the product. This presser foot is designed to enhance precision and control when sewing, particularly with industrial coverstitch machines.

2. PRODUCT OVERVIEW

The Blooy FM-11510 is an adjustable fabric guide presser foot engineered for industrial coverstitch sewing machines. It features a robust metal construction with an integrated fabric guide that can be adjusted to maintain consistent seam allowances. The standard needle distance for this model is 5.6mm.



Figure 1: Front view of the Blooy FM-11510 Adjustable Fabric Guide Presser Foot. This image displays the overall design, including the main foot, the adjustable guide mechanism, and the attachment point for the sewing machine.

3. COMPATIBILITY

The Blooy FM-11510 Adjustable Fabric Guide Presser Foot is compatible with a wide range of industrial coverstitch sewing machines, including but not limited to:

- **Siruba:** F007, C007
- **Pegasus:** W500, W600
- **Yamato:** VC2600, VC2700, VG2700
- **JACK:** K4, W4, JK-8569, JK-8669

Please verify your machine's model number and presser foot attachment type to ensure proper fit before installation.

4. SETUP AND INSTALLATION

Follow these general steps to install the adjustable fabric guide presser foot onto your industrial sewing machine:

1. **Power Off:** Ensure your sewing machine is turned off and unplugged from the power source for safety.
2. **Remove Existing Foot:** Raise the presser foot lever. Loosen the screw that holds the current presser foot in place and carefully remove it.
3. **Attach New Foot:** Align the Blooy FM-11510 presser foot with the presser foot bar. Ensure the attachment point is correctly seated.
4. **Secure Foot:** Tighten the screw firmly to secure the new presser foot. Do not overtighten.
5. **Check Alignment:** Lower the presser foot and manually turn the machine's handwheel to ensure the needle passes cleanly through the foot's opening without striking any part of the foot.



Figure 2: Angled view of the presser foot, highlighting the screws used for attaching the foot and adjusting the fabric guide. Proper tightening of these screws is crucial for stable operation.



Figure 3: Top-down perspective of the presser foot, clearly showing the adjustable guide bar and its mechanism. This view is helpful for understanding how the guide can be positioned.

5. OPERATING INSTRUCTIONS

The primary function of this presser foot is to provide an adjustable guide for maintaining consistent seam allowances. Follow these steps for operation:

1. **Adjust Fabric Guide:** Loosen the small screw(s) on the adjustable guide mechanism. Slide the guide to the desired distance from the needle, corresponding to your required seam allowance.
2. **Secure Guide:** Once the guide is in position, tighten the screw(s) to lock it in place.
3. **Position Fabric:** Place your fabric under the presser foot, ensuring the edge of the fabric rests against the adjustable guide.

4. **Begin Sewing:** Start sewing, keeping the fabric edge gently pressed against the guide. This will help maintain a straight and consistent seam.

The foot is designed for a 5.6mm needle distance, which is important for coverstitch applications. Always perform a test stitch on scrap fabric to confirm settings before sewing on your main project.



Figure 4: Underside view of the presser foot, clearly indicating the 5.6mm needle distance marking. This specification is critical for compatibility and proper stitch formation in coverstitch applications.



Figure 5: Side profile of the presser foot, illustrating the full range of motion and construction of the adjustable fabric guide. This view helps in understanding the guide's functionality.

6. MAINTENANCE

To ensure optimal performance and extend the lifespan of your Blooy FM-11510 presser foot, follow these maintenance guidelines:

- **Cleaning:** Regularly wipe the presser foot with a soft, dry cloth to remove lint, dust, and fabric fibers. For stubborn residue, a slightly damp cloth can be used, followed by immediate drying.
- **Inspection:** Periodically inspect the foot for any signs of wear, damage, or loose screws. Ensure all components are securely fastened.
- **Storage:** When not in use, store the presser foot in a clean, dry place to prevent corrosion or damage.

7. TROUBLESHOOTING

If you encounter issues while using the Blooy FM-11510 presser foot, consider the following common solutions:

• **Fabric Not Feeding Straight:**

- Ensure the adjustable fabric guide is securely tightened at the desired seam allowance.
- Verify that the fabric is consistently held against the guide during sewing.
- Check for any obstructions under the presser foot or in the feed dog area.

• **Presser Foot Feels Loose:**

- Re-tighten the screw that attaches the presser foot to the presser foot bar.
- Ensure the foot is correctly seated on the bar.

• **Needle Striking Foot:**

- Immediately stop sewing.
- Check if the presser foot is installed correctly and aligned with the needle plate opening.
- Ensure the needle is the correct type and size for your machine and fabric.

If problems persist, consult your sewing machine's main instruction manual or contact a qualified technician.

8. SPECIFICATIONS

Feature	Detail
Model Number	FM-11510
Part Number	FM-11510
Needle Distance	5.6mm
Material	Metal
Item Weight	1.76 ounces (approximately 50 grams)
Package Dimensions	5 x 4 x 2 inches
Manufacturer	Blooy

9. WARRANTY AND SUPPORT

For specific warranty information or technical support regarding your Blooy FM-11510 Adjustable Fabric Guide Presser Foot, please refer to the product packaging or contact the retailer or manufacturer directly. Keep your purchase receipt as proof of purchase.

© 2023 Blooy. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CPKYFKMV>

More documents and user manuals: **<https://manuals.plus/>**