

## Playtive 359778P

# Playtive Wooden Railway Set Instruction Manual

Model: 359778P

## 1. INTRODUCTION

Thank you for choosing the Playtive Wooden Railway Set. This manual provides essential information for the safe assembly, operation, and maintenance of your new railway set. Designed to foster creativity, imagination, and fine motor skills, this set offers hours of engaging play. Please read these instructions carefully before use and retain them for future reference.

This product is available in two main variants:

- **Firefighter Railway Set:** Featuring a detailed fire station and a self-propelled fire truck.
- **Passenger Railway Set:** Including various stations, a level crossing, and a self-propelled passenger train.

## 2. SAFETY INFORMATION

**WARNING: CHOKING HAZARD - Small parts. Not suitable for children under 36 months (3 years).**

- **Recommended Age:** This product is suitable for children aged 3 years and older.
- **Small Parts:** The set contains small components that could be swallowed or inhaled, posing a choking hazard for young children. Adult supervision is required.
- **Battery Safety:** For sets with self-propelled trains, ensure batteries are inserted correctly with the correct polarity (+/-). Do not mix old and new batteries, or different types of batteries. Non-rechargeable batteries are not to be recharged. Rechargeable batteries are only to be charged under adult supervision. Exhausted batteries are to be removed from the toy.
- **Material:** The tracks are made from genuine European beech wood. Ensure no splinters or sharp edges are present before play.

## 3. PACKAGE CONTENTS

Please check that all components are present and undamaged. The exact contents vary depending on the set variant:

### 3.1 Firefighter Railway Set (65 Pieces)

- Wooden track pieces (approx. 3.8 m total length)
- Detailed firefighter headquarters building
- Battery-operated self-propelled fire truck (forward and reverse function)
- Trolley
- Helicopter
- 2 figures
- Various accessories

### 3.2 Passenger Railway Set (56 Pieces)

- Wooden track pieces (approx. 4.2 m total length)
- 3 detailed stations
- Level crossing
- Bridge elements
- Stop sign
- Battery-operated self-propelled passenger train (forward and reverse function)
- Freight train for pushing and loading
- Taxi
- 4 figures
- Various accessories



*Image 1: A generic representation of Playtive Wooden Railway Set components, including wooden tracks, trains, and various accessories. This image serves as a general visual reference for the type of items included in the set.*

## 4. SETUP INSTRUCTIONS

---

Follow these steps to assemble your Playtive Wooden Railway Set:

1. **Unpack Components:** Carefully remove all pieces from the packaging. Dispose of packaging materials responsibly.
2. **Plan Your Layout:** Arrange the wooden track pieces on a flat, stable surface. The tracks are designed for creative and varied construction.
3. **Connect Tracks:** Join the track pieces together using the interlocking connectors. Ensure a snug fit for smooth train movement.
4. **Assemble Accessories:** Place buildings, bridges, level crossings, and other accessories in your desired locations along the track.
5. **Install Batteries (for self-propelled trains):** Locate the battery compartment on the underside of the self-propelled train(s) or fire truck. Open the compartment, insert the required batteries (typically AA or AAA, not included) according to the polarity markings, and close the compartment securely.
6. **Place Vehicles:** Position the trains, vehicles, and figures on the tracks and within the play area. All vehicles and trains feature magnetic couplings for easy connection.

The Playtive Wooden Railway Set is compatible with other Playtive vehicle kits and commercially available wooden tracks and road kits, allowing for expanded play possibilities.

## 5. OPERATING INSTRUCTIONS

---

Once assembled, your railway set is ready for play:

- **Self-Propelled Trains/Vehicles:** For battery-operated trains and the fire truck, locate the ON/OFF switch (usually on the top or side). Switch it to 'ON' to activate the forward movement. Some models may have a reverse function.
- **Magnetic Couplings:** Connect train cars and vehicles using the integrated magnetic couplings. Simply bring the ends together, and the magnets will attach.
- **Interactive Play:** Use the included figures and accessories to create various scenarios and stories. Encourage imaginative play around the fire station, passenger stations, and other elements.
- **Manual Movement:** Non-motorized trains and vehicles can be pushed along the tracks manually.

## 6. MAINTENANCE

---

Proper care will ensure the longevity of your Playtive Wooden Railway Set:

- **Cleaning:** Wipe all wooden and plastic components with a slightly damp cloth. Do not immerse in water. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store the set in a dry place, away from direct sunlight and extreme temperatures, to prevent warping or damage to the wood.
- **Battery Replacement:** When the self-propelled trains or vehicles slow down or stop, it's time to replace the batteries. Follow the battery installation instructions in Section 4.3.
- **Inspection:** Periodically inspect all parts for wear and tear, loose connections, or damage. Discontinue use if any part is broken or damaged.

## 7. TROUBLESHOOTING

---

If you encounter any issues with your railway set, refer to the following common problems and solutions:

- **Train/Vehicle Not Moving:**
  - Check if the ON/OFF switch is in the 'ON' position.
  - Verify that batteries are correctly inserted with the correct polarity.
  - Replace old or depleted batteries with new ones.
  - Ensure the wheels are clean and free from obstructions.
- **Trains Derailing:**
  - Ensure all track pieces are securely connected and lie flat on the surface.
  - Check for any foreign objects on the tracks.
  - Verify that the train wheels are properly seated on the tracks.
- **Parts Not Fitting Together:**
  - Ensure you are using the correct pieces for the intended connection.
  - Do not force pieces together; they should fit smoothly.

If problems persist, please contact Playtive customer support.

## 8. SPECIFICATIONS



Feature	Detail
Model Number	359778P
Material	European Beech Wood
Recommended Age	3 years and up
Product Dimensions (L x W x H)	Approximately 30 x 20 x 10 cm (packaging)
Scale	1:87 Scale
Firefighter Set Track Length	Approx. 3.8 meters
Firefighter Set Pieces	65 pieces
Passenger Set Track Length	Approx. 4.2 meters
Passenger Set Pieces	56 pieces




9. WARRANTY AND SUPPORT

Specific warranty information for the Playtive Wooden Railway Set is not provided in the product details. For any questions regarding warranty, product support, or spare parts availability, please contact Playtive customer service directly through their official channels or the retailer where the product was purchased.

© 2023 Playtive. All rights reserved.

Related Documents - 359778P

	<p><a href="#">Playtive Passenger Train Set - Instructions for Use</a></p> <p>Comprehensive user manual and safety guide for the Playtive Passenger Train Set, covering assembly, operation, safety precautions, and disposal. Includes multilingual instructions.</p>
	<p><a href="#">Playtive Jungle Train Set: Assembly and Operation Manual</a></p> <p>Comprehensive instructions for assembling, using, and maintaining the Playtive Jungle Train Set. Includes safety guidelines, technical specifications, and warranty information.</p>

 <p>MEINE ERSTE BAHN / MONTESORI SET / UNDERWATER SET MY FIRST TRAIN SET MONTESORI SET / UNDERWATER SET MON PREMIER TRAIN SET MONTESORI / SET SOUS-MARIN</p> <p>IAN 460793_2401</p>	<p><a href="#">Playtive My First Train Set Montessori / Underwater Set - Instructions and Safety Information</a></p> <p>Comprehensive guide for the Playtive My First Train Set Montessori and Underwater Set, including delivery contents, intended use, safety instructions, storage, cleaning, disposal, and warranty information. Features multilingual support.</p>
 <p>FARM / DINOSAUR WOODEN TRAIN SET</p> <p>IAN 460730_2401</p>	<p><a href="#">Playtive Farm / Dinosaur Wooden Train Set - Instructions &amp; Safety Guide</a></p> <p>Comprehensive instructions and safety information for the Playtive Farm / Dinosaur Wooden Train Set (IAN 460730_2401), including delivery contents, intended use, care, and guarantee details.</p>
 <p>SIGNAL BUILDING</p> <p>IAN 460505_2401</p>	<p><a href="#">Playtive Signal Building Toy - Instructions and Safety Information</a></p> <p>Official instructions and safety guidelines for the Playtive Signal Building toy set. Learn how to use, store, and dispose of the product safely. Includes warranty information.</p>
 <p>EISENBAHN-SET DINOLAND RAILWAY SET DINOSAUR LAND SET CHEMIN DE FER DINOLAND</p> <p>IAN 460731_2401</p>	<p><a href="#">Playtive Eisenbahn-Set Dinoland: Anleitung &amp; Informationen</a></p> <p>Umfassende Anleitung und Informationen zum Playtive Eisenbahn-Set Dinoland. Entdecken Sie Aufbau, Verwendung und Sicherheitshinweise für dieses Dinosaurier-Themen-Spielzeug von Delta-Sport Handelskontor GmbH.</p>