

## IMGadgets Desk300

# IMGadgets Electric Standing Desk (Model Desk300) - User Manual

47x24 Inch Height Adjustable Ergonomic Sit-Stand Desk

## 1. INTRODUCTION

---

Thank you for choosing the IMGadgets Electric Standing Desk, Model Desk300. This manual provides essential information for the safe and efficient use of your new height-adjustable desk. Please read these instructions carefully before assembly and operation, and retain them for future reference.

This electric standing desk is designed to offer a versatile workspace, allowing seamless transitions between sitting and standing positions. It features a robust motor, memory height presets, and a spacious 47x24 inch tabletop, promoting an ergonomic and productive environment.

## 2. SAFETY INFORMATION

---

### Important Safety Precautions:

- Do not load the desk with more than 70 kilograms (154 lbs). Exceeding this weight limit can cause damage to the desk and potential injury.
- Ensure all cables are properly managed and secured to prevent tripping hazards or entanglement during height adjustments.
- Keep children and pets away from the desk during operation to prevent accidents.
- Avoid placing liquids directly on the control panel or near electrical components.
- Regularly check all screws and connections to ensure they are tight and secure.
- Operate the desk only on a level surface.
- This product is intended for indoor use only.

## 3. PACKAGE CONTENTS

---

Please verify that all components are present before beginning assembly. Refer to the included assembly guide for a detailed list of parts.

- Desk tabletop (47x24 inches, typically in two pieces)

- Electric lifting columns (legs)
- Control panel with LED display and memory buttons
- Motor and power adapter
- Frame components (crossbar, feet)
- Headphone holders (2 units)
- Assembly hardware (screws, tools)
- User manual and assembly guide

## 4. SETUP AND ASSEMBLY

---

Detailed assembly instructions are provided in the separate assembly guide included with your product. Please follow these instructions carefully, ensuring all parts are correctly installed and tightened. Assembly typically involves:

1. Attaching the lifting columns to the desk feet.
2. Connecting the crossbar between the lifting columns.
3. Securing the tabletop to the assembled frame. Note that the tabletop is typically supplied in two pieces.
4. Mounting the control panel and headphone holders.
5. Connecting the motor and power cables.

It is recommended to have two people for assembly due to the size and weight of the components.

## 5. OPERATING INSTRUCTIONS


---

### 5.1 Basic Height Adjustment



The desk's height can be adjusted electrically from 28.3 inches (71cm) to 46.5 inches (118cm). Use the **Up** (▲) and **Down** (▼) buttons on the control panel to raise or lower the desk to your desired height. The current height is displayed on the LED screen.

### 5.2 Memory Presets



The control panel features three memory buttons (1, 2, 3) to save and recall your preferred sitting and standing heights.

- **To Save a Height:** Adjust the desk to your desired height. Press the **M** button, then immediately press one of the number buttons (1, 2, or 3) until you hear a beep or see the display flash. The height is now saved.
- **To Recall a Height:** Simply press the corresponding number button (1, 2, or 3). The desk will automatically move to the saved position.

### 5.3 Child Safety Lock

To prevent accidental adjustments, especially by children, the control panel includes a child safety lock feature.

- **To Enable/Disable Child Lock:** Press and hold the **Up (▲)** and **Down (▼)** buttons simultaneously for 5 seconds. The display will indicate when the lock is activated or deactivated.

## 6. FEATURES OVERVIEW



### Ergonomic Sit-Stand Design

Seamlessly switch between sitting and standing positions to optimize your posture and reduce physical strain throughout your workday. The desk's electric height adjustment allows for a smooth transition.




## Spacious and Sturdy Tabletop

The 47x24 inch tabletop provides ample space for multiple monitors, a laptop, and other office essentials, helping you maintain an organized and efficient workspace. The laminated wood pattern offers a sleek, scratch-resistant finish.



## High Weight Capacity and Stability

Constructed with a sturdy steel frame, the desk supports up to 70 kg (154 lbs) and maintains stability even at its highest point. Leveling feet ensure balance on uneven floors.



## Quiet and Smooth Operation

Equipped with a 6th generation quiet motor, the desk adjusts height with a motion noise of less than 55 dB, ensuring a peaceful work environment. Soft start/stop functions provide seamless movement.



### Integrated Headphone Holders

Two smart holders are included, allowing you to conveniently hang headphones, bags, or other accessories, keeping your desk surface clear and organized.



### Certified High-Quality Materials

The desk is made from CARB, UL1310, TSCA, and EPA Certified Premium Engineered Wood, ensuring it is free from harmful chemicals and meets strict environmental standards for a safer, healthier workspace.

## 7. MAINTENANCE

---

To ensure the longevity and optimal performance of your IMGadgets Electric Standing Desk, follow these maintenance guidelines:

- **Cleaning:** Wipe the desk surface and frame with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners that could damage the finish.
- **Cable Management:** Periodically check and reorganize cables to prevent tangles and ensure smooth operation during height adjustments.
- **Fasteners:** Every few months, inspect all screws and bolts to ensure they are securely tightened. Retighten if necessary.
- **Weight Limit:** Always adhere to the maximum weight capacity of 70 kg (154 lbs) to prevent damage to the motor and frame.

## 8. TROUBLESHOOTING

---

If you encounter any issues with your IMGadgets Electric Standing Desk, refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Desk does not move	Power cable disconnected; Child lock activated; Overload protection triggered	Check power connection; Deactivate child lock (hold Up/Down for 5s); Reduce load on desk and wait 20 minutes before trying again.
Uneven height adjustment	Obstruction; Unbalanced load	Remove any obstructions; Redistribute weight evenly on the desk surface.
Noise during operation	Normal motor sound; Loose fasteners	A low hum is normal (under 55 dB). If excessive, check all assembly fasteners for tightness.
Memory presets not working	Incorrect saving procedure	Ensure you press 'M' then the number button immediately after adjusting to the desired height.

If the problem persists after attempting these solutions, please contact IMGadgets customer support.

## 9. SPECIFICATIONS

Feature	Detail
Brand	IMGadgets
Model Number	Desk300
Colour	Electric - Ivory
Product Dimensions	60D x 120W x 118H Centimetres (47" x 24" tabletop)
Adjustable Height Range	28.3" (71cm) to 46.5" (118cm)
Material	CARB, UL1310, TSCA and EPA Certified Premium Engineered Wood, Metal Base
Max Weight Capacity	70 kg (154 lbs)
Motor Type	6th Gen Quiet Motor
Noise Level	Less than 55 dB
Special Features	Adjustable Height, Electric, Ergonomic, Height Memory Buttons, LED Display, 2 Headphone Holders
Item Weight	18.5 kg

## 10. WARRANTY AND SUPPORT

---

IMGadgets is committed to providing high-quality products and customer satisfaction. For warranty information, technical support, or any inquiries regarding your Electric Standing Desk, please contact us directly:

- **Phone:** +1 647-797-3804
- **Email:** [customercare@imgadgets.com](mailto:customercare@imgadgets.com)
- **Chat:** Visit [www.imgadgets.com](http://www.imgadgets.com)

Please have your model number (Desk300) and purchase information ready when contacting support.