

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Brother](#) /
- › [Brother HL-L2460DW Laser Printer Instruction Manual](#)

## Brother HLL2460DW

# Brother HL-L2460DW Wireless Compact Monochrome Laser Printer

Model: HLL2460DW | Brand: Brother

## INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Brother HL-L2460DW Wireless Compact Monochrome Laser Printer. Designed for home offices and small teams, this printer offers efficient, high-quality black and white printing with versatile connectivity options.



Image: Front view of the Brother HL-L2460DW printer, showcasing its compact design and a document being printed.

## WHAT'S IN THE BOX

Upon unboxing your Brother HL-L2460DW printer, verify that all the following components are included:

- AC Power Cord
- Drum Unit (DR830)
- Toner Cartridge (TN830, 700 pages yield)
- Quick Setup Guide
- Product Safety Guide
- Reference Guide
- Warranty Card



*Image: All components included in the Brother HL-L2460DW printer package, laid out for inspection.*

## SETUP

### 1. Initial Printer Setup

1. Remove all packing materials and protective tapes from the printer.
2. Install the included Drum Unit and Toner Cartridge. Refer to the Quick Setup Guide for detailed visual instructions.
3. Connect the AC Power Cord to the printer and then to a power outlet.
4. Turn on the printer using the power button.

## 2. Connectivity Setup

Your HL-L2460DW printer offers multiple connection options:

- **Dual-band Wireless (2.4GHz/5GHz):** For convenient printing from anywhere within your network.
- **Ethernet:** For a stable wired network connection.
- **USB 2.0:** For direct connection to a single computer.

For the easiest setup, especially for wireless connectivity, download and use the **Brother Mobile Connect App** on your smartphone or tablet. The app guides you through the network setup process and allows for mobile printing.

# HL-L2460DW

# Easy Connect

## Steady, On-Demand Connection Options

Ethernet

Dual Band Wireless<sup>‡</sup>

Wi-Fi Direct<sup>®</sup>

AirPrint<sup>®</sup>

Mopria<sup>™</sup>

Brother Mobile  
Connect App<sup>‡</sup>

USB 2.0



<sup>‡</sup>Scroll down to learn more

*Image: Visual representation of the diverse connectivity options available for the HL-L2460DW printer.*

## OPERATING INSTRUCTIONS

### Loading Paper

The printer features a 250-sheet capacity paper tray and a manual feed slot for specialty paper and envelopes.

1. Open the paper tray and adjust the paper guides to fit your paper size (up to 8.5 x 14 inches).
2. Load paper into the tray, ensuring it is flat and not exceeding the maximum fill line.
3. For the manual feed slot, insert one sheet at a time.

### Printing Documents

Once connected, you can print from your computer or mobile device. The printer supports speeds up to 36 pages per minute (ppm) for black and white output.

- **Automatic Duplex Printing:** To save paper, enable automatic double-sided printing through your printer's settings on your computer or the mobile app.
- **Mobile Printing:** Use the Brother Mobile Connect App to print documents and photos directly from your smartphone or tablet.

# HL-L2460DW

# In The Box



## Wireless Monochrome (Black & White) Laser Printer

Quick Setup Guide  
Product Safety Guide  
Reference Guide  
Warranty Card



Black Toner Cartridge  
(700 pages)<sup>†</sup>



Drum Unit



<sup>†</sup>Scroll down to learn more


Image: The Brother HL-L2460DW printer in an office setting, demonstrating its use for business documents.

# HL-L2460DW

# Mobile Connect

## Use the Brother Mobile Connect App<sup>†</sup> to:

- Manage printer from phone
- Print from almost anywhere
- Monitor toner levels and order more



<sup>†</sup>Scroll down to learn more

*Image: The Brother Mobile Connect App interface, highlighting its features for remote printer management and mobile printing.*

## MAINTENANCE

### Toner and Drum Unit Replacement

For optimal performance, use Brother Genuine Supplies. The printer uses separate toner cartridges and drum units.

- **Toner Cartridges:** TN830 (Standard Yield), TN830XL (High Yield), TN830XL 2PK (Twin-Pack).
- **Drum Unit:** DR830.

The Brother Mobile Connect App can help you monitor toner usage and order replacements.

# HL-L2460DW

brother  
**genuine**  
INK & TONER

## The only toner made exclusively *by Brother for Brother*

Reliable compatibility & superior performance.



*Image: The Brother HL-L2460DW printer alongside Brother Genuine Toner, illustrating the importance of using authentic supplies.*

### Toner Save Mode

To extend the life of your toner cartridge, enable Toner Save Mode through your printer settings. This reduces toner consumption for less critical documents.

### TROUBLESHOOTING

If you encounter issues with your printer, consider the following common solutions:

- **Connectivity Issues:**

- Ensure the printer is powered on and connected to your network (Wi-Fi or Ethernet).
- Verify your device (computer, phone) is on the same network as the printer.
- Restart your printer, router, and device.
- Check the printer's LCD display for error messages.

- **Paper Jams:**

- Follow the instructions on the printer's LCD display or in the Reference Guide to clear any jammed

paper.

- Ensure paper is loaded correctly and not creased or damaged.

- **Print Quality Issues:**

- Check toner and drum unit levels. Replace if low.
- Clean the drum unit and toner cartridge if smudges or streaks appear.
- Ensure you are using appropriate paper for your print job.

For more detailed troubleshooting, refer to the comprehensive Reference Guide or contact Brother support.

## SPECIFICATIONS

Feature	Detail
Printer Type	Monochrome Laser
Print Speed (Black & White)	Up to 36 ppm
Print Resolution	Up to 1200 x 1200 dpi
Duplex Printing	Automatic (2-sided)
Paper Capacity (Input)	250 sheets (standard tray)
Maximum Media Size	8.5 x 14 inches (Legal)
Connectivity	Ethernet, USB 2.0, Wi-Fi (Dual-band 2.4GHz/5GHz)
Compatible Cartridges	Brother Genuine TN830, TN830XL, TN830XL2PK (Toner); DR830 (Drum)
Product Dimensions (W x D x H)	14.2" x 14" x 7.2"
Item Weight	15.6 pounds
Energy Efficiency	ENERGY STAR® compliant, EPEAT® Silver rated

## WARRANTY AND SUPPORT

Your Brother HL-L2460DW printer is backed by a **1-year limited warranty**.

For any questions, technical assistance, or support, Brother offers free online, call, or live chat support for the life of your printer. Visit the official Brother support website for contact information and resources.

For information on the Refresh EZ Print Subscription Service, please refer to the documentation provided with your printer or the Brother website.