



Manuals.plus /

› ZURU SMASHERS /

› Smashers Dino Island Gold Treasure Hunt (Orange) User Manual

ZURU SMASHERS 74123

Smashers Dino Island Gold Treasure Hunt (Orange) User Manual

Model: 74123 | Brand: ZURU SMASHERS

INTRODUCTION

The Smashers Dino Island Gold Treasure Hunt is an interactive toy designed for ages 3 and up, offering over 70 surprises. This manual provides comprehensive instructions for the setup, operation, and care of your new toy, ensuring a fun and engaging experience.

SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small pieces. Not for children under 3 years.

WHAT'S IN THE BOX

Your Smashers Dino Island Gold Treasure Hunt includes a variety of components for an exciting adventure:

- 1 x Large Golden Pirate Skull (main container)
- Over 70 surprises, including:
 - Smashers Dino Island figures (various dinosaurs, sharks, and pirate characters)
 - Gold slime and kinetic sand for sensory play
 - Multiple treasure chests, gold coins, and colorful gems
 - Interactive elements such as a light-up eye and projectile launchers



Figure 1: Complete contents of the Smashers Dino Island Gold Treasure Hunt set.

SETUP AND DISCOVERY

Begin your treasure hunt by interacting with the main golden skull and uncovering its hidden contents.

1. **Activate the Skull:** Locate the 'Try Me!' button on the skull's eye. Press it to activate the skull's light and sound features.
2. **Open the Skull:** Carefully separate the two halves of the skull to reveal the individually packaged surprises inside.
3. **Unpack Surprises:** Unpack each surprise package. Some packages may require adult assistance with scissors to open. You will find various elements such as kinetic sand, gold slime, and different toy components.



Figure 2: The large golden skull, the primary container for all surprises.

ASSEMBLING YOUR FIGURES

Your set includes parts to assemble a large dinosaur and a shark figure, enhancing your play experience.

Dinosaur Assembly

Locate all the dinosaur body parts, including the main body, golden armor pieces, and the projectile launcher. Snap these pieces together firmly to form the complete dinosaur figure.



Figure 3: Assembled orange dinosaur with golden armor.

Shark Assembly

Find the blue shark body parts and its corresponding golden armor. Connect these pieces to assemble the complete shark figure.



Figure 4: Assembled blue shark with golden armor.

INTERACTIVE PLAY FEATURES

Engage with the various interactive elements of your Smashers Dino Island set.

Skull Eye Interaction

The removable eye from the golden skull can be placed into the mouth of the large dinosaur figure. Press the eye to hear the dinosaur roar and watch the eye glow with different colors, adding an exciting auditory and visual element to playtime.

Projectile Launchers

Both the assembled dinosaur and shark figures are equipped with projectile launchers. Load the small projectiles into the designated slots and press the activation point to launch them, simulating battles and adventures.

Treasure Hunt Play

Utilize the kinetic sand and gold slime to create your own treasure hunt scenarios. Bury the included gold coins, gems, and small pirate figures for endless discovery and imaginative play.



Figure 5: Children engaging in interactive play with the set's components.

MAINTENANCE

Proper care will extend the life and enjoyment of your toy.

- **Slime and Sand Storage:** To prevent the kinetic sand and gold slime from drying out, always store them in their original resealable bags or in airtight containers immediately after play.
- **Cleaning Figures:** Wipe down plastic figures with a damp cloth as needed. Avoid using harsh chemicals.
- **Electronic Components:** Do not submerge the electronic skull eye in water. Clean with a dry cloth only.

TROUBLESHOOTING

If you encounter any issues with your Smashers Dino Island set, refer to the following common solutions:

Parts Not Fitting During Assembly

Ensure you are using the correct pieces for each figure as indicated in the included instruction sheet. Apply gentle, even pressure when snapping components together. Do not force parts, as this may cause damage.

Electronic Eye Not Working

Check if the batteries are correctly installed in the skull eye. If the issue persists, the batteries may need to be replaced. Refer to the battery compartment for the specific battery type required.

Slime or Sand Consistency Issues

If the slime or kinetic sand becomes too dry, ensure it has been stored in an airtight container. A very small amount of water can sometimes help restore the slime's consistency, but this should be done cautiously and is not guaranteed to fully restore the product.

PRODUCT SPECIFICATIONS

Product Dimensions	8.84 x 9.92 x 12.43 inches
Item Weight	3.49 pounds
Country of Origin	China
ASIN	B0CPL7B3BB
Item Model Number	74123
Manufacturer Recommended Age	3 years and up
Release Date	July 1, 2024
Manufacturer	ZURU

WARRANTY AND SUPPORT

For detailed warranty information or product support, please refer to the contact details provided on the original product packaging. You may also visit the official ZURU SMASHERS website for additional resources and assistance.