

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [VssoplOr](#) /

› [VssoplOr Multi-Device Wireless Keyboard and Mouse Combo User Manual](#)

VssoplOr B0CPLCP7L1

VssoplOr Multi-Device Wireless Keyboard and Mouse Combo User Manual

Model: B0CPLCP7L1

1. PRODUCT OVERVIEW

The VssoplOr Multi-Device Wireless Keyboard and Mouse Combo offers versatile connectivity and a sleek design for enhanced productivity across multiple devices. This combo features dual Bluetooth 4.0 modes and a 2.4G USB mode, allowing simultaneous connection to up to three devices with seamless switching.

Key features include low-profile scissor-switch keys for a quiet and responsive typing experience, an ultra-slim profile, and a rechargeable lithium battery for both the keyboard and mouse. The mouse offers adjustable DPI settings for precise control.



Image 1.1: The VessoPlor Multi-Device Wireless Keyboard and Mouse Combo, featuring a rose gold full-size keyboard and a matching wireless mouse.

ULTRA SLIM DESIGN



Image 1.2: Close-up view highlighting the ultra-slim design of both the keyboard (0.16 inch) and the mouse (1 inch height).

2. SETUP AND CONNECTION

2.1 Charging the Devices

Both the keyboard and mouse are equipped with built-in 280mAh rechargeable lithium batteries. Before first use, or when the battery indicator is low, charge the devices using the supplied USB cable.

- Connect the Micro USB end of the cable to the charging port on the keyboard/mouse.
- Connect the USB-A end to a USB power source (e.g., computer USB port, USB wall adapter).
- An indicator light will show charging status and turn off when fully charged.




Image 2.1: Illustration showing the Micro USB charging ports on both the keyboard and mouse, indicating their rechargeable battery feature.

2.2 Connecting via 2.4G USB Mode

This mode uses a USB dongle for wireless connection.

1. Locate the 2.4G USB receiver, typically stored in the mouse's battery compartment.
2. Plug the USB receiver into an available USB port on your computer or device.
3. Turn on the keyboard and mouse. They should automatically connect to the receiver.

2.3 Connecting via Bluetooth Mode (BT1 / BT2)

The combo supports two independent Bluetooth connections, allowing you to switch between devices.

1. **For Keyboard:** Turn on the keyboard. Press and hold the **Fn + BT1** or **Fn + BT2** key combination for 3-5 seconds until the indicator light flashes, indicating pairing mode.
2. **For Mouse:** Turn on the mouse. Press the Bluetooth pairing button (usually on the bottom of the mouse) until the indicator light flashes.
3. On your device (computer, tablet, smartphone), go to Bluetooth settings.
4. Search for new devices. Select "VssoPlor Keyboard" and "VssoPlor Mouse" from the list.
5. Follow any on-screen prompts to complete the pairing process.

MULTI-DEVICE WORKFLOW



Image 2.2: A setup demonstrating the multi-device workflow, showing the keyboard and mouse connected to a desktop monitor, a tablet, and a laptop, with icons for Bluetooth 1, Bluetooth 2, and 2.4G connectivity.

3. OPERATING INSTRUCTIONS

3.1 Switching Between Devices

To switch between connected devices:


- **For Keyboard:** Press **Fn + BT1**, **Fn + BT2**, or **Fn + 2.4G** (for USB mode) to switch to the desired connected device.
- **For Mouse:** Press the dedicated switch button on the bottom of the mouse to cycle through the 2.4G, BT1, and BT2 modes.

3.2 Keyboard Functions

The keyboard features a full-size layout with a numeric keypad and convenient multimedia keys.

- **Multimedia Keys:** Use the **Fn** key in combination with the F1-F12 keys to access multimedia functions (e.g., volume control, play/pause, previous/next track). Refer to the keycap legends for specific functions.
- **Scissor-Switch Keys:** The low-profile scissor-switch mechanism provides a quiet and comfortable typing experience with good tactile feedback.

SCISSOR-SWITCH KEYS



Offer a better tactile response and a quieter typing experience

Image 3.1: A detailed view of a keyboard key, showing the internal scissor-switch mechanism designed for a better tactile response and quieter typing.

3.3 Mouse Functions

The wireless mouse offers adjustable sensitivity and a quiet clicking experience.

- **Adjustable DPI:** Press the DPI button on top of the mouse to cycle through 1000, 1600, and 2400 DPI settings, allowing you to adjust cursor speed and precision.

- **Noiseless Click:** The mouse is designed for quiet operation, reducing click noise.




Image 3.2: Visual representation of the mouse's adjustable DPI settings (1000, 1600, 2400) and its noiseless click feature.

3.4 Power Saving Mode

To conserve battery life, both the keyboard and mouse will automatically enter sleep mode after 10 minutes of inactivity. To wake them up, simply press any key on the keyboard or move/click the mouse.

4. MAINTENANCE

Proper care will extend the life of your keyboard and mouse combo.

- **Cleaning:** Use a soft, dry cloth to wipe down the surfaces of the keyboard and mouse. For stubborn dirt, a slightly damp cloth with mild soap can be used, ensuring no liquid enters the device. Avoid abrasive cleaners.
- **Battery Care:** Recharge the devices regularly, even if not fully depleted, to maintain battery health. Avoid extreme temperatures.
- **Storage:** When not in use for extended periods, turn off the devices to save battery. Store them in a cool, dry place.
- **Keyboard Cover:** The product may include a thin silicon keyboard cover. This can be used to protect the keys from dust, spills, and pet hair. Clean the cover separately with water and mild soap.

5. TROUBLESHOOTING

If you encounter issues with your Vssoplur Keyboard and Mouse Combo, please refer to the following common solutions:

- **No Connection/Lag:**
 - Ensure both devices are fully charged.
 - Verify the correct connection mode (2.4G, BT1, BT2) is selected on both the keyboard and mouse, matching your device's connection.
 - For 2.4G mode, try plugging the USB receiver into a different USB port.
 - For Bluetooth mode, try unpairing and re-pairing the devices in your system's Bluetooth settings.
 - Ensure the devices are within the effective operating range (typically 10 meters) and there are no significant obstructions or strong interference sources.
- **Keyboard Not Typing/Mouse Not Moving:**
 - Check if the devices have entered sleep mode; press any key or move the mouse to wake them up.
 - Confirm the power switch on both devices is in the 'ON' position.
- **Mouse Scroll Wheel Issues:**
 - Ensure no debris is obstructing the scroll wheel.
 - If the issue persists, try restarting the mouse or reconnecting it.

If these steps do not resolve the issue, please contact customer support for further assistance.

6. SPECIFICATIONS

Feature	Detail
Brand	Vssoplur
Model	B0CPLCP7L1
Color	Rose Gold
Connectivity Technology	Bluetooth 4.0 (BT1, BT2), 2.4G USB
Special Features	Full Size, Multi-Device, Ultra Slim, Rechargeable, Scissor-Switch Keys, Noiseless Click Mouse

Compatible Devices	Windows 8/10 or above, Mac OS X 10.10 or above, Android 4.3 or above (Laptops, Desktops, Tablets)
Keyboard Battery	280mAh Rechargeable Lithium Battery
Mouse Battery	280mAh Rechargeable Lithium Battery
Mouse DPI Settings	1000, 1600, 2400
Item Weight	1.63 pounds (approx.)
Package Dimensions	17.44 x 5.28 x 1.69 inches (approx.)

7. WARRANTY AND SUPPORT

VssoPlor products are designed for reliability and performance. This product is covered by a standard manufacturer's warranty against defects in materials and workmanship. Please refer to the product packaging or the seller's information for specific warranty terms and duration.

For technical support, troubleshooting assistance, or warranty claims, please contact the seller or VssoPlor customer service through the platform where the product was purchased. Provide your product model number (B0CPLCP7L1) and a detailed description of the issue to expedite support.