

[Manuals.plus](#) /

› [Lamshaw](#) /

› Lamshaw 20mm Quick Release Silicone Smart Watch Band User Manual for IOWODO R30 Pro, R50, Blackview R50, RLQA 54 Smart Watches

Lamshaw 20mm Quick Release Silicone Smart Watch Band

Lamshaw 20mm Quick Release Silicone Smart Watch Band User Manual

For IOWODO R30 Pro, R50, Blackview R50, and RLQA 54 Smart Watches

1. PRODUCT OVERVIEW

The Lamshaw 20mm Quick Release Silicone Smart Watch Band is designed for comfort and durability, offering a secure and stylish replacement for your compatible smartwatch. Made from high-quality silicone, these bands are skin-friendly, sweat-proof, and easy to install.



Image 1.1: A set of three Lamshaw 20mm quick release silicone watch bands in white, pink, and green colors.

Key Features:

- **Premium Silicone Material:** Skin-friendly, durable, lightweight, and sweat-proof for comfortable wear.
- **Quick Release Design:** Allows for easy installation and removal without the need for tools.
- **Secure Buckle:** Features a reliable tang buckle and metal snap fastener for a secure fit.
- **Compatibility:** Specifically designed for 20mm lug width smartwatches.

2. COMPATIBILITY

These 20mm quick release silicone watch bands are compatible with the following smartwatch models:

- IOWODO R30 Pro Smart Watch
- IOWODO R50 Smart Watch
- Blackview R50 Smart Watch
- RLQA 54 1.83" Smart Watch

Important: Ensure your smartwatch has a 20mm lug width for proper fit. Please measure your watch's lug width before installation.



Image 2.1: Visual representation of compatible smartwatch models.

3. PACKAGE CONTENTS

Your package typically includes:

- 3 x Lamshaw 20mm Quick Release Silicone Smart Watch Bands (in selected colors, e.g., White, Pink, Green)

4. INSTALLATION GUIDE

Follow these steps to install or replace your watch band:

1. **Prepare Your Watch:** Place your smartwatch face down on a soft, clean surface to prevent scratches.
2. **Remove Existing Band (if applicable):** Locate the quick release pin on the underside of your current watch band. Slide the pin inwards to detach the band from the watch lug. Repeat for the other side.
3. **Attach New Band:** Take one half of the Lamshaw quick release band. Insert one end of the spring bar into the lug hole on one side of your watch.
4. **Engage Quick Release Pin:** While holding the first end in place, slide the quick release pin inwards. Align the other end of the spring bar with the opposite lug hole.
5. **Secure the Band:** Release the quick release pin, ensuring both ends of the spring bar are securely seated within the watch lugs. Gently tug on the band to confirm it is firmly attached.
6. **Repeat for Second Half:** Follow the same steps to attach the second half of the watch band.



Image 4.1: Exploded view illustrating the quick release mechanism and components for easy installation.



Secure Double Buckle



Metal Snap Fastener



Soft & Breathable

Image 4.2: Detail of the secure buckle and breathable design, highlighting ease of use.

5. USAGE AND COMFORT

Once installed, adjust the band to a comfortable fit on your wrist using the tang buckle. The silicone material is designed to be soft, lightweight, and breathable, making it suitable for daily wear, exercise, and various activities.



Image 5.1: Example of the pink band being worn, showcasing its comfortable fit.



Image 5.2: Example of the white band being worn, showcasing its comfortable fit.



Image 5.3: Example of the teal band being worn during physical activity, highlighting its suitability for sports.

6. MAINTENANCE AND CARE

To ensure the longevity and hygiene of your silicone watch band, follow these care instructions:

- **Cleaning:** Wipe the band regularly with a soft, damp cloth. For deeper cleaning, use mild soap and water, then rinse thoroughly and dry completely before reattaching to your watch.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or strong detergents, as these can damage the silicone material.
- **Storage:** When not in use, store the band in a clean, dry place away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

- **Band does not fit:** Ensure your smartwatch has a 20mm lug width. These bands are specifically designed for 20mm lugs. If your watch has a different lug width, the band will not fit correctly.
- **Difficulty installing:** Make sure the quick release pin is fully retracted when inserting the band. Wiggle the band gently to help the pin snap into place. Verify that both ends of the spring bar are seated in the lug holes.

- **Skin irritation:** While the silicone is skin-friendly, ensure the band is not worn too tightly. Clean the band regularly to prevent buildup of sweat or debris that could cause irritation. If irritation persists, discontinue use and consult a healthcare professional.

8. SPECIFICATIONS

Material	Silicone
Band Width	20mm
Clasp Type	Tang Buckle
Compatibility	IOWODO R30 Pro, R50; Blackview R50; RLQA 54 1.83" Smart Watches

9. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Lamshaw watch band, please refer to the seller's contact information on the platform where you purchased the product. Specific warranty details may vary by retailer.

© 2023 Lamshaw. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

