Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VECELO KHD-OC15-BRN

VECELO Home Office Desk Chair User Manual

Model: KHD-OC15-BRN

Introduction

This manual provides essential instructions for the assembly, operation, maintenance, and troubleshooting of your VECELO Home Office Desk Chair, Model KHD-OC15-BRN. Please read this manual thoroughly before assembly and use to ensure proper function and safety.





Image: Front view of the VECELO Home Office Desk Chair, showcasing its brown PU leather upholstery, ergonomic design, and adjustable features.

Safety Information

- Avoid allowing children to climb on the desk chair without supervision.
- Ensure the chair is always placed on even and stable surfaces to prevent tipping.
- Regularly inspect all screws and fasteners to ensure they are tight. Loose screws can compromise stability and safety.
- Clean the chair with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the material.
- If any issues arise with the product, discontinue use and contact customer service immediately.

Package Contents

Before beginning assembly, verify that all components listed below are present in your package:

- 1 x VECELO Home Office Desk Chair
- 1 x Accessory Kit (containing all necessary hardware)
- 1 x Installation Instructions (this manual)

Assembly Instructions

Follow these steps carefully to assemble your VECELO Home Office Desk Chair. It is recommended to assemble the chair on a soft, clean surface to prevent scratches.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out. Check against the package contents

list.

2. **Attach Casters to Base:** Insert the five nylon casters into the holes at the end of each leg of the chair base. Push firmly until they click into place.
3. **Insert Gas Lift:** Place the gas lift cylinder into the center hole of the chair base.
4. **Assemble Footrest:** Slide the footrest ring over the gas lift cylinder. Secure it at your desired height using the adjustment knob on the footrest.
5. **Attach Seat Plate:** Secure the seat plate to the underside of the seat cushion using the provided screws. Ensure the front of the seat plate faces the front of the seat.
6. **Connect Seat to Gas Lift:** Carefully place the assembled seat onto the gas lift cylinder, ensuring it is centered and securely seated.
7. **Final Check:** Once assembled, sit on the chair to engage the gas lift and ensure all connections are secure.



Image: Illustration of the heavy-duty chair base with five durable nylon casters, highlighting its stability and mobility. Max load capacity up to 330 lbs.




Image: Detailed view of premium components including the high-quality air gas lift for height adjustment, the solid and stable base with an adjustable footrest, and 360° silent casters designed to protect floors.

Operating Instructions

Your VECELO Home Office Desk Chair is designed for ease of use and comfort. Familiarize yourself with its adjustable features:

- **Height Adjustment:** To adjust the seat height, pull the lever located under the seat upwards. While pulling the lever, stand up to raise the seat or remain seated to lower it. Release the lever at your desired height. The seat height can be adjusted from 32.28 inches to 40.16 inches.
- **Footrest Adjustment:** The footrest ring can be adjusted vertically along the gas lift. Loosen the knob on the footrest, slide it to the desired height, and then tighten the knob securely.
- **360° Swivel:** The chair seat can rotate 360 degrees, allowing for flexible movement and access to different areas of your workspace without needing to reposition the entire chair.
- **Mobility:** The five smooth-rolling casters allow for effortless movement across various floor surfaces.



Image: Close-up view of the chair's height adjustment lever and the footrest adjustment knob, illustrating how to raise/lower the seat and tighten/loosen the footrest.



Image: Diagram showing the chair's ability to slide under a desk, illustrating its compact design and ease of integration into various workspaces.

Maintenance

Proper maintenance will extend the life and appearance of your VECELO chair:

- **Cleaning:** For general cleaning, wipe the PU leather surface with a soft, slightly damp cloth. For stubborn stains, use a mild soap solution and immediately wipe dry. Avoid harsh detergents, solvents, or abrasive cleaners.
- **Hardware Check:** Periodically check all screws and bolts to ensure they are tight. Re-tighten if necessary to maintain stability and prevent wobbling.
- **Caster Care:** Keep the casters free of hair, dust, and debris to ensure smooth rolling. You may occasionally need to clean the caster wheels.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the PU leather to fade or crack. Position the chair away from direct sunlight when possible.

Troubleshooting

If you encounter any issues with your chair, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Chair wobbles or feels unstable.	Loose screws or uneven surface.	Ensure all assembly screws are tightened. Move the chair to a flat, even surface.
Seat height adjustment not working.	Gas lift not properly engaged or damaged.	Ensure the lever is fully pulled. If the issue persists, the gas lift may need replacement. Contact customer service.

Problem	Possible Cause	Solution
Casters not rolling smoothly.	Debris caught in casters or damaged casters.	Clean any hair or debris from the caster wheels. If damaged, casters may need replacement.
Footrest slides down.	Footrest adjustment knob is loose.	Tighten the footrest adjustment knob firmly.

Specifications

Brand:	VECELO
Model Name:	VECELO Home Office Desk Chair with Height Adjustable Seat and Footrest
Item Model Number:	KHD-OC15-BRN
Color:	Brown
Material:	PU Leather, Metal (Base)
Fill Material:	Foam
Overall Dimensions (L x W x H):	22.83"L x 22.83"W x 32.28-40.16"H (from product description) *Note: Please refer to the dimension image for detailed measurements as there is a slight discrepancy in listed dimensions.*
Seat Height Adjustment Range:	32.28" - 40.16"
Maximum Weight Capacity:	330 Pounds
Item Weight:	18.12 pounds
Special Features:	Adjustable Height, Arm Rest, Ergonomic, Foot Rest, Upholstered Leather, 360° Swivel, Rolling Casters
UPC:	840408902762



Image: Detailed diagram illustrating the product dimensions, including overall height (32.28-40.16 inches), seat width (19.88 inches), seat depth (16.34 inches), and maximum weight capacity (330 lbs).

Warranty and Customer Support

VECELO is committed to providing high-quality products and excellent customer service.

- **Free Replacement Service:** VECELO offers a free replacement service for any defective or damaged parts.
- **24-Hour Customer Service:** For any product-related issues, questions, or concerns, please contact our customer service team.
- **Contact Information:** You can reach us via email at support@vecelo.com.

Please have your model number (KHD-OC15-BRN) and purchase information ready when contacting support to expedite assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CPLRBLP1

More documents and user manuals: **https://manuals.plus/**