

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [HOSPAN](#) /

› [HOSPAN FS02A Foot Spa Instruction Manual](#)

HOSPAN FS02A

HOSPAN Collapsible Foot Spa Instruction Manual

Model: FS02A

INTRODUCTION

Thank you for choosing the HOSPAN Collapsible Foot Spa. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your new foot spa. Designed for stress relief and relaxation, this foot bath features electric rotary massage, heat, bubble function, and convenient remote control. Please read this manual thoroughly before first use and keep it for future reference.

SAFETY INFORMATION

Your safety is paramount. Please adhere to the following safety guidelines:

- Do not fill the foot spa with hot water above 113°F (45°C) directly. Use lukewarm water and allow the unit to heat it to your desired temperature.
- Always remove the remote control before pouring out the water to prevent damage.
- Ensure the unit is placed on a stable, level surface during use.
- Do not stand in the foot spa. Use it only while seated.
- Keep the power cord away from heated surfaces.
- Do not operate if the unit or cord is damaged. Contact customer support for assistance.
- Keep out of reach of children.
- Unplug the unit from the power outlet when not in use and before cleaning.

SETUP

Follow these steps to set up your HOSPAN Foot Spa:

1. **Unpack the Unit:** Carefully remove the foot spa from its packaging.
2. **Expand the Spa:** The foot spa is designed to be collapsible for easy storage. To expand, rotate the support rod to the supporting position and gently pull up the sides until fully extended.
3. **Position the Unit:** Place the foot spa on a flat, stable surface near a power outlet.
4. **Fill with Water:** Fill the foot spa with warm water (around 95°F / 35°C). Do not exceed the maximum fill line. Do not fill with water above 113°F (45°C) directly.
5. **Connect Power:** Plug the power cord into a suitable electrical outlet.



Figure 1: Fully expanded HOSPAN Foot Spa ready for use.

IT IS COLLAPSIBLE!



Figure 2: The foot spa in its compact, folded state, demonstrating its space-saving design.

OPERATING INSTRUCTIONS

Your foot spa is equipped with several features for a personalized experience. The magnetic remote control can be detached for convenience.

Control Panel & Remote

The control panel is located on the top of the unit and also serves as the remote control. Ensure the infrared transmitter on the remote is aimed at the display screen within 1 meter and at a 90-degree angle to the red light for optimal function.

HANDY REMOTE CONTROL

No need to bend over to operate



Figure 3: Operating the foot spa using the handy remote control.

Power On/Off

Press the **ON/OFF** button on the control panel or remote to turn the unit on or off. The LED display will illuminate.

Intelligent Temperature Control

The foot spa features intelligent temperature control, maintaining water temperature between 95°F (35°C) and 118°F (48°C). Use the **TEMP+** and **TEMP-** buttons to adjust the desired temperature. The LED screen displays the real-time water temperature.

95°F ~ 118°F TEMPERATURE CONTROL

Automatically maintain the setting temperature



Figure 4: Visual representation of the foot spa's temperature control range.

Automatic Rotary Massage

The foot spa is equipped with 6 groups of 3D Tai Chi massage balls that automatically massage the acupuncture points on the soles of your feet. Press the **MASSAGE 3 MODES** button to cycle through three massage modes: continuous, intermittent, or intelligent.

MASSAGE FROM TOE TO HEEL

24 massage balls are as smooth as pebbles



Automatic
Massage



3 Modes
Conversion



Tai Chi
Massage

Figure 5: Close-up view of the 24 motorized shiatsu massage balls.

Bubble & Red Light Function

Activate the oxygen bubbles and red light therapy by pressing the **RED LIGHT BUBBLE** button. The bubbles provide a soft, hot spring-like massage, while the red light enhances relaxation.

LED TEMPERATURE DISPLAY & BUBBLE

Smarter and meet your multiple needs



Figure 6: The LED display showing temperature and the active bubble function.

Timer Settings

Set a timer for your foot spa session using the **TIMING** button. You can choose intervals of 10, 20, 30, 40, 50, or 60 minutes. The unit will automatically turn off once the timer expires.

Official Product Video

Watch this official video from HOSPAN for a detailed introduction to the foot spa's functions.

Your browser does not support the video tag.

Video 1: HOSPAN Foot Spa Function Introduction. This video demonstrates the various features and controls of the foot spa, including temperature adjustment, massage modes, and bubble function.

MAINTENANCE

Proper maintenance ensures the longevity of your foot spa:

- **Draining Water:** After each use, unplug the unit and remove the remote control. Use the integrated handle to carefully carry the unit to a drain and pour out the water.
- **Cleaning:** Wipe up any residual water with a clean, dry cloth. Do not use abrasive cleaners or harsh chemicals.
- **Storage:** Once completely dry, collapse the foot spa by gently pushing down on the sides until it is flat. Store it in a cool, dry place, such as under a table or sofa.

TROUBLESHOOTING

If you encounter any issues, refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Unit does not turn on.	Not plugged in; power outlet issue; unit not expanded correctly.	Ensure power cord is securely plugged in. Test outlet with another device. Fully expand the unit until it clicks into place.
Water is not heating.	Temperature setting too low; unit not powered on.	Increase the temperature setting using TEMP+ button. Ensure the unit is powered on.
Massage balls not rotating.	Massage function not activated; incorrect mode selected.	Press the MASSAGE 3 MODES button to activate and cycle through modes.
Bubbles not working.	Bubble function not activated.	Press the RED LIGHT BUBBLE button to activate.
Remote control not responding.	Incorrect aiming; battery low (if applicable); obstruction.	Ensure remote is aimed directly at the display. Check/replace remote battery. Remove any obstructions between remote and unit.

If the problem persists after trying these solutions, please contact HOSPAN customer support.

SPECIFICATIONS

- **Model Number:** FS02A
- **Brand:** HOSPAN
- **Power Source:** Corded Electric
- **Material:** Plastic
- **Item Weight:** 8.1 Pounds (approx. 3.67 kg)
- **Package Dimensions:** 17.09 x 13.78 x 6.38 inches (approx. 43.4 x 35 x 16.2 cm)
- **Temperature Range:** 95°F to 118°F (35°C to 48°C)
- **Massage Features:** 6 groups of 3D Tai Chi massage balls, 3 modes
- **Additional Features:** Bubble function, Red Light, Remote Control, Timer (10-60 min), Collapsible design

WARRANTY & SUPPORT

HOSPAN products come with a standard manufacturer's warranty. For specific warranty details, product support, or to inquire about replacement parts, please contact HOSPAN customer service through the retailer where you purchased the product or visit the official HOSPAN website. Please have your model number (FS02A) and purchase date available when contacting support.

Visit the [HOSPAN Store](#) for more information.

