

[Manuals.plus](#) /

› [OR O R O W](#) /

› OROW S206 Computer Speakers Instruction Manual

OR O R O W S206

OROW S206 Computer Speakers Instruction Manual

Model: S206

INTRODUCTION

Thank you for choosing the OROW S206 Computer Speakers. These 12W mini desktop speakers are designed to provide clear audio for your PC, laptop, monitor, Mac, iMac, or projector. Featuring a 3.5mm AUX audio input and USB power, they offer simple plug-and-play functionality with convenient volume control. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance.

SETUP INSTRUCTIONS

Follow these steps to set up your OROW S206 Computer Speakers:

1. **Unpack the Speakers:** Carefully remove both speaker units and the integrated cables from the packaging.
2. **Position the Speakers:** Place the left and right speakers on your desk or desired surface. Ensure they are positioned to provide optimal sound projection.
3. **Connect Audio Cable:** Insert the 3.5mm audio jack into the audio output port of your computer, laptop, monitor, or other compatible device.
4. **Connect USB Power:** Insert the USB-A connector into an available USB port on your computer, laptop, or a USB power adapter (5V/1A recommended). The speakers are powered via USB.
5. **Verify Connection:** Once both the audio and USB cables are connected, the speakers are ready for use. No additional drivers are required for most operating systems.



Image: The OROW S206 speakers connected to a laptop, demonstrating the simple plug-and-play setup using the USB power and 3.5mm audio jack.




Image: A diagram illustrating the cable lengths for the OROW S206 speakers, showing the 1.6m USB cable and 1.3m audio connection for flexible placement.

Setup Video Guide

Your browser does not support the video tag.

Video: A seller-provided video demonstrating the setup process for the OROW S206 mini desktop speakers, showing how to connect them to a PC.

OPERATING INSTRUCTIONS

Once connected, operating your OROW S206 speakers is straightforward:

- **Power On/Off:** The speakers power on automatically when the USB cable is connected to a powered USB port. Disconnect the USB cable to power them off.
- **Volume Control:** Adjust the volume using the inline volume control knob located on the cable. Turn the knob clockwise to increase volume and counter-clockwise to decrease it.
- **Audio Source:** Ensure your device's audio output is set to the 3.5mm jack if you are not hearing sound.

Conveniently Adjustable Volume Knob



Image: The OROW S206 speakers connected to a laptop, highlighting the inline volume control knob on the cable for easy audio adjustment.

No Matter What You Need A Speaker To Do, It Can Do It



Image: Demonstrates the versatility of the OROW S206 speakers in different usage scenarios, including listening to music, watching videos, gaming, and office work.

Operation Video Guide

Your browser does not support the video tag.

Video: A seller-provided video showcasing the OROW S206 desktop speakers in use with a PC, demonstrating their audio output.

Your browser does not support the video tag.

Video: A seller-provided video highlighting the OROW S206 as a mini laptop speaker, showing its compact size and ease of use.

MAINTENANCE

To ensure the longevity and optimal performance of your OROW S206 speakers, follow these simple maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the speakers. Avoid using liquid cleaners, aerosols, or solvents, as these may damage the finish or internal components.
- **Storage:** When not in use for extended periods, store the speakers in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid bending or kinking the cables sharply. Do not pull on the cables to disconnect them; always grasp the plug.
- **Environmental Conditions:** Keep the speakers away from water, excessive dust, and high humidity. These speakers are not waterproof.

TROUBLESHOOTING

If you encounter issues with your OROW S206 speakers, refer to the following common problems and solutions:

Problem	Solution
No sound from speakers.	• Ensure the USB power cable is securely connected to a powered USB port. • Verify the 3.5mm audio jack is fully inserted into your device's audio output. • Check the volume level on the inline control knob and on your connected device. • Confirm that your device's audio output is directed to the correct port (e.g., "Speakers" or "Headphones"). • Test with another audio source or USB port if possible.
Sound is distorted or unclear.	• Reduce the volume on both the speakers and your connected device. • Ensure the audio cable is not damaged and is fully connected. • Test with a different audio source to rule out source issues.
Only one speaker is working.	• Check the 3.5mm audio jack connection; sometimes a partial connection can cause this. • Verify your device's audio balance settings are centered. • Ensure both speaker units are properly connected to the main cable.

SPECIFICATIONS

Feature	Detail
Brand	OR O R O W
Model Number	S206
Speaker Maximum Output Power	12 Watts
Connectivity Technology	Auxiliary, USB

Feature	Detail
Audio Output Mode	Stereo (2.0 Channels)
Input Voltage	5 Volts
Mounting Type	Tabletop Mount
Enclosure Material	Plastic
Additional Features	Bass Boost, Dual Diaphragm, Pure Voice, USB Port, Mini Size
Color	Gray
Control Method	Inline Volume Control
Item Dimensions (D x W x H)	3.1"D x 2.4"W x 4.25"H
Item Weight	0.55 Kilograms
Compatible Devices	Desktop, Gaming Console, Laptop, MP3 Player, Projector
USB Cable Length	1.6 meters (5.2 feet)
Audio Connection Cable Length	1.3 meters (4.2 feet)



Image: An exploded view of the OROW S206 speaker, highlighting the side dual diaphragm design for enhanced bass and clear vocals.

WARRANTY INFORMATION

The OROW S206 Computer Speakers come with a **1-year limited warranty**. This warranty covers manufacturing defects and issues arising from normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or improper maintenance. Please retain your proof of purchase for warranty claims.

CUSTOMER SUPPORT

For any questions, technical assistance, or warranty claims, please contact OROW customer support. We are committed to providing prompt and helpful service.

- **Online Support:** Visit the [OROW Brand Store on Amazon](#) for FAQs and additional product information.
- **Email Support:** Refer to the contact information provided in your product packaging or on the official OROW website for email assistance.
- **Response Time:** OROW customer support aims to respond to inquiries within 24 hours.



Image: OROW customer service representatives ready to assist with product inquiries and support.