

[Manuals.plus](#) /

> [K&F CONCEPT](#) /

> K&F Concept 60-inch Invisible Selfie Stick (Model KF09.132) Instruction Manual

K&F CONCEPT KF09.132

K&F Concept 60-inch Invisible Selfie Stick

Model: KF09.132

1. INTRODUCTION

Thank you for choosing the K&F Concept 60-inch Invisible Selfie Stick. This extension pole is designed to enhance your photography and videography experience with action cameras such as Insta360, GoPro, and DJI OSMO Pocket 3. Its lightweight, durable aluminum alloy construction and adjustable length make it a versatile tool for capturing unique perspectives.



Image 1.1: K&F Concept Invisible Selfie Stick with accessories and camera compatibility examples.

Key features include an extra-long extension up to 153cm (60 inches), strong compatibility with various sports cameras, a compact and portable design, and a sturdy aviation-grade aluminum alloy build. The stick also features 1/4-inch connectors for versatile mounting options.

2. WHAT'S IN THE BOX

Please verify that all items are present in your package:

- 1 x K&F Concept Invisible Selfie Stick for Sports Camera
- 1 x GoPro Adapter

3. SETUP GUIDE

3.1 Attaching Your Camera

1. **For Cameras with 1/4-inch Thread (e.g., Insta360):** Locate the 1/4-inch screw at the top of the selfie stick. Align your camera's 1/4-inch thread with the screw and rotate clockwise until securely fastened.
2. **For Cameras with GoPro Mount (e.g., GoPro, DJI Action):** Attach the provided GoPro adapter to the 1/4-inch screw at the top of the selfie stick. Secure the adapter by tightening the knurled knob. Then, attach your GoPro or DJI Action camera to the adapter using its standard mounting screw.




Image 3.1: Top and bottom 1/4-inch connectors for camera and tripod mounting.

3.2 Extending and Retracting the Pole

- **To Extend:** Hold the base of the selfie stick firmly. Gently pull each section outwards until it reaches the desired length. The tensioned design ensures each section locks securely into place.
- **To Retract:** Push each section back into the main body of the stick. Ensure all sections are fully retracted for compact storage.



Image 3.2: Tensioned design for stable extension and retraction.

The selfie stick offers 6 levels of adjustment, allowing for lengths from 29cm (11.4 inches) to 153cm (60 inches).




Image 3.3: Six levels of height adjustment.

4. OPERATING INSTRUCTIONS

4.1 General Usage

Once your camera is securely attached, hold the silicone handle for a comfortable and firm grip. Extend the pole to your desired length to capture wider angles or elevated shots. Ensure the camera is properly oriented for your intended shot.



Image 4.1: Silicone handle for comfortable use.

4.2 Invisible Selfie Stick Effect (for Insta360 Cameras)

When used with Insta360 panoramic cameras, this selfie stick is designed to be automatically removed from the footage by the camera's software, creating an "invisible" effect. This allows for drone-like perspectives without the need for a drone.



Image 4.2: Demonstration of the "invisible" selfie stick effect with Insta360 cameras.

4.3 Tripod Mounting

The bottom of the extension pole features a 1/4-inch connector, allowing it to be mounted onto a compatible tripod or stand for stationary shots or added stability.

5. MAINTENANCE

- **Cleaning:** Wipe the selfie stick with a soft, dry cloth after each use to remove dust, dirt, or moisture. For stubborn grime, a slightly damp cloth can be used, followed by immediate drying.
- **Storage:** Store the selfie stick in a cool, dry place, away from direct sunlight and extreme temperatures. Ensure it is fully retracted before storage to protect the extension mechanisms.
- **Inspection:** Periodically check all connections and extension sections for any signs of wear or damage. Ensure the 1/4-inch screws are tight and the pole extends and retracts smoothly.




Image 5.1: Aviation-grade aluminum alloy shaft construction.

6. TROUBLESHOOTING

- **Pole does not extend/retract smoothly:** Ensure no dirt or debris is lodged in the sections. Clean the pole as described in the Maintenance section. Do not force the sections.
- **Camera feels loose:** Double-check that the 1/4-inch screw or GoPro adapter is fully tightened. Ensure the camera's mounting point is not stripped or damaged.
- **Excessive shaking when extended:** While the pole is designed for stability, extreme lengths or windy conditions can cause some movement. Ensure all sections are fully extended and locked. For maximum stability, consider using a tripod with the 1/4-inch bottom connector.

If you encounter issues not listed here, please contact K&F Concept customer support for assistance.

7. SPECIFICATIONS

Model Number	KF09.132
Material	Aviation-grade Aluminum Alloy
Color	Aluminum (Black)
Extended Length	153 cm (60 inches)
Folded Size	29 cm (11.4 inches)
Item Weight	177 g (7 ounces)

Mounting Thread	1/4-inch (top and bottom)
Compatible Devices	Insta360 Sports Camera, GoPro, DJI OSMO Pocket 3, DJI Action, other sports cameras with 1/4-inch thread or GoPro mount.

8. WARRANTY AND SUPPORT

8.1 Manufacturer's Warranty

This K&F Concept product is covered by a manufacturer's warranty against defects in materials and workmanship. Please refer to the warranty card included with your purchase or visit the official K&F Concept website for detailed warranty terms and conditions.

8.2 Customer Support

For technical support, product inquiries, or warranty claims, please contact K&F Concept customer service. You can find contact information on the official K&F Concept website or through your retailer.

Visit the official K&F Concept Store: [K&F Concept Store on Amazon](#)