

[Manuals.plus](#) /

> [FOHERE](#) /

> FOHERE 5L Portable Mini Fridge User Manual

FOHERE MFA-5L-GA

FOHERE 5L Portable Mini Fridge User Manual

Model: MFA-5L-GA

INTRODUCTION

Thank you for choosing the FOHERE 5L Portable Mini Fridge. This versatile thermoelectric device is designed to provide both cooling and warming functions, making it ideal for various applications. Its compact size and dual power options (AC/DC) allow for convenient use in offices, dormitories, cars, or for storing cosmetics and beverages. Please read this manual thoroughly before operation to ensure proper use and maintenance.



Image: FOHERE 5L Mini Fridge on a desk, showcasing its compact and portable design.

SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Read all instructions before using the appliance.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Ensure proper ventilation around the unit. Do not block the ventilation openings.
- Unplug the appliance from the power outlet before cleaning or when not in use.

- Do not operate the appliance if the power cord or plug is damaged, or if the unit malfunctions or has been damaged in any way.
- Keep the appliance out of reach of children.
- Use only the provided AC and DC power adapters.
- Do not use the appliance in direct sunlight or near heat sources.

PACKAGE CONTENTS

Upon unpacking, please ensure all items are present and in good condition:

- FOHERE 5L Portable Mini Fridge
- AC Power Adapter (220-240V)
- DC Car Power Cable (12V)
- Removable Shelf
- Drip Tray

PRODUCT OVERVIEW

The FOHERE 5L Mini Fridge offers a compact and efficient solution for your cooling and warming needs. Key features include:

- **Compact 5L Capacity:** Holds up to 6 standard 330ml beverage cans. Internal dimensions: 20 cm (H) x 13.5 cm (W) x 15 cm (D).
- **Cooling & Warming Functions:** Cools to 18-22°C below ambient temperature and warms up to 66°C.
- **Ultra-Quiet Operation:** Operates at less than 28 decibels, ensuring minimal disturbance.
- **Dual Power Options:** Includes AC (220-240V) and DC (12V) adapters for home, office, or car use.
- **Portable Design:** Lightweight at 1.8 kg with a premium leather handle for easy transport.
- **Removable Components:** Features a removable shelf and door basket for flexible storage, plus a drip tray for condensation management.
- **Magnetic Door:** Ensures a secure seal and easy access.

Mini frigo per la cura della pelle

Ti offre una migliore esperienza di cura della pelle



DOPO: Organizza i tuoi cosmetici in modo ordinato e mantieni i tuoi cosmetici freschi



Image: Interior view of the FOHERE 5L Mini Fridge, demonstrating its capacity for beverages with and without the removable shelf.

Mantieni caldo

Riscalda fino a 65 °C



Image: The mini fridge used for storing skincare products, highlighting its versatility.

Tecnologia ultra-silenziosa

60dB
TV

40dB
Whisper

28dB
Fridge

10dB
Breating

0,1\$/al giorno

28dB

CAUTION
DON'T COVER FAN

Tips:
Please check whether the power cord is firmly connected during long-term use to avoid power outage due to loose plug.

FOHERE RoHS
Min i Edge
Model: MFA-9L-C1 2210
AC/DC 24V/1.5A/30W/1.5A/30W/1.5A/30W
DC 12V / 1.5A/30W/1.5A/30W
www.fohere.com
P.O. Box 110000
Guangzhou, China
MADE IN CHINA

Image: The mini fridge in warming mode, keeping food warm on a desk.




Image: Noise level comparison chart, showing the fridge operates at a quiet 28dB.



Image: Detailed view of product features including the magnetic door, removable shelf, and drip tray.

SETUP

- Unpacking:** Carefully remove the mini fridge and all accessories from the packaging. Retain packaging for future transport or storage.
- Placement:** Place the mini fridge on a flat, stable surface. Ensure there is adequate ventilation (at least 10 cm clearance) around all sides, especially the rear fan, to allow for proper heat dissipation. Avoid placing it in direct sunlight or near heat sources.
- Internal Configuration:** Insert the removable shelf and door basket as desired for organizing your items. Ensure the drip tray is correctly positioned at the bottom.
- Power Connection:**
 - For Home/Office (AC):** Connect the AC power adapter to the AC port on the back of the fridge, then plug it into a standard 220-240V wall outlet.
 - For Car (DC):** Connect the DC car power cable to the DC port on the back of the fridge, then plug it into your vehicle's 12V cigarette lighter socket.

Per la casa.

100-240V



per automobile.

9-12V



Image: Compact dimensions of the FOHERE 5L Mini Fridge for easy placement.

With AC Adapter



Enjoy drinks to pair with your favorite game



Image: Mini fridge connected via AC adapter for home or office use.

With DC Adapter



Enjoy cold drinks on the go anytime



Image: Mini fridge connected via DC adapter for car use.

OPERATING INSTRUCTIONS

The FOHERE Mini Fridge features a simple switch on the back to select between cooling and warming modes.

1. **Power On/Off:** Locate the power switch on the back of the unit. Flip it to the 'ON' position to power on the fridge.
2. **Select Mode:**
 - o **Cooling Mode:** Flip the switch to the 'COLD' setting. The internal temperature will decrease to 18-22°C below the ambient temperature. This mode is suitable for beverages, cosmetics, and certain medications.
 - o **Warming Mode:** Flip the switch to the 'HOT' setting. The internal temperature will rise and maintain up to 66°C. This mode is suitable for keeping food warm.

3. **Loading Items:** Place items inside the fridge. For optimal performance, pre-chill or pre-warm items before placing them in the unit, especially when switching modes.

4. **Power Off:** When not in use, flip the power switch to the 'OFF' position and unplug the unit from the power source.

Note: The cooling effect is dependent on the ambient temperature. For best cooling results, operate in a cool environment.

MAINTENANCE

Regular cleaning and maintenance will ensure the longevity and optimal performance of your mini fridge.

- **Cleaning the Interior:** Disconnect the power. Use a soft cloth dampened with mild soap and water to wipe the interior surfaces. Do not use abrasive cleaners or harsh chemicals. Dry thoroughly before reconnecting power.
- **Cleaning the Exterior:** Wipe the exterior with a soft, damp cloth.
- **Drip Tray:** Periodically empty and clean the drip tray located at the bottom of the unit to prevent water accumulation from condensation.
- **Ventilation:** Ensure the rear fan and vents are free from dust and obstructions. Use a soft brush or vacuum cleaner to gently clean them if necessary.
- **Storage:** If storing the unit for an extended period, ensure it is clean and dry. Store in a cool, dry place.

TROUBLESHOOTING

If you encounter any issues with your FOHERE Mini Fridge, please refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|--|--|--|
| Unit is not powering on. | No power supply; loose connection; faulty adapter. | Check if the power cord is securely plugged into both the unit and the outlet. Try a different outlet. Ensure the power switch is 'ON'. |
| Unit is not cooling/warming effectively. | Incorrect mode selected; poor ventilation; high ambient temperature; door not sealed properly. | Ensure the correct mode (COLD/HOT) is selected. Check for obstructions around vents. Ensure the door is fully closed and sealed. Allow more time for temperature change. |
| Excessive noise. | Fan obstruction; unit not on a stable surface. | Check if the fan is clear of debris. Ensure the unit is placed on a flat, stable surface to minimize vibrations. |
| Condensation inside the unit. | Normal operation; frequent door opening. | This is normal. Empty and clean the drip tray regularly. Avoid opening the door too frequently. |

SPECIFICATIONS

| Feature | Specification |
|--------------------------------|--------------------------------------|
| Brand | FOHERE |
| Model Name | MFA-5L-GA |
| Capacity | 5 Liters (Net Refrigerator Capacity) |
| Product Dimensions (D x W x H) | 29 cm x 20 cm x 27 cm |

| Feature | Specification |
|---------------------------------|---|
| Internal Dimensions (H x W x D) | 20 cm x 13.5 cm x 15 cm |
| Item Weight | 1.8 kg |
| Voltage (AC) | 220-240V |
| Voltage (DC) | 12V |
| Cooling Method | Thermoelectric |
| Cooling Performance | Cools 18-22°C below ambient temperature |
| Warming Performance | Warms up to 66°C |
| Noise Level | < 28 dB |
| Annual Energy Consumption | 60 kWh/year |
| Defrost System | Frost-free |
| Shelf Type | Plastic (removable) |
| Country of Origin | China |
| UPC | 616943002836 |

WARRANTY & SUPPORT

Warranty: This FOHERE Mini Fridge comes with a 2-year product warranty from the date of purchase. This warranty covers manufacturing defects and material faults under normal use. It does not cover damage caused by misuse, accident, unauthorized modification, or improper installation.

Customer Support: For any questions, technical assistance, or warranty claims, please contact FOHERE customer service. Refer to the contact information provided with your purchase or visit the official FOHERE website for support details.