

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [VGR](#) /

› [VGR V-901 Premium Metal Housing Hair Clipper User Manual](#)

## VGR V-901

# VGR V-901 Premium Metal Housing Hair Clipper User Manual

Model: V-901

## INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your VGR V-901 Premium Metal Housing Hair Clipper. Please read all instructions carefully before using the appliance and retain this manual for future reference.

## IMPORTANT SAFETY INFORMATION

### **WARNING: To reduce the risk of electric shock, injury, or fire:**

- Avoid use near water. Do not use while bathing or showering.
- Do not use on infants.
- Keep away from children.
- Do not immerse the appliance in water or other liquids.
- Always unplug the appliance immediately after use and before cleaning.
- Do not operate the appliance with a damaged cord or plug, or if it malfunctions or has been dropped or damaged.

## PACKAGE CONTENTS

Verify that all items are present and in good condition upon opening the package:



**Image Description:** The image displays the VGR V-901 hair clipper in gold, alongside its accessories. These include four guide combs (1mm, 3mm, 5mm, 7mm), a small cleaning brush, a bottle of lubricating oil, and a USB Type-C charging cable. The product packaging is also visible, highlighting key features like the LED display and metal housing.

- VGR V-901 Hair Clipper
- 4 Guide Combs (1mm, 3mm, 5mm, 7mm)
- USB Type-C Charging Cable
- Cleaning Brush
- Lubricating Oil
- User Manual (this document)

## PRODUCT OVERVIEW

The VGR V-901 is a professional-grade hair clipper designed for precision grooming. It features a durable metal housing and advanced blade technology.

- **Powder Metallurgic Blades:** Self-sharpening ceramic and powder metallurgic blades for smooth cutting.
- **Powerful Motor:** Heavy-duty motor with 5500-7000 RPM and speed control buttons.
- **LED Digital Display:** Shows battery charge status and RPM. Includes over-charge protection.
- **Cordless/Corded Operation:** Rechargeable 1600mAh Li-ion battery provides up to 240 minutes of cordless use after a 2.5-hour charge. Can also be used while corded.

- **Adjustable Taper Lever:** For fine-tuning cutting lengths.

## SETUP

1. **Initial Charge:** Before first use, fully charge the clipper for approximately 2.5 hours using the provided USB Type-C cable. The LED display will indicate charging status and battery level.
2. **Blade Inspection:** Ensure the blades are clean and properly aligned. Apply a few drops of lubricating oil to the blades before first use and after each cleaning.
3. **Attach Guide Comb:** Select the desired guide comb (1mm, 3mm, 5mm, or 7mm) and securely attach it to the clipper head. Ensure it clicks into place.

## OPERATING INSTRUCTIONS

1. **Power On/Off:** Press the power button to turn the clipper on or off.
2. **Adjust Speed:** Use the speed control buttons (+/-) to select the desired motor RPM (5500-7000 RPM). The LED display will show the current speed.
3. **Turbo Function:** The clipper features a turbo function for extra power when needed. Activate it via the dedicated button.
4. **Cutting Hair:**
  - Start with a longer guide comb than you think you need, and gradually reduce the length if necessary.
  - Hold the clipper with the blades pointing slightly away from the scalp.
  - Move the clipper against the direction of hair growth for an even cut.
  - Use smooth, overlapping strokes.
5. **Adjust Taper Lever:** The adjustable taper lever allows for precise blending and fading without changing guide combs. Move the lever up for a shorter cut and down for a longer cut.

## MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your clipper.

1. **Cleaning Blades:** After each use, turn off the clipper and remove the guide comb. Use the provided cleaning brush to remove loose hairs from the blades.
2. **Lubricating Blades:** After cleaning, apply 1-2 drops of lubricating oil across the top of the blades. Turn the clipper on for a few seconds to distribute the oil. Wipe off any excess oil.
3. **Storage:** Store the clipper in a dry, cool place, away from direct sunlight and moisture.
4. **Battery Care:** To maintain battery life, avoid completely draining the battery frequently. Charge the clipper when the LED display indicates low battery.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Clipper does not turn on.	Battery is depleted.	Charge the clipper using the USB Type-C cable.

Problem	Possible Cause	Solution
Clipper pulls hair or cuts unevenly.	Blades are dull, dirty, or not lubricated.	Clean and lubricate the blades. If problem persists, blades may need replacement.
Clipper runs slowly.	Low battery or blades are clogged.	Charge the clipper. Clean the blades thoroughly.
Excessive noise or vibration.	Blades are not properly aligned or lubricated.	Check blade alignment and apply lubricating oil.

## SPECIFICATIONS

<b>Model Number</b>	V-901
<b>Brand</b>	VGR
<b>Blade Material</b>	Powder Metallurgic / Stainless Steel
<b>Motor Speed</b>	5500-7000 RPM (Adjustable)
<b>Battery Type</b>	1600mAh Li-ion Battery
<b>Charging Time</b>	Approx. 2.5 hours
<b>Operating Time</b>	Up to 240 minutes (cordless)
<b>Power Source</b>	Battery Powered / Corded (USB Charging)
<b>Guide Combs</b>	1mm, 3mm, 5mm, 7mm
<b>Product Dimensions</b>	19.6 x 13 x 7.5 cm
<b>Item Weight</b>	570 Grams
<b>Special Features</b>	LED Display, Fast Charge, Rechargeable, USB Charging, Metal Housing

## WARRANTY AND SUPPORT

VGR offers a 12-month quality warranty for this product. If you encounter any issues or are not satisfied with your purchase, please contact VGR customer service for assistance. They aim to respond within 24 hours to provide a satisfactory resolution.

For further support or inquiries, please refer to the contact information provided on the product packaging or the official VGR website.

© 2025 VGR. All rights reserved.



[VGR V-282 Professional Hair Clipper User Manual and Specifications](#)

Comprehensive user manual for the VGR V-282 Voyager Professional Hair Clipper. Includes detailed information on components, safety instructions, usage, charging, maintenance, technical features, and disposal guidelines.



[VGR V-990 Cordless Hair Trimmer User Guide](#)

Comprehensive guide to using the VGR V-990 professional cordless hair trimmer, featuring 8000RPM, barber-grade performance, and easy hair cutting for men.



[VGR V-085 Professional Hair Trimmer Manual and Safety Instructions](#)

This document provides comprehensive safety instructions, components list, usage guidelines, cleaning and maintenance procedures, and technical specifications for the VGR V-085 Professional Hair Trimmer.



[VGR V-906 Professional Hair Trimmer User Manual](#)

Comprehensive user manual for the VGR V-906 electric hair trimmer, detailing features, operation, charging, maintenance, and troubleshooting for professional and home grooming.



[VGR V-085 Professional Hair Trimmer User Manual & Safety Instructions](#)

This document provides comprehensive safety instructions, component descriptions, usage guidelines, charging, cleaning, and maintenance information for the VGR V-085 Professional Hair Trimmer.



[VGR V-930 Professional Hair Trimmer User Manual with AFA Endorsement](#)

Comprehensive user manual for the VGR V-930 Professional Hair Trimmer, featuring AFA endorsement with player imagery. Covers safety instructions, components, usage, charging, cleaning, maintenance, and technical specifications for this personal grooming device.