

[Manuals.plus](#) /

› [Little Live Pets](#) /

› Little Live Pets Mama Surprise Bunny – Amazon Exclusive Interactive Hutch Playset with Mama Bunny, 3 Surprise Babies, 20+ Sounds & Reactions, Accessories & Gift Boxes, Repeat Play, Ages 4+ Bunny - Amazon Exclusive Instruction Manual

Little Live Pets 26593

Little Live Pets Mama Surprise Bunny - Interactive Hutch Playset Instruction Manual

Model: 26593

Brand: Little Live Pets

SETUP GUIDE

Unboxing and Initial Setup

Carefully remove all contents from the packaging. Ensure all components are present before beginning play.

- 1 Electronic Mama Toy
- 1 Hutch Toy
- 3 Baby Toys
- 3 Gift Boxes
- 9 Gift Contents (accessories)
- 3 Birth Certificates
- 3 Accessories



The complete Little Live Pets Mama Surprise Bunny playset, including the interactive hutch, the soft Mama Bunny, three surprise baby bunnies, and various accessories like a carrot, brush, and gift boxes.

Battery Installation

The Mama Bunny and the hutch require batteries for interactive features. Locate the battery compartments on both units. Insert 6 AAA batteries in total (3 for Mama Bunny, 3 for the hutch), ensuring correct polarity. Batteries are required and not included.

Hutch Preparation

Open the front doors of the hutch. Ensure the interior is clear before placing Mama Bunny inside. On the back of the hutch, you will find a switch to select between 'Normal Mode' and 'Fast Mode' for baby arrival timing. 'Normal Mode' allows for a longer waiting period between births, while 'Fast Mode' expedites the process.



Mama Bunny and her three baby bunnies are shown inside the interactive hutch, ready for play.

OPERATING INSTRUCTIONS

Caring for Mama Bunny

To prepare Mama Bunny for her babies, you must nurture her. Pet her head, feed her with the included carrot accessory, and brush her fur with the heart-shaped brush. Mama Bunny will respond with over 20 sounds and reactions.

20+ Pieces

A child gently feeds the interactive Mama Bunny with its plastic carrot accessory, demonstrating one of the nurturing interactions.



A child uses the pink heart-shaped brush to groom the soft fur of the Mama Bunny, an action that elicits responses from the toy.

When Mama Bunny's heart starts to glow, it indicates she is ready to have a baby. This is your cue to place her inside the interactive hutch.

The Magical Birth Process

Once Mama Bunny is glowing and placed inside the hutch, close the doors. The hutch will then begin the magical reveal process. The time it takes for a baby to appear depends on the selected mode ('Normal' or 'Fast').



A child watches the interactive hutch with anticipation, waiting for the magical arrival of the baby bunnies.



This four-panel image visually guides users through the steps: 1) Feeding Mama Bunny, 2) Brushing her fur, 3) Placing her in the hutch, and 4) The surprise reveal of a baby bunny.

Discovering the Babies

After the waiting period, open the hutch doors to discover a new-born baby bunny! Each baby comes with its own gift box care package, which includes a birth certificate, two accessories, and two hair elastics. There are three unique themed babies to collect: rock n' roll, preppy, or princess.



A child smiles while holding one of the small, soft baby bunnies that magically appears from the hutch.



A child is shown dressing and styling the three small baby bunnies with their unique themed accessories, such as glasses and crowns.

Repeat Play

The magical experience is repeatable! To play again, open the top lid of the hutch. Place the baby bunnies back into the designated slots inside the hutch. Close the lid, and Mama Bunny is ready to have more babies after being nurtured again.



A child demonstrates how to reload the baby bunnies into the top compartment of the hutch, allowing for the magical birth process to be repeated.

MAINTENANCE

Cleaning

To clean the Mama Bunny and hutch, gently wipe with a damp cloth. Do not submerge the electronic parts in water. Avoid harsh chemicals or abrasive cleaners.

Battery Replacement

If the interactive features of Mama Bunny or the hutch begin to diminish, it may be time to replace the batteries. Refer to the battery compartment for proper battery type and orientation. Always use fresh batteries and dispose of old batteries responsibly.

TROUBLESHOOTING

Mama Bunny Not Responding

- Check if batteries are correctly installed and not depleted.
- Ensure the power switch on Mama Bunny is in the 'ON' position.
- Confirm Mama Bunny has been sufficiently nurtured (fed, petted, brushed) until her heart glows.

Babies Not Appearing

- Verify Mama Bunny is correctly placed inside the hutch and the doors are closed.
- Ensure the baby bunnies are properly loaded into the top compartment for repeat play.
- Check the 'Normal'/'Fast' mode switch on the hutch. Allow sufficient time for the babies to appear based on the selected mode.

PRODUCT SPECIFICATIONS

Feature	Detail
Product Dimensions	7.8 x 11.93 x 11.38 inches
Item Weight	3.54 pounds
Country of Origin	China
Item Model Number	26593
Manufacturer Recommended Age	4 - 15 years
Batteries Required	6 AAA batteries (not included)
Manufacturer	MOOSE TOYS LLC

WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official Little Live Pets website or contact MOOSE TOYS LLC directly. Keep your purchase receipt for any warranty claims.

Safety Information: CHOKING HAZARD---Small parts. Not for children under 3 years.

Visit the official [Little Live Pets Store](#) for more products and information.