

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [MAX](#) /
- › [MAX Adventure Fire Rescue Playset \(Model 83172\) Instruction Manual](#)

MAX 83172

# MAX Adventure Fire Rescue Playset Instruction Manual

Model: 83172

## 1. INTRODUCTION

Welcome to the MAX Adventure Fire Rescue Playset. This 238-piece building brick set allows you to construct a dynamic fire rescue scene, including a fire truck and a fire helicopter. Designed for children aged 6 years and up, this set encourages creative play, problem-solving, and fine motor skills development.



Image description: The product packaging for the MAX Adventure Fire Rescue Playset, showing the assembled fire truck and helicopter, along with fire elements, against a city backdrop. The box highlights "238 Pieces" and "6+".

## 2. SAFETY INFORMATION

**WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.**

Adult supervision is recommended during assembly and play, especially for younger children. Ensure all small pieces are kept out of reach of infants and toddlers.

## 3. PACKAGE CONTENTS

Your MAX Adventure Fire Rescue Playset includes the following components:

- 238+ MAX building bricks
- Detailed instruction manual for building the MAX Fire Rescue vehicles
- Components for one buildable fire truck
- Components for one buildable fire helicopter
- Buildable fire elements



Image description: The fully assembled MAX Fire Rescue Playset, featuring a red and black fire truck with blue lights, a red and grey helicopter with spinning blades, and two orange fire elements, all on a white background.

## 4. SETUP AND ASSEMBLY

Follow the included step-by-step instructions to assemble the MAX Fire Rescue fire truck and helicopter. The manual provides clear diagrams to guide you through each stage of construction.

1. Unpack all building bricks and the instruction manual from the box.
2. For easier assembly, sort the bricks by color or type before you begin.
3. Begin by constructing the fire truck, carefully following the diagrams in the manual.
4. Proceed to assemble the fire helicopter according to the instructions.
5. Assemble the fire elements as shown in the manual.

MAX Bricks are designed to be compatible with leading brick brands, allowing for seamless integration with existing building brick collections.



Image description: A detailed view of the assembled MAX Fire Rescue truck, showcasing its red and black body, blue emergency lights, robust front bumper, and roof-mounted ladder, set against a white background.

## 5. OPERATING THE PLAYSET

---

Once assembled, the MAX Adventure Fire Rescue Playset is ready for imaginative play scenarios.

### 5.1. Fire Truck

- The fire truck features rolling wheels for easy movement across surfaces.
- Use the truck to transport your brave firefighters (figures not included) to the scene of the fire.
- The roof-mounted ladder can be positioned for various rescue operations.

### 5.2. Fire Helicopter

- The fire helicopter features articulated movement with spinning rotor blades.

- Simulate flying the helicopter to reach fires from above or provide aerial support.
- The helicopter can be used to assist the fire truck in coordinated rescue operations.

### 5.3. Fire Elements

- Place the translucent orange fire elements to create realistic fire scenarios for the fire rescue team to extinguish.



Image description: A child smiling and playing with the assembled MAX Fire Rescue Playset, which includes the fire truck, helicopter, and fire elements, on a white table. The product box is visible in the background.






Image description: A close-up view of the assembled MAX Fire Fighter helicopter, highlighting its red body, blue cockpit, and black spinning rotor blades, set against a white background.

## 6. MAINTENANCE AND CARE

---

To ensure the longevity and cleanliness of your MAX Adventure Fire Rescue Playset:

- **Cleaning:** Keep the building bricks clean by gently wiping them with a damp cloth. Avoid using harsh chemicals, abrasive cleaners, or submerging electronic components (if any) in water.
- **Storage:** Store the playset in a dry, cool place away from direct sunlight. Prolonged exposure to sunlight can cause discoloration or warping of the plastic bricks.
- **Inspection:** Periodically check for any loose, damaged, or worn pieces. Replace any broken parts to maintain play integrity and safety.
- **Safety:** Always keep small parts away from very young children and pets to prevent choking hazards.

## 7. TROUBLESHOOTING

---

### 7.1. Missing Pieces

In the rare event of a missing piece, please contact MAX customer support for assistance. While MAX bricks are compatible with other leading brands, it is recommended to use original MAX parts for optimal fit and design integrity.

### 7.2. Assembly Difficulties

If you encounter difficulties during assembly, carefully review the instruction manual diagrams. Ensure all pieces are correctly oriented and firmly pressed together. Sometimes, a small adjustment can resolve the issue.

## 8. SPECIFICATIONS

---

Feature	Detail
Product Name	MAX Adventure Fire Rescue Playset
Model Number	83172
ASIN	B0CPNZV45P
Number of Pieces	238+
Recommended Age	6 years and up
Product Dimensions	11.02 x 2.2 x 8.98 inches
Item Weight	12.6 ounces
Manufacturer	ZURU
Release Date	July 1, 2024



Image description: A close-up view of a translucent orange fire element, designed to represent flames, attached to a brown brick base, set against a white background.

## 9. CUSTOMER SUPPORT

---

For further assistance, questions, or to report missing parts regarding your MAX Adventure Fire Rescue Playset, please contact ZURU, the manufacturer of MAX products. Refer to the product packaging for specific contact details or visit the official MAX website.

For more information about MAX products, you can also visit the [MAX Store on Amazon](#).