

[Manuals.plus](#) /

› [Robo Alive](#) /

› Robo Alive Dino Escape Robotic Toy Instruction Manual - Model 71127 by ZURU

## Robo Alive 71127

# Robo Alive Dino Escape Robotic Toy Instruction Manual

Model: 71127 | Brand: ZURU

## 1. INTRODUCTION

Welcome to the exciting world of Robo Alive Dino Escape! This robotic toy set provides an immersive experience where you can embark on a mission to capture a runaway dinosaur. Utilize the included vehicles, firing weapons, and traps to secure the Dino before it causes chaos. The dinosaur features lifelike lights and sounds, bringing the prehistoric world to life.

## 2. WHAT'S IN THE BOX

- Robotic Light-Up Dino
- Dino Cage (doubles as storage)
- Capture Vehicle with Firing Weapons
- Helicopter with Claw Attachment
- Small Dino Figures
- Dino Slime with Hidden Dino Egg
- 1 AAA battery (included for demonstration purposes)



Image: All components included in the Robo Alive Dino Escape set.

### 3. IMPORTANT SAFETY INFORMATION

**WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.**

- Adult supervision is recommended during play.
- Keep small parts away from young children to prevent choking.
- Do not aim firing weapons at eyes or face.
- Ensure battery compartment is securely closed after installation.

## 4. SETUP

### 4.1 Battery Installation (Robotic Dino)

1. Locate the battery compartment on the underside of the robotic dinosaur.
2. Using a small screwdriver, open the battery compartment cover.
3. Insert 1 AAA battery, ensuring correct polarity (+/-).
4. Replace the cover and tighten the screw.

### 4.2 Initial Assembly

- The Dino Cage can be opened to access accessories. Unlatch the side clips to open the cage.
- Attach the helicopter to the top of the cage if desired, or use it independently.
- Ensure all small accessories (weapons, traps, small Dinos) are removed from packaging.

## 5. OPERATING INSTRUCTIONS

### 5.1 Robotic Dino Functions

- **Power On/Off:** Locate the switch on the underside of the Dino to turn it on or off.
- **Lights and Sounds:** Move the Dino's tail to activate its light-up features and realistic roaring sounds.
- **Movement:** The Dino is equipped with wheels on its feet, allowing it to move across smooth surfaces. It performs best on hard floors.



*Image: Robotic Dino with approximate dimensions.*

### 5.2 Vehicle and Accessory Use

- **Capture Vehicle:** Use the vehicle to race towards the Dino. It features real firing weapons to help capture the dinosaur.
- **Helicopter:** The helicopter can be used to transport the Dino Cage or to assist in the capture mission. It may include a claw attachment to pick up small items.
- **Dino Trap:** Set the included trap to ensnare the Dino.
- **Dino Slime & Egg:** Dig through the Dino Slime to discover a hidden Dino egg and additional small Dino figures.



*Image: Helicopter with claw picking up a small dinosaur.*

### 5.3 Product Overview Video

Your browser does not support the video tag.

*Video: A brief product overview demonstrating the Robo Alive Dino Escape set and its features.*

## 6. MAINTENANCE

- Clean the toy with a soft, damp cloth. Do not immerse in water.
- Remove batteries if the toy will not be used for an extended period to prevent leakage.
- Store all components in the Dino Cage or a designated storage area to prevent loss.

## 7. TROUBLESHOOTING

- **Dino not moving/lighting up:** Check battery installation and ensure the power switch is in the 'ON' position. Replace batteries if necessary.
- **Dino movement is slow:** Ensure the Dino is on a smooth, hard surface. Carpet or uneven surfaces may impede movement.
- **Missing parts:** Carefully check all packaging materials. Contact customer support if parts are genuinely missing from a new set.

## 8. SPECIFICATIONS

| Feature                      | Detail                      |
|------------------------------|-----------------------------|
| Product Dimensions           | 15.08 x 8.43 x 11.77 inches |
| Item Weight                  | 1.1 pounds                  |
| Item Model Number            | 71127                       |
| Manufacturer Recommended Age | 3 years and up              |
| Batteries Required           | 1 AAA battery (included)    |
| Manufacturer                 | ZURU                        |

## 9. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the contact details provided on the product packaging or visit the official ZURU website. Keep your purchase receipt as proof of purchase.

© 2026 ZURU. All rights reserved.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question