



Manuals.plus /

› LINSY HOME /

› LINSY HOME 9-Drawer Dresser Instruction Manual

**LINSY HOME Dresser+LH618E4-B+MAY**

# LINSY HOME 9-Drawer Dresser Instruction Manual

Model: Dresser+LH618E4-B+MAY

## INTRODUCTION

---

Thank you for choosing the LINSY HOME 9-Drawer Dresser. This manual provides detailed instructions for the assembly, safe operation, and maintenance of your new furniture. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image: The LINSY HOME 9-Drawer Dresser, showcasing its farmhouse design and ample storage capacity in a bedroom environment.

## SAFETY INFORMATION

---

Your safety is paramount. Please adhere to the following safety guidelines:

- **Tip-Over Prevention:** Always secure the dresser to a wall using the provided anti-tip kit. This is crucial to prevent serious injury from tip-over incidents, especially in households with children or pets.
- **Weight Capacity:** Do not exceed the maximum load capacity of the tabletop, which is 66 lbs (approximately 30 kg). Distribute weight evenly across drawers and the top surface.
- **Assembly:** Assemble the dresser on a soft, clean surface to prevent scratches. Ensure all screws and fasteners are tightened securely before use. Periodically check and re-tighten fasteners as needed.
- **Drawer Safety Stops:** The drawers are equipped with safety stops to prevent them from being pulled out completely. Do not attempt to force drawers beyond their intended extension.

# Anti-tip kit adds extra stability

Protect your kids and pets




Image: Illustration demonstrating the proper installation of the anti-tip kit to secure the dresser to a wall, preventing accidental tipping.

## ASSEMBLY INSTRUCTIONS

Assembly is required for this dresser. While detailed instructions are provided within the product packaging, here are general guidelines:

1. **Unpack and Verify:** Carefully unpack all components and hardware. Refer to the parts list in your packaged manual to ensure all pieces are present and undamaged.
2. **Prepare Workspace:** Clear a spacious area for assembly. Lay down a blanket or cardboard to protect both the dresser components and your floor from scratches.
3. **Follow Step-by-Step:** Adhere strictly to the numbered steps in the provided instruction booklet. Each part is typically labeled for easy identification.
4. **Tools Recommended:** An electric screwdriver is recommended for faster and more efficient assembly. Two people are recommended for assembly to ensure stability and ease of handling larger components.
5. **Secure Fasteners:** Ensure all screws, cam locks, and dowels are fully inserted and tightened. Do not overtighten to avoid damaging the wood.

6. **Install Anti-Tip Kit:** Once the dresser is fully assembled and in its final position, install the anti-tip kit as per the safety instructions.

## Product Size



Estimated installation time: **3H**



Image: A detailed diagram illustrating the overall dimensions of the dresser (15.7"D x 53.5"W x 36.8"H) and the internal dimensions of its various drawers, along with estimated assembly time.

## OPERATION

The LINSY HOME 9-Drawer Dresser is designed for efficient storage in various rooms.

- **Drawer Usage:** The dresser features nine spacious drawers. Six larger drawers are suitable for items like shirts, pants, or larger accessories, while three smaller top drawers are ideal for smaller items such as socks, underwear, or personal effects.
- **Drawer Extension:** For safety, the drawers are designed with stops that limit their full extension. This prevents accidental detachment and enhances stability. Items at the very back of the drawer may require reaching or shifting front items to access.
- **Tabletop Use:** The top surface can be used for decorative items, lamps, or as a display area. Ensure the total

weight on the tabletop does not exceed 66 lbs (30 kg).




Image: An illustration detailing the approximate storage capacity of the dresser's drawers for different types of items, such as tissues, socks, underwear, snacks, toys, and shirts.

## CARE AND MAINTENANCE

Proper care will extend the life and appearance of your dresser.

- **Cleaning:** Wipe the dresser surfaces with a dry, soft cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the finish.
- **Spills:** Immediately wipe up any spills with a dry cloth to prevent staining or damage to the wood finish.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the finish.
- **Temperature and Humidity:** Maintain a stable room temperature and humidity level to prevent warping or cracking of the wood.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten as necessary to maintain structural integrity.

# Premium Edge Sealing Process



Exquisite sealing edge,  
longer service life



No edge sealing,  
easy to crack and mold



Image: A close-up view highlighting the exquisite sealing edge of the dresser drawers, designed for durability and a longer service life.

## TROUBLESHOOTING

If you encounter issues with your dresser, consider the following common solutions:

Problem	Possible Cause	Solution
Drawers do not slide smoothly.	Loose drawer slides or misaligned tracks.	Check that all screws securing the drawer slides to both the drawer and the dresser frame are tight. Ensure the tracks are free of debris.
Dresser feels wobbly or unstable.	Loose assembly fasteners or uneven floor.	Re-tighten all assembly screws. Ensure the dresser is on a level surface; use shims if necessary. Verify the anti-tip kit is securely installed.
Drawers do not close flush.	Misaligned drawer front or obstruction.	Check for any items obstructing the drawer's path. Ensure the drawer front is properly attached and aligned with the drawer box.

## SPECIFICATIONS

---

Feature	Detail
Brand	LINSY HOME
Model Name	Dresser
Model Number	Dresser+LH618E4-B+MAY
Product Dimensions	15.6"D x 53.4"W x 36.7"H
Color	Brown
Furniture Finish	Brown, Rustic
Room Type	Bedroom, Living Room, Nursery
Item Weight	120 Pounds (approx. 54.4 kg)
Number of Drawers	9
Tabletop Load Capacity	66 lbs (approx. 30 kg)
Material	CARB P2 & TSCA certified eco-friendly manufactured wood
Assembly Required	Yes
GTIN (UPC)	00850052261412

# | P2 Grade Plate



Image: An illustration of the P2 Grade Plate material used in the dresser's construction, indicating low formaldehyde emission for environmental and health safety.

## WARRANTY AND SUPPORT

For any questions, concerns, or assistance with your LINSY HOME dresser, please refer to the following information:

- **Return Policy:** This product typically comes with a 30-day easy return policy. Please refer to your purchase platform's specific return guidelines for detailed information.
- **Customer Support:** For direct support, please contact LINSY HOME customer service through the retailer's platform or visit the official LINSY HOME store page.
- **Missing Parts or Damage:** If you find any missing parts or damaged components upon unboxing, please contact customer support immediately for assistance.

For more information, you can visit the [LINSY HOME Store on Amazon](#).

