

PSIDE PARKSIDE® PLS 2600 B2

Parkside® PLS 2600 B2 Electric Blower Vacuum

Model: PARKSIDE® PLS 2600 B2 | Brand: PSIDE

1. INTRODUCTION

This manual provides important information regarding the safe operation, assembly, maintenance, and troubleshooting of your Parkside® PLS 2600 B2 Electric Blower Vacuum. Please read this manual thoroughly before using the device for the first time and keep it for future reference. This 3-in-1 device functions as a powerful blower, an efficient vacuum, and includes an integrated shredder function for reducing leaf volume.

2. IMPORTANT SAFETY INSTRUCTIONS

WARNING: Read all safety warnings, instructions, illustrations, and specifications provided with this power tool. Failure to follow all instructions listed below may result in electric shock, fire, and/or serious injury.

- Always wear appropriate personal protective equipment, including eye protection, hearing protection, and sturdy footwear.
- Ensure the power cord is in good condition and positioned to avoid tripping hazards or damage.
- Do not operate the device in wet conditions or rain.
- Keep children, bystanders, and pets away from the operating area.
- Before cleaning, servicing, or storing, always disconnect the device from the power supply.
- Never direct the blower nozzle at people or animals.
- Do not vacuum hard objects such as stones, metal pieces, or glass, as this can damage the impeller and cause injury.
- Use only original spare parts and accessories.

3. PRODUCT OVERVIEW AND COMPONENTS

The Parkside® PLS 2600 B2 is designed for efficient leaf management. Below is an illustration of the main components:



Image: The Parkside PLS 2600 B2 Electric Blower Vacuum, showing its main body, long tube with guide wheels, and attached collection bag. Red arrows indicate the adjustable length of the tube.

- **Motor Unit:** Contains the 2600 W motor and control switches.
- **Main Handle:** Ergonomically designed for comfortable grip and control.
- **Auxiliary T-Handle:** Provides additional grip for better guidance during operation.
- **Blower/Vacuum Tube:** The main tube for air intake (vacuum) or output (blower). Features adjustable length.
- **Guide Wheels:** Two wheels located at the end of the tube for easier maneuverability on the ground.
- **Collection Bag:** 34-liter capacity bag with a zipper for easy emptying, attaches to the vacuum port.
- **Function Selector Switch:** Allows easy switching between blower and vacuum modes.
- **Speed Control:** Two-level speed adjustment for air velocity up to 270 km/h.
- **Shoulder Strap:** Adjustable length strap with a carabiner for comfortable carrying.
- **Cable Strain Relief:** Integrated to prevent accidental disconnection of the power cable.

4. ASSEMBLY

Before first use, some assembly may be required:

1. **Attach the Blower/Vacuum Tube:** Securely connect the main tube to the motor unit according to the instructions in the device manual. Ensure it clicks into place or is firmly fastened.
2. **Attach the Collection Bag:** For vacuuming, attach the 34-liter collection bag to the designated vacuum port on the motor unit. Ensure the zipper is closed before operation.
3. **Install the Shoulder Strap:** Attach the adjustable shoulder strap to the designated points on the device using the carabiner. Adjust the length for comfortable operation.
4. **Check Power Cable:** Ensure the power cable is securely connected and routed through the integrated cable strain relief.

5. OPERATING INSTRUCTIONS

5.1 Switching Between Blower and Vacuum Modes

The device features a convenient rocker switch to select between blower and vacuum functions:

- To activate the **blower function**, set the selector switch to the 'Blower' position.
- To activate the **vacuum function**, set the selector switch to the 'Vacuum' position. Ensure the collection bag is properly attached.

5.2 Speed Control

The device offers two levels of speed control for optimal performance:

- Use the lower speed setting for lighter debris or sensitive areas.
- Select the higher speed setting for stubborn debris or larger areas, achieving air speeds up to 270 km/h.

5.3 Using the Shredder Function

When operating in vacuum mode, the integrated shredder function automatically reduces the volume of collected leaves by up to 10:1. This allows for more efficient collection and less frequent emptying of the bag.

5.4 Ergonomics and Maneuverability

- Utilize the adjustable shoulder strap to distribute the weight of the device, reducing fatigue during extended use.
- The two guide wheels at the end of the tube facilitate easier movement across surfaces, especially when vacuuming.
- The additional T-handle provides improved guidance and control.

6. MAINTENANCE AND CLEANING

Regular maintenance ensures optimal performance and extends the lifespan of your device.

- **Emptying the Collection Bag:** Regularly empty the 34-liter collection bag, especially when it feels full, to maintain suction efficiency. Use the zipper for easy emptying.
- **Cleaning the Collection Bag:** Periodically clean the collection bag to remove fine dust and debris that can clog the fabric. Follow the manufacturer's instructions for washing, if applicable.
- **Clearing Blockages:** If suction power decreases or the device vibrates excessively, check the blower/vacuum tube and impeller for blockages. **Always disconnect the power before attempting to clear any blockages.**
- **General Cleaning:** Wipe down the exterior of the device with a damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure no water enters the motor unit.
- **Storage:** Store the device in a dry, well-ventilated area, away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

If you encounter issues with your Parkside® PLS 2600 B2, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not start.	No power supply. Power switch off. Thermal overload protection activated.	Check power connection and outlet. Ensure power switch is in 'ON' position. Allow device to cool down for several minutes.

Problem	Possible Cause	Solution
Reduced suction/blowing power.	Collection bag full. Tube or impeller blocked. Function selector in wrong position.	Empty collection bag. Disconnect power, then clear blockages from tube and impeller. Ensure selector is in correct mode (vacuum/blower).
Excessive vibration or unusual noise.	Impeller damaged or unbalanced. Foreign object in impeller. Loose components.	Disconnect power and inspect impeller for damage or foreign objects. If damage is severe or problem persists, contact customer support.

If the problem persists after attempting these solutions, please contact qualified service personnel.

8. TECHNICAL SPECIFICATIONS

Specification	Value
Model Name	Parkside PLS 2600 B2
Power Connection	2600 W
Max. Rotational Speed	15000 rpm
Max. Air Speed	270 km/h
Max. Suction Volume	12 m³/min
Shredding Ratio	Max. 10:1
Collection Bag Volume	34 liters
Power Cable Length	Approx. 20 cm (device cable)
Dimensions (L x W x H)	Approx. 111.6 x 16.8 x 38 cm
Weight	Approx. 3 kg
Material	Plastic, Textile
Power Source	Electric Cable
Voltage	230 Volts (AC)

9. WARRANTY AND SUPPORT

Specific warranty information is not provided within this manual. For details regarding warranty coverage, spare parts availability, and customer support, please refer to the purchase documentation, the manufacturer's official website, or contact your retailer directly. Always retain your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question