

[Manuals.plus](#) /

> [vidaXL](#) /

> vidaXL Dog Crate Furniture, Brown Oak, 64.5x80x71 cm - Instruction Manual

## vidaXL 838336

# vidaXL Dog Crate Furniture - Instruction Manual

Model: 838336 | Brand: vidaXL

## INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your vidaXL Dog Crate Furniture. This versatile product serves as both a comfortable kennel for your dog and a functional side table for your living space. Please read these instructions carefully before assembly and use to ensure safe and correct operation.



*Image: The vidaXL Dog Crate Furniture, showcasing its dual functionality as a pet kennel and a stylish side table.*

## **SAFETY INFORMATION**

### **General Safety:**

- Ensure all components are securely fastened before allowing your pet to use the crate.
- Do not overload the top surface if using as a table.
- Keep small children away during assembly to prevent access to small parts.
- Regularly inspect the crate for any loose parts or damage. Repair or replace as necessary.
- This product is designed for indoor use. While durable, prolonged outdoor exposure may affect its lifespan.

## **SETUP AND ASSEMBLY**

Assembly is required for this product. Please follow the steps below carefully. It is recommended to assemble the crate on a soft, clean surface to prevent scratches.

### **Required Tools (Not Included):**

- Screwdriver (Phillips head recommended)
- Hammer (optional, for dowels)

## Assembly Steps:

1. **Unpack and Identify Components:** Carefully unpack all parts and compare them with the included parts list and diagrams. Ensure all pieces are present and undamaged.
2. **Assemble Side Panels:** Attach the metal bars to the designated slots on the side panels. Secure them according to the diagram.
3. **Connect Panels:** Join the side panels, back panel, and bottom panel using the provided screws and dowels. Ensure all connections are tight and stable.
4. **Install Door:** Attach the door panel using the hinges. The door is designed to be reversible, allowing it to open from either the left or right side. Choose your preferred orientation before securing the hinges.
5. **Attach Latch:** Install the security latch on the door and the corresponding side panel. Ensure the latch operates smoothly and securely.
6. **Place Top Panel:** Position the top panel onto the assembled structure and secure it with the remaining screws.
7. **Final Check:** Verify that all screws are tightened, and the crate is stable and free from wobbling.



*Image: Visual guide illustrating the assembly process of the dog crate furniture.*



*Image: Detail of the secure latch mechanism on the crate door.*

## OPERATING INSTRUCTIONS

This dog crate furniture is designed for versatile use, providing a secure space for your pet and a functional surface for your home.

- **For Pet Confinement:** Place a comfortable bed or cushion inside the crate for your dog. Ensure the door is securely latched when your pet is inside. The steel bar windows provide

proper ventilation and prevent odors, creating a comfortable sleeping area.

- **As a Side Table:** The sturdy top surface can be used to place decorative items, books, or beverages. Avoid placing excessively heavy items or hot liquids directly on the surface without protection.
- **Door Orientation:** The door can be mounted to open either to the left or right, adapting to your room layout.



*Image: A dog comfortably inside the crate, demonstrating its use as a pet enclosure.*

## MAINTENANCE

Proper maintenance will extend the life of your dog crate furniture.

- **Cleaning:** Wipe the wooden surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish. For the metal bars, a mild soap solution can be used.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary. Inspect the metal bars for any signs of damage or bending.
- **Pet Bedding:** Regularly clean or replace your pet's bedding inside the crate to maintain hygiene.

## TROUBLESHOOTING

If you encounter any issues with your dog crate furniture, refer to the following common solutions:

Problem	Possible Cause	Solution
Crate is wobbly or unstable.	Loose screws or uneven assembly.	Ensure all screws are fully tightened. Check that the crate is on a level surface. Re-assemble if necessary, paying close attention to alignment.
Door does not close or latch properly.	Misaligned hinges or latch components.	Adjust the hinges or latch to ensure proper alignment. Check for any obstructions.
Wood appears damaged during assembly.	Excessive force during assembly or manufacturing defect.	Avoid overtightening screws. If damage occurs due to a defect, contact customer support.
Pet is uncomfortable or resists using the crate.	Lack of proper introduction or uncomfortable bedding.	Introduce your pet to the crate gradually. Ensure comfortable bedding and familiar toys are inside. Never force your pet into the crate.

## PRODUCT SPECIFICATIONS




Image: Detailed dimensions of the dog crate furniture.

**Brand:** vidaXL

**Model Name:** Dog Crate Furniture Doghouse Kennel Cage Brown Oak Engineered Wood vidaXL

**Model Number:** 838336

**Product Dimensions (L x W x H):** 64.5 cm x 80 cm x 71 cm (25.4 in x 31.5 in x 28 in)

**Material:** Engineered Wood, Metal

**Color:** Brown Oak

**Item Weight:** 29.5 kg

**Number of Doors:** 1

**Special Feature:** Chew Resistant

**Target Species:** Dog

**Recommended Breed Size:** Large

**Included Components:** Stand (Crate structure)

**Country of Origin:** China

## WARRANTY AND SUPPORT

For warranty information, product support, or to order replacement parts, please contact vidaXL customer service. Refer to your purchase documentation for specific contact details or visit the official vidaXL website.

**Online Support:** [Visit the vidaXL Store on Amazon](#)

