

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [KXD](#) /

› [KXD A10 Smartphone User Manual](#)

KXD KXD A10

KXD A10 Smartphone User Manual

Model: KXD A10

1. INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your KXD A10 smartphone. Please read this guide thoroughly to ensure proper use and to maximize the device's capabilities.



Image 1.1: Front and rear view of the KXD A10 Smartphone.

2. WHAT'S IN THE BOX

Verify that all items are present in the package:

- KXD A10 Smartphone
- Adapter
- Quick Start Guide
- Screen Protector (pre-applied or included separately)
- TPU Protective Case

3. SETUP

3.1. SIM Card and Micro SD Card Installation

The KXD A10 supports dual SIM cards and a Micro SD card for expandable storage up to 256GB. Locate the SIM tray on the side of the device.

1. Power off the device before inserting or removing SIM/SD cards.
2. Use the provided SIM ejector tool to open the SIM tray.
3. Place your Nano-SIM card(s) and/or Micro SD card into the designated slots on the tray. Ensure correct orientation.
4. Carefully reinsert the SIM tray into the phone.

3.2. Initial Power On and Basic Configuration

1. Press and hold the Power button until the KXD logo appears.
2. Follow the on-screen prompts to select your language, connect to a Wi-Fi network, and set up your Google account.
3. Configure security features such as Face ID or fingerprint unlock during the initial setup or later in the settings.

4. OPERATING INSTRUCTIONS

4.1. Display and Navigation

The KXD A10 features a 6.6-inch HD+ display with a 20:9 aspect ratio. Navigate the interface using touch gestures.

Extra large screen,

Better Experience

6.6"



6.56 HD+
screen size

720*1600
resolution

20:9
aspect ratio

IPS
Technical IPS

Image 4.1: The 6.6-inch HD+ display of the KXD A10.

4.2. Processor and Memory

The device is equipped with an Octa-core processor and 12GB of RAM (4GB physical + 8GB virtual expansion) for multitasking. It includes 128GB of internal storage, expandable up to 256GB via a Micro SD card.

8(4+4)GB RAM+128GB ROM UP TO 256GB Extension

Enjoy a smoother experience




Image 4.2: Illustration of the KXD A10's memory and storage capabilities.

4.3. Operating System

The KXD A10 runs on Android 13, offering updated features and privacy controls.

Android 13 OS



Image 4.3: Android 13 operating system interface.

4.4. Camera Functions

The smartphone features a 13MP rear camera and an 8MP front camera. AI scene recognition adjusts settings for optimal photo quality.

Keep Every Good Memory

• 13MP Rear Camera •



• 8MP Front Camera •




Image 4.4: Camera specifications and sample photos.

4.5. Battery and Charging

The device is powered by a 4500mAh battery. Use the included adapter for charging. Battery life varies based on usage.

4500 mAh High Capacity Battery

Provides you with long-lasting battery life

4500 mAh




Image 4.5: The 4500mAh high-capacity battery.

4.6. Network and Connectivity

The KXD A10 supports 4G FDD (B2/B4/B5/B7/B12/B28A/B), 3G WCDMA (B2/B5), and 2G GSM (850/900/1800) networks. It is compatible with GSM carriers such as T-Mobile, Speedtalk, and Mint Mobile. It is not compatible with CDMA carriers like AT&T, Cricket Wireless, Verizon, Straight Talk, or U.S. Cellular. Bluetooth connectivity is also available.

5. MAINTENANCE

5.1. General Care

- Keep the device clean using a soft, dry cloth. Avoid harsh chemicals.
- Protect the screen with the included screen protector and the device body with the TPU case.
- Avoid exposing the phone to extreme temperatures, direct sunlight, or moisture.

5.2. Software Updates

Regularly check for and install system updates to ensure optimal performance and security. Navigate to Settings > System > System update.

Note: Some users have reported issues with security updates failing. If you encounter this, please refer to the Troubleshooting section or contact support.

5.3. Battery Longevity

To prolong battery life, avoid fully discharging the battery frequently. Charge the device using the provided adapter.

6. TROUBLESHOOTING

6.1. Common Issues and Solutions

- **Device is slow or lagging:** Close unused applications, clear cache, or restart the phone. Consider reducing the number of installed apps if storage is low.
- **Network connectivity issues:** Ensure your SIM card is correctly inserted and activated. Check network settings (Settings > Network & internet > Mobile network). Verify compatibility with your carrier.
- **Fingerprint sensor not working:** Ensure your finger is clean and dry. Re-register your fingerprints in Settings > Security > Fingerprint.
- **Software updates fail:** Ensure you have a stable internet connection and sufficient storage space. If issues persist, a factory reset may be necessary (back up data first) or contact support.

6.2. Factory Reset

A factory reset will erase all data from your phone and restore it to its original settings. Back up all important data before proceeding. Navigate to Settings > System > Reset options > Erase all data (factory reset).

7. SPECIFICATIONS

Feature	Specification
Model Name	KXD A10
Operating System	Android 13
Processor	Octa-Core, 1.6 GHz
RAM	4 GB (expandable to 12 GB virtual RAM)
Internal Storage	128 GB
Expandable Storage	Up to 256 GB (Micro SD)
Screen Size	6.6 Inches HD+
Rear Camera	13 MP
Front Camera	8 MP
Battery Capacity	4500 mAh

Feature	Specification
Network Support	4G FDD (B2/B4/B5/B7/B12/B28A/B), 3G WCDMA (B2/B5), 2G GSM (850/900/1800)
Connectivity	Bluetooth, Cellular
Special Features	Dual SIM, Fingerprint Sensor, Face ID, Built-In GPS
Dimensions	6.5 x 2.99 x 0.33 inches
Weight	6.9 ounces (195 grams)
Audio Jack	3.5 mm

8. WARRANTY AND SUPPORT

8.1. Warranty Information

For specific warranty details, please refer to the warranty card included with your product or contact KXD customer support directly. Warranty terms typically cover manufacturing defects for a specified period from the date of purchase.

8.2. Customer Support

If you encounter issues not covered in this manual or require further assistance, please contact KXD customer support through their official website or the contact information provided in your product packaging.