

ROOMTEC W-B10400523D

ROOMTEC Glass Display Cabinet User Manual

Model: W-B10400523D

1. INTRODUCTION

Thank you for choosing the ROOMTEC Glass Display Cabinet. This manual provides essential information for the safe assembly, operation, and maintenance of your new display cabinet. Please read these instructions thoroughly before beginning assembly and retain them for future reference.

This elegant display cabinet features tempered glass panels and sturdy particle board construction, designed to showcase your valuable collections, such as jewelry, bags, shoes, figurines, books, wine, and whisky. Its double-door design and three spacious shelves offer ample storage and display opportunities for various items in your living room, bedroom, office, or collection room.



Image 1.1: The ROOMTEC Glass Display Cabinet, elegantly displaying various items in a home environment.

2. SAFETY INSTRUCTIONS

Your safety is paramount. Please adhere to the following safety guidelines:

- **Two-Person Assembly:** Assembly requires at least two adults. Do not attempt to assemble alone due to the weight and fragility of the glass components.
- **Handle Glass with Care:** All glass panels are tempered for safety, but they can still break if mishandled or subjected to sharp impacts. Wear protective gloves during assembly.
- **Anti-Tipping Device:** Always secure the cabinet to the wall using the provided anti-tipping device. This prevents accidental tipping, especially in households with children or pets.
- **Weight Limits:** Do not exceed the maximum weight capacity for each shelf or the overall cabinet. Refer to the "Specifications" section for detailed weight limits.
- **Stable Surface:** Place the cabinet on a flat, level, and stable surface to ensure proper balance and prevent wobbling. Use the adjustable feet to level the cabinet if necessary.

- **Avoid Overloading:** Distribute weight evenly across shelves. Avoid placing heavy items on the top of the cabinet.
- **Moving the Cabinet:** Once assembled and filled, the cabinet is very heavy. If relocation is necessary, empty the cabinet first and move it carefully with assistance to prevent damage or injury.




Image 2.1: Key safety and installation features of the display cabinet.

3. PACKAGE CONTENTS

Before assembly, verify that all parts are present and undamaged. If any parts are missing or damaged, please contact customer support immediately.

- Tempered Glass Panels (Side, Back, Doors, Shelves)
- Top and Bottom Particle Board Panels
- Adjustable Base Feet
- Hardware Kit (Screws, Hinges, Locks, Anti-tipping device, Shelf supports)

- Assembly Tools (Hex key, Screwdriver - may be included or required)
- Instruction Manual (This document)

4. SETUP AND ASSEMBLY

Follow these steps carefully for proper assembly. It is highly recommended to have two people for this process.

1. **Prepare the Area:** Choose a clean, flat, and spacious area for assembly. Lay down a soft blanket or cardboard to protect the glass panels and your floor.
2. **Attach Base Feet:** Secure the adjustable base feet to the bottom particle board panel using the provided screws. Ensure they are tightened securely.
3. **Assemble Frame:** Attach the side glass panels to the bottom panel, followed by the back glass panels. Use the designated connectors and screws to create the basic frame.
4. **Install Shelves:** Insert the shelf supports into the pre-drilled holes at your desired heights. Carefully place the tempered glass shelves onto the supports.
5. **Attach Top Panel:** Place the top particle board panel onto the assembled frame, securing it with the appropriate hardware.
6. **Install Doors:** Attach the hinges to the glass doors and then to the cabinet frame. Adjust the hinges to ensure the doors align properly and close smoothly.
7. **Install Lock:** If your model includes a lock, install it according to the instructions in the hardware kit.
8. **Level the Cabinet:** Once fully assembled, adjust the base feet to ensure the cabinet is perfectly level and stable on your floor.
9. **Secure to Wall:** Attach the anti-tipping device to the top rear of the cabinet and secure it firmly to a wall stud using appropriate wall anchors (not always included, depending on wall type). This step is crucial for safety.

Note: Some users have reported that the instructions can be challenging. If you encounter difficulties, refer to the provided diagrams carefully or seek assistance from the seller if a video guide is available.



HD Explosion-proof Glass

Image 4.1: The cabinet features HD Shatter-proof Glass for enhanced safety and durability.

5. OPERATING THE CABINET

Using your ROOMTEC Glass Display Cabinet is straightforward:

- **Opening/Closing Doors:** Gently pull the handles to open the double doors. Push them firmly to close. Ensure they latch properly.
- **Locking Mechanism:** If your cabinet has a lock, insert the key and turn to lock or unlock the doors. Remove the key after locking to prevent loss.
- **Adjusting Shelves:** To change shelf height, carefully remove items from the shelf, lift the glass shelf, reposition the shelf supports to desired holes, and then place the shelf back.
- **Displaying Items:** Arrange your items on the shelves, ensuring even weight distribution and adherence to weight limits. The glass doors help protect your collections from dust.



Image 5.1: The cabinet is versatile for displaying various items, such as handbags in a bedroom setting.

6. MAINTENANCE AND CARE

Proper care will ensure the longevity and appearance of your display cabinet:

- **Cleaning Glass:** Use a soft, lint-free cloth and a glass cleaner (ammonia-free recommended) to clean glass surfaces. Spray cleaner onto the cloth, not directly onto the glass, to avoid streaks and protect the wood panels.
- **Cleaning Wood Panels:** Wipe wood particle board panels with a soft, damp cloth. Avoid abrasive cleaners or excessive moisture.
- **Dusting:** Regularly dust the interior and exterior surfaces to maintain clarity and cleanliness.
- **Hardware Check:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight may cause fading or damage to the wood panels.

- **Temperature and Humidity:** Maintain a stable room temperature and humidity level to prevent warping or damage to the materials.

7. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

Problem	Possible Cause	Solution
Cabinet is wobbly/unstable.	Uneven floor; loose base feet; not secured to wall.	Adjust the base feet until the cabinet is level. Ensure all screws are tightened. Secure the cabinet to the wall using the anti-tipping device.
Doors do not align or close properly.	Hinges are loose or misaligned; cabinet is not level.	Check and adjust the hinges. Ensure the cabinet is level.
Small gaps between doors or panels.	Minor manufacturing tolerance; assembly not perfectly flush.	This can be a minor aesthetic issue. Ensure all connections are as tight as possible. While minimal gaps may exist, they typically do not affect functionality.
Glass shattered during assembly.	Improper handling; excessive force; defect.	Immediately stop assembly. Carefully clean up all glass shards. Contact customer support for replacement parts.

If you encounter issues not listed here, or if the suggested solutions do not resolve the problem, please contact ROOMTEC customer support for assistance.

8. SPECIFICATIONS

Feature	Detail
Model Number	W-B10400523D
Dimensions (H x W x D)	125.7 cm x 80.7 cm x 36.5 cm (approx. 49.5" H x 31.7" W x 14.3" D)
Material	Tempered Glass, Solid Wood Particle Board
Glass Thickness	5 mm
Number of Shelves	3 (adjustable)
Shelf Weight Capacity (each)	7.3 kg (approx. 16 lbs)

Feature	Detail
Top/Bottom Plate Weight Capacity (each)	38.1 kg (approx. 84 lbs)
Adjustable Feet Weight Capacity	Up to 90.7 kg (approx. 200 lbs)
Features	Double Doors, Lockable, Adjustable Base Stand, Anti-Tipping Device
Product Weight	48.1 kg (approx. 106 lbs)



Image 8.1: Detailed dimensions and shelf weight capacity of the display cabinet.

9. WARRANTY AND SUPPORT


ROOMTEC products are designed for quality and durability. For information regarding warranty coverage, please refer to the purchase documentation or contact your retailer.


If you have any questions, require assistance with assembly, or need replacement parts, please contact ROOMTEC customer support. Provide your model number (W-B10400523D) and purchase details for faster service.

Customer Support Contact: Please refer to the contact information provided with your purchase or visit the official ROOMTEC website for support details.

© 2024 ROOMTEC. All rights reserved.

Related Documents - W-B10400523D

 <p>RoomTec Operation Manual RoomTec App Download Method Instructions</p> <p>IOS Download</p> <ol style="list-style-type: none">Open the App Store on your iPhone.Search for the RoomTec App.Once you tap the RoomTec App, click Get and confirm the download.After the download is complete, click the icon to open the RoomTec App and start operating.	<p>RoomTec App Operation Manual and User Guide</p> <p>A comprehensive guide to downloading, installing, and using the RoomTec App for sleep monitoring and health tracking. Covers app setup, device binding, Wi-Fi configuration, sleep data analysis, and account management.</p>
 <p>Chicken Coop Run Instruction Manual</p> <p>For Specification: 5'Wx11'3"lx6'4'H (154*349*193.5cm)</p> <p>Note: If you encounter any problem with the installation, Please Contact ROOMTEC Installation Help, Missing or Replace parts, please contact our customer service. ROOMTEC, we will solve for you as soon as possible.</p> <p>W1: (000)03.3709 (inch) W1: (000)03.3709 (inch) E1: (000)03.3709 (inch) E1: (000)03.3709 (inch)</p>	<p>Chicken Coop Run Assembly and Instruction Manual</p> <p>Comprehensive guide for assembling a ROOMTEC Chicken Coop Run, featuring a detailed parts list, step-by-step visual instructions translated into text, and after-sales service information.</p>
 <p>41" Furniture Style Large Dog Crate Instruction Manual</p> <p>41" Furniture Style Large Dog Crate</p> <p>11: [000]20.31.09 (inch) W1: 9.05cm E1: 5.05cm (inch) E1: 5.05cm (inch)</p>	<p>41" Furniture Style Large Dog Crate Instruction Manual</p> <p>This manual provides step-by-step instructions for assembling the 41" Furniture Style Large Dog Crate. It includes a parts list, assembly steps with diagrams, and guidelines for measuring your dog to determine the correct feeding tray height.</p>

 <p>Rectangle LED Bathroom Mirror Manual</p> <p>Customer Service: 1800 000 1000 (M-F 9AM-5PM) Email: TechSupport@RoomTec.com Address: 100 Parker Ave, Commerce, GA 30029</p>	<p>ROOMTEC LED Bathroom Mirror: Installation, Operation, and Safety Manual</p> <p>Comprehensive guide for ROOMTEC LED bathroom mirrors, covering installation, electrical safety, operation modes (dimming, fog-free, human body detection), specifications, and cleaning. Includes contact information and product details.</p>
 <p>Bypass Barn Door Hardware Instruction Manual - ROOMTEC 2-DOOR I-Shape 12ft</p>	<p>Bypass Barn Door Hardware Instruction Manual - ROOMTEC 2-DOOR I-Shape 12ft</p> <p>Comprehensive instruction manual for installing the ROOMTEC Bypass Barn Door Hardware system, featuring a 2-DOOR I-Shape 12ft configuration. Includes parts list, tools needed, step-by-step installation guides, and safety warnings.</p>
 <p>LED Wall-mounted Mirror Manual</p>	<p>RoomTec LED Wall-mounted Mirror: Installation and User Manual</p> <p>Comprehensive guide for installing and maintaining the RoomTec LED Wall-mounted Mirror, featuring anti-fog, dimming, and adjustable light color. Includes safety instructions, specifications, and step-by-step installation.</p>