

[Manuals.plus](#) /

› [TENGA](#) /

› TENGAF LIP ORB Ocean Blue Reusable Toy Instruction Manual

TENGA TFO-003

TENGA FLIP ORB Ocean Blue Instruction Manual

Model: TFO-003

PRODUCT OVERVIEW

The TENGAF LIP ORB Ocean Blue is a reusable male masturbator designed for enhanced sensations. It features firm orbs and wavy ribs within its internal structure. Its fully waterproof design ensures easy cleaning and maintenance.



Image: The internal texture of the TENGAF LIP ORB Ocean Blue, highlighting the wavy ribs and orbs for entwining sensations.

Key features include:

- **Enhanced Internal Structure:** Features firm orbs and wavy ribs for varied sensations.
- **Reusable Design:** Constructed from durable elastomer material for long-lasting use.
- **Fully Waterproof:** Allows for thorough and easy cleaning.
- **Unique Flip-Open Mechanism:** Designed for convenient cleaning and drying.

SETUP

1. **Unboxing:** Carefully remove the TENGAF LIP ORB from its packaging.
2. **Initial Cleaning:** Before first use, open the device and rinse both halves thoroughly with lukewarm water and a mild, pH-neutral soap. Ensure all surfaces are clean.
3. **Drying:** Allow the device to air dry completely. The cap can be used as a stand for hygienic drying.
4. **Lubrication:** Apply a generous amount of water-based lubricant to the internal surfaces of the FLIP ORB and to yourself for optimal comfort and experience. The product typically includes single-use lubricant packets.

OPERATING INSTRUCTIONS

The TENGAF LIP ORB is designed for intuitive use. Follow these steps for operation:

1. **Prepare the Device:** Ensure the FLIP ORB is clean and adequately lubricated as described in the Setup section.
2. **Close the Device:** Securely close the two halves of the FLIP ORB until the latch clicks into place.
3. **Usage:** Insert and use the device as desired. The internal orbs and wavy ribs provide varied sensations. You can adjust the intensity by applying gentle pressure to the exterior of the device.
4. **Post-Use:** After use, proceed to the Maintenance and Cleaning section immediately.

FLIP ORB

OCEAN BLUE



Image: A hand holding the Tenga FLIP ORB Ocean Blue, demonstrating its ergonomic design for use.

MAINTENANCE AND CLEANING

Proper cleaning and maintenance are crucial for the longevity and hygiene of your Tenga FLIP ORB.

1. **Open the Device:** Unlatch and open the FLIP ORB completely.
2. **Rinse:** Rinse both internal and external surfaces thoroughly with lukewarm running water.
3. **Clean with Soap:** Apply a small amount of mild, pH-neutral soap to a soft cloth or your fingers and gently clean all textured areas.
4. **Rinse Again:** Rinse thoroughly to remove all soap residue.
5. **Dry:** Shake off excess water. Use a clean, lint-free cloth to pat dry the exterior. For the interior, allow it to air dry completely in an open position. The cap can serve as a stand to facilitate drying.

6. **Storage:** Once completely dry, close the device and store it in a clean, dust-free environment away from direct sunlight and extreme temperatures.



Image: The TENGA FLIP ORB Ocean Blue open and being rinsed under running water, demonstrating its waterproof design for easy cleaning.

SPECIFICATIONS

Feature	Detail
Model Number	TFO-003
Brand	TENGA
Color	Ocean Blue
Material	Elastomer
Product Dimensions	2.79 x 3.38 x 7 inches
Item Weight	15.38 ounces
Waterproof	Yes

TROUBLESHOOTING

If you encounter any issues with your TENGA FLIP ORB, refer to the common problems and solutions below:

- **Device does not close securely:**
 - Ensure both halves are properly aligned before attempting to close.
 - Check for any debris or foreign objects obstructing the latch mechanism.
 - Apply gentle, even pressure until you hear a click, indicating it is latched.
- **Lubricant or fluids leak during use:**
 - Ensure the device is completely closed and latched before use.
 - Verify that the silicone material is correctly seated within the hard plastic shell.
 - Use an appropriate amount of lubricant; excessive lubricant might be forced out.
- **Reduced sensation or discomfort:**
 - Ensure sufficient water-based lubricant is applied before and during use.
 - Experiment with different pressures on the device exterior to find your preferred intensity.
 - Confirm the device is clean and free from any residue that might affect sensation.

If problems persist, contact TENGA customer support for further assistance.

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the official TENGA website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

You can visit the TENGA Store for more information: [TENGA Official Store](#)