

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [Blackview](#) /

> [Blackview Active 8 Pro 10.36-inch Rugged Tablet User Manual](#)

## Blackview ACTIVE 8 PRO

# Blackview Active 8 Pro Rugged Tablet User Manual

Model: ACTIVE 8 PRO

## INTRODUCTION

---

Welcome to the user manual for your Blackview Active 8 Pro Rugged Tablet. This device is engineered for durability and performance, designed to withstand challenging environments while providing a robust computing experience. Featuring a 10.36-inch display, a powerful MediaTek Helio G99 Octa-core processor, and a massive 22000mAh battery, the Active 8 Pro is built for extended use and demanding tasks. It is MIL-STD-810H certified and boasts IP68 & IP69K waterproof ratings, ensuring resilience against water, dust, and drops.

This manual provides essential information on setting up, operating, maintaining, and troubleshooting your tablet to ensure optimal performance and longevity.



Image: Front view of the Blackview Active 8 Pro Rugged Tablet, showcasing its display and robust bezel.

## PACKAGE CONTENTS

---

Please verify that all items are present in your product package:

- Blackview Active 8 Pro Rugged Tablet
- Padded Leather Strap
- Charging Cable
- Power Adapter
- SIM Ejector Tool (if applicable)
- Quick Start Guide

## DEVICE LAYOUT

---

Familiarize yourself with the physical components and ports of your Active 8 Pro tablet.



Image: Front view of the Blackview Active 8 Pro tablet, highlighting the display and front camera location.



Image: Rear view of the Blackview Active 8 Pro tablet, showing the camera module, speaker grilles, and the attached padded leather strap for secure handling.



Image: Angled rear view of the Blackview Active 8 Pro tablet, providing a perspective of its ruggedized corners and the ergonomic padded leather strap.

## SETUP

---

### 1. Charging the Device

Before first use, fully charge your Active 8 Pro tablet. Connect the provided charging cable to the tablet's charging port and the power adapter to a wall outlet. The tablet supports 33W fast charging for quick power replenishment.

- Use only the original Blackview charger and cable to ensure optimal charging speed and safety.
- A charging indicator will appear on the screen.

### 2. Powering On/Off

- **To Power On:** Press and hold the Power button (typically located on the side) until the Blackview logo appears on

the screen.

- **To Power Off:** Press and hold the Power button until a power menu appears. Select "Power off" from the options.
- **To Restart:** From the power menu, select "Restart".

### 3. Initial Configuration

Upon first power-on, the tablet will guide you through the initial setup process. Follow the on-screen prompts to:

- Select your language.
- Connect to a Wi-Fi network.
- Sign in with your Google account or create a new one.
- Set up screen lock (PIN, pattern, password, or fingerprint).
- Review and accept terms and conditions.

## OPERATING INSTRUCTIONS

---

### 1. Basic Navigation

Your Active 8 Pro runs on Android 14, offering an intuitive user interface. Use standard touchscreen gestures:

- **Tap:** Select an item or open an app.
- **Tap & Hold:** Access contextual menus or move icons.
- **Swipe:** Scroll through pages, lists, or switch between home screens.
- **Pinch-to-Zoom:** Zoom in or out on images and web pages.

### 2. Connectivity

- **Wi-Fi:** Go to Settings > Network & internet > Wi-Fi to connect to available networks. The tablet supports 802.11ac, 802.11ax, 802.11g, and 802.11n standards.
- **Bluetooth:** Go to Settings > Connected devices > Connection preferences > Bluetooth to pair with Bluetooth accessories like headphones or speakers.
- **Mobile Data (if applicable):** Insert a SIM card into the designated slot to access mobile data services.

### 3. Camera Usage

The tablet features a 48 MP rear camera. Open the Camera app to capture photos and videos. Tap on the screen to focus, and use the on-screen shutter button to take a picture.

### 4. Audio Enhancement

Experience enhanced audio quality with Sound By Harman AudioEFX. Adjust audio settings in the tablet's sound preferences to optimize your listening experience for music, movies, or calls.

### 5. Using the Padded Leather Strap

The included padded leather strap is designed to provide extra grip and comfort, reducing hand fatigue during extended use. Securely attach the strap to the designated points on the back of the tablet. Adjust for a snug fit that allows for comfortable one-handed or two-handed holding.

## MAINTENANCE

---

### 1. Cleaning Your Tablet

- Use a soft, lint-free cloth to wipe the screen and body of the tablet.
- For stubborn dirt, slightly dampen the cloth with water or a screen-safe cleaning solution.
- Avoid using harsh chemicals, abrasive materials, or excessive moisture, especially near ports.
- Ensure all port covers are securely closed before cleaning if exposing to water.

## 2. Storage

When not in use for extended periods, store your tablet in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the battery is charged to approximately 50% before long-term storage to preserve battery health.

## 3. Software Updates

Regularly check for and install software updates to ensure your tablet has the latest features, security patches, and performance improvements. Go to Settings > System > System update to check for available updates.

## TROUBLESHOOTING

---

This section addresses common issues you might encounter with your Blackview Active 8 Pro tablet.

- **Device Not Powering On:**

Ensure the tablet is sufficiently charged. Connect it to the charger for at least 30 minutes before attempting to power it on again. If it still doesn't power on, try holding the power button for 10-15 seconds to force a restart.

- **Screen Unresponsive or Display Issues:**

If the screen becomes unresponsive, try restarting the device. If the display fails or shows abnormalities, ensure the tablet has not sustained severe physical damage. Contact customer support if the issue persists after a restart.

- **Charging Problems:**

Verify that the charging cable and adapter are securely connected and undamaged. Try using a different compatible charger and cable if available. Ensure the charging port is free of debris.

- **Wi-Fi/Bluetooth Connectivity Issues:**

Toggle Wi-Fi or Bluetooth off and on. Restart your tablet and the router/Bluetooth device. Ensure you are within range and have the correct password for Wi-Fi networks.

- **Slow Performance:**

Close unnecessary background applications. Clear cache data for apps that are frequently used. Consider performing a factory reset as a last resort (back up your data first).

## SPECIFICATIONS

---

Feature	Specification
Model Name	Active 8 Pro
Display Size	10.36 Inches
Screen Resolution	1920 x 1080 pixels
Processor	MediaTek Helio G99 Octa-core (2.2 GHz)

Feature	Specification
RAM	8 GB (DDR4 SDRAM)
Internal Storage	256 GB
Operating System	Android 14
Battery Capacity	22000mAh
Fast Charging	33W Support
Durability Ratings	MIL-STD-810H Certified, IP68 & IP69K Waterproof
Screen Protection	Corning Gorilla Glass 5
Rear Camera	48 MP
Wireless Connectivity	802.11ac, 802.11ax, 802.11g, 802.11n
Dimensions (LxWxH)	10.09 x 6.53 x 0.66 inches
Item Weight	3.34 pounds

## WARRANTY AND SUPPORT

---

Your Blackview Active 8 Pro tablet comes with a limited warranty. Please refer to the warranty card included in your package for specific terms and conditions, including coverage duration and limitations. Keep your proof of purchase for warranty claims.

For technical support, service, or warranty inquiries, please visit the official Blackview support website or contact their customer service department. Contact information can typically be found on the Blackview website or in the documentation provided with your product.

For more information, you can visit the [Blackview Store on Amazon](#).