

[Manuals.plus](#) /

› [JOYROOM](#) /

› JOYROOM JR-OE2 Wireless Open-Ear Headphones User Manual

JOYROOM JR-OE2

JOYROOM JR-OE2 Wireless Open-Ear Headphones User Manual

Model: JR-OE2

1. PRODUCT OVERVIEW

The JOYROOM JR-OE2 Wireless Open-Ear Headphones are designed for comfortable listening while maintaining awareness of your surroundings. These headphones feature an open-ear design and connect wirelessly via Bluetooth, offering a convenient audio experience for various activities.

2. PACKAGE CONTENTS

Please check the package for the following items:

- JOYROOM JR-OE2 Wireless Open-Ear Headphones (Left and Right)
- Charging Case
- USB Charging Cable
- User Manual



Image: The complete package contents for the JR-OE2 headphones, showing the headphones, their charging case, a USB charging cable, and the instruction manual.

3. PRODUCT DIAGRAM

Familiarize yourself with the components of your JR-OE2 headphones and charging case.



Image: A front view of the JR-OE2 headphones, highlighting their open-ear design and ear-hook structure.



Image: The JR-OE2 headphones resting in their charging case, with the case lid open, revealing the charging ports for each earbud.



Image: A top-down perspective of the JR-OE2 headphones securely placed within their open charging case.

4. SETUP

4.1 Charging the Headphones and Case

Before first use, fully charge the headphones and the charging case.

1. Place the headphones into the charging case, ensuring they are correctly seated.
2. Connect the USB charging cable to the charging port on the case and to a compatible USB power source (e.g., computer, wall adapter).
3. The indicator lights on the case and/or headphones will show the charging status. Refer to the specific light patterns in your detailed manual for full information.
4. Once fully charged, disconnect the charging cable.



Image: The JR-OE2 headphones positioned within their charging case, illustrating how they connect for charging.

4.2 Bluetooth Pairing

To connect your JR-OE2 headphones to a device:

1. Ensure the headphones are charged.
2. Open the charging case. The headphones will automatically enter pairing mode (indicator lights will flash, typically blue and red).
3. On your device (smartphone, tablet, etc.), go to the Bluetooth settings.
4. Search for available devices and select "JOYROOM JR-OE2" from the list.
5. Once connected, the indicator lights on the headphones will typically stop flashing or show a steady blue light.
6. If pairing fails, turn off Bluetooth on your device, close the case, wait a few seconds, then reopen the case and try again.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- **Power On:** Open the charging case, and the headphones will power on automatically.
- **Power Off:** Place the headphones back into the charging case and close the lid. They will power off automatically.

5.2 Music Control

The headphones feature touch controls for music playback:

- **Play/Pause:** Single tap on either headphone.
- **Next Track:** Double tap on the right headphone.
- **Previous Track:** Double tap on the left headphone.

5.3 Call Control

Manage your calls with simple touch gestures:

- **Answer/End Call:** Single tap on either headphone.
- **Reject Call:** Press and hold on either headphone for 2 seconds.

5.4 Volume Control

Volume control is typically managed via your connected device. Some models may support direct volume adjustment on the headphones; refer to the detailed manual for specific instructions if available.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the headphones and charging case. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the headphones in their charging case to protect them and keep them charged.
- **Avoid Water:** The headphones are not waterproof. Avoid exposure to water or excessive moisture.
- **Temperature:** Store and operate the headphones within recommended temperature ranges to prevent damage.

7. TROUBLESHOOTING

Problem	Solution
Headphones do not power on.	Ensure the headphones and charging case are fully charged. Place headphones in the case and close the lid, then reopen.
Cannot pair with device.	• Ensure Bluetooth is enabled on your device. • Make sure the headphones are in pairing mode (open case). • Forget "JOYROOM JR-OE2" from your device's Bluetooth list and try pairing again. • Move closer to your device.
No sound or low volume.	• Check the volume level on both the headphones and your connected device. • Ensure the headphones are properly connected to your device. • Try playing different audio.
One headphone has no sound.	Place both headphones back into the charging case, close the lid, wait a few seconds, then reopen to reset the connection.

8. SPECIFICATIONS

- **Model Number:** 70464 (JR-OE2)
- **Brand:** JOYROOM

- **Connectivity:** Wireless (Bluetooth)
- **Control Type:** Volume Control (via connected device)
- **Material:** Faux Leather
- **Components Included:** 1 package (Headphones, Charging Case, Cable, Manual)
- **Age Range Description:** Adult
- **Country of Origin:** China
- **International Article Code (EAN/UPC):** 06956116779313

9. WARRANTY AND SUPPORT

The JOYROOM JR-OE2 Wireless Open-Ear Headphones come with a **2-year manufacturer's warranty**. For warranty claims, technical support, or further assistance, please contact your retailer or visit the official JOYROOM website.

Please retain your proof of purchase for warranty purposes.