Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl KP72A-120400

onerbl AC/DC Adapter User Manual

Compatible with Homedics MCS-1010HJ Massage Cushion (Model KP72A-120400)

Introduction

This manual provides essential information for the safe and effective use of your onerbl AC/DC Adapter. This adapter is designed to be compatible with devices such as the Homedics MCS-1010HJ Total Recline Shiatsu Massage Cushion Chair and other devices requiring a 12V 4A power supply, specifically model KP72A-120400. Please read these instructions carefully before use and retain them for future reference.

Product Overview

The onerbl AC/DC Adapter is a replacement power supply unit designed to provide stable and reliable power to compatible electronic devices. It consists of an adapter unit and a detachable AC power cord.



Image: The onerbl AC/DC Adapter unit connected to its power cord, ready for use.



Image: The detachable AC power cord, which connects the adapter to a wall outlet.

Specifications

- **Input Voltage:** AC 100-240V, 50/60Hz (Worldwide AC Input)
- **Output Voltage/Current:** 12V 4A (Compatible with devices requiring 12V 4A, such as Homedics KP72A-120400)
- **Protection Features:**
  - Over Voltage Protection
  - Over Heat Protection
  - Short-Circuit Protection
  - Over-Current Protection
- **Adapter Unit Dimensions (Approximate):** 4.2 inches (Length) x 1.8 inches (Width) x 1.2 inches (Height)
- **Total Cable Length (Approximate):** 127.8 inches (including AC and DC cords)
- **AC Power Cord Length (Approximate):** 79.3 inches
- **DC Output Cord Length (Approximate):** 44.3 inches
- **Material:** Copper Wire, PVC Jacket




Image: Detailed dimensions of the adapter unit and its connected cables.



Image: Visual representation of the adapter's built-in safety features, including short-circuit, over-voltage, and over-current protection.



Image: Illustration highlighting the durable construction of the cable, featuring copper wire and a PVC jacket for enhanced longevity.

Setup

1. **Verify Compatibility:** Ensure your device requires a 12V 4A power supply and is compatible with the KP72A-120400 model. Check your device's original adapter or specifications.
2. **Connect AC Cord:** Plug the detachable AC power cord into the adapter unit. Ensure it is firmly seated.
3. **Connect to Device:** Insert the DC output plug of the adapter into the power input port of your Homedics massage cushion or other compatible device.
4. **Connect to Power Outlet:** Plug the AC power cord into a standard wall electrical outlet (100-240V).
5. **Power On:** Once connected, the adapter is ready to supply power. Turn on your device as per its own instructions.



Image: The adapter properly connected to a wall outlet and a device, indicating it is in use.

Operating

Once properly connected, the adapter will continuously supply power to your device. Observe the following guidelines for optimal operation:

- Ensure the adapter is placed in a well-ventilated area to prevent overheating.
- Avoid covering the adapter with cloths or other materials during operation.
- Do not expose the adapter to water, moisture, or extreme temperatures.
- If the adapter feels excessively hot to the touch, disconnect it immediately and allow it to cool before further use.

Maintenance

- **Cleaning:** Disconnect the adapter from the power outlet and your device before cleaning. Use a dry, soft cloth to wipe the surface. Do not use liquid cleaners or abrasive materials.

- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and moisture. Avoid tightly coiling the cables to prevent damage.
- **Inspection:** Periodically inspect the adapter and cables for any signs of damage, such as frayed wires, cracks, or bent pins. If damage is found, discontinue use and replace the adapter.

Troubleshooting

Problem	Possible Cause	Solution
Device not powering on	• Adapter not properly connected. • Power outlet is not active. • Device power switch is off. • Adapter is faulty.	• Ensure all connections (AC cord to adapter, adapter to device, AC cord to wall) are secure. • Test the power outlet with another device. • Verify the device's power switch is in the 'ON' position. • If issues persist, the adapter may need replacement.
Adapter feels warm	Normal operation.	Slight warmth during operation is normal. Ensure adequate ventilation around the adapter. If it becomes excessively hot or emits smoke/smell, disconnect immediately.
Adapter light not on	• No power to adapter. • Adapter malfunction.	• Check power connections and wall outlet. • If connections are secure and outlet is active, the adapter may be faulty.

Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your purchase or contact the seller directly. Keep your purchase receipt as proof of purchase.

© 2023 onerbl. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CPPNN6PF

More documents and user manuals: **https://manuals.plus/**