

[manuals.plus](#) /

- › [Vontar](#) /
- › [Vontar X3 S905X3/4GB/32GB Android 9.0 Android TV Box User Manual](#)

Vontar X3 S905X3/4GB/32GB

Vontar X3 S905X3/4GB/32GB Android TV Box User Manual

Model: X3 S905X3/4GB/32GB

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Vontar X3 S905X3/4GB/32GB Android TV Box. Please read this manual thoroughly before using the device to ensure proper functionality and to maximize your user experience. Keep this manual for future reference.

2. PRODUCT OVERVIEW

The Vontar X3 S905X3/4GB/32GB is an Android TV Box designed to transform your television into a smart entertainment hub. It runs on Android 9.0 and features a powerful S905X3 processor, 4GB of RAM, and 32GB of internal storage, providing a smooth and responsive user experience for streaming, gaming, and app usage.




Figure 2.1: The Vontar X3 Android TV Box shown alongside its included remote control. The TV box features a sleek, dark design with a prominent 'V' logo on top, while the remote is a standard black infrared type with navigation and media control buttons.



Figure 2.2: A front-angle view of the Vontar X3 Android TV Box, highlighting its digital display which shows the current time (08:58) and Wi-Fi status. The device has a dark, glossy finish with an illuminated 'V' logo and subtle golden accents.

Package Contents:

- Vontar X3 S905X3/4GB/32GB Android TV Box
- Remote Control
- Power Adapter

- HDMI Cable
- User Manual

3. SETUP GUIDE

3.1 Connecting the Device

1. **Connect to TV:** Insert one end of the HDMI cable into the HDMI port on the Vontar X3 TV Box and the other end into an available HDMI input on your television.
2. **Connect to Power:** Plug the power adapter into the DC IN port on the TV Box, then plug the adapter into a wall outlet. The device should power on automatically or can be turned on using the power button on the remote.
3. **Connect to Network (Optional):**
 - **Wi-Fi:** Once the device is powered on, navigate to the 'Settings' menu, select 'Network & Internet', and choose your Wi-Fi network. Enter the password if prompted.
 - **Ethernet:** For a wired connection, connect an Ethernet cable from your router to the LAN port on the TV Box. The device will automatically detect the wired connection.



Figure 3.1: Rear view of the Vontar X3 Android TV Box, showing various ports including HDMI, Ethernet (LAN), and DC power input. These ports are essential for connecting the device to a television and power source.



Figure 3.2: Side view of the Vontar X3 Android TV Box, displaying additional connectivity options such as USB ports (one

3.2 Initial Boot-up

After connecting all necessary cables, switch your TV's input source to the corresponding HDMI port. The Vontar X3 TV Box will display the boot-up screen. Follow any on-screen prompts for initial setup, such as language selection and Google account login.

4. OPERATING INSTRUCTIONS

4.1 Remote Control Functions

The included remote control allows you to navigate the Android TV interface and control media playback. Familiarize yourself with the main buttons:

- **Power Button:** Turns the device on or off.
- **Navigation Pad (Up/Down/Left/Right):** Moves the cursor or selection.
- **OK Button:** Confirms selection or opens an item.
- **Back Button:** Returns to the previous screen.
- **Home Button:** Returns to the main home screen.
- **Volume Buttons:** Adjusts the audio volume.
- **Menu Button:** Accesses context-sensitive menus.

4.2 Navigating the Android 9.0 Interface

The Vontar X3 runs on Android 9.0, offering a user-friendly interface. Use the remote's navigation pad to browse through apps, settings, and content. The home screen typically displays frequently used apps, recommended content, and quick access to settings.

4.3 Installing and Uninstalling Applications

- **Installing Apps:** Access the Google Play Store from the home screen. Search for desired applications and select 'Install'.
- **Uninstalling Apps:** Go to 'Settings' > 'Apps'. Select the app you wish to uninstall and choose 'Uninstall'.

4.4 Media Playback

The device supports various media formats. You can play media from:

- **Streaming Services:** Install apps like Netflix, YouTube, Hulu, etc., from the Google Play Store.
- **Local Storage:** Connect a USB drive or MicroSD card to play media files directly. Use a file manager or media player app.
- **Network Storage:** Access media files from network-attached storage (NAS) or shared folders on your local network.

5. MAINTENANCE

5.1 Cleaning the Device

To clean the Vontar X3 TV Box, use a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as

they may damage the device's finish or internal components.

5.2 Software Updates

Periodically check for software updates to ensure optimal performance and access to the latest features. Go to 'Settings' > 'Device Preferences' > 'About' > 'System update'.

5.3 Factory Reset

If you encounter persistent issues, a factory reset may resolve them. **Warning:** A factory reset will erase all data, settings, and installed applications. Go to 'Settings' > 'Device Preferences' > 'Reset'. Confirm your choice when prompted.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your Vontar X3 TV Box.

Problem	Possible Cause	Solution
No power	Power adapter not connected; Power outlet not working; Device faulty.	Ensure power adapter is securely connected to the device and a working power outlet. Try a different outlet.
No signal on TV	Incorrect HDMI input selected; HDMI cable loose or faulty; TV Box not powered on.	Select the correct HDMI input on your TV. Check HDMI cable connections. Ensure the TV Box is powered on.
Wi-Fi not connecting	Incorrect Wi-Fi password; Router issues; Device too far from router.	Verify Wi-Fi password. Restart your router. Move the TV Box closer to the router or use an Ethernet cable.
Remote control not working	Batteries drained; Obstruction between remote and device; Remote not paired (if Bluetooth).	Replace batteries. Ensure no obstructions. If it's a Bluetooth remote, re-pair it via settings.
Apps crashing or freezing	Insufficient memory; App specific issue; Software glitch.	Close background apps. Clear app cache/data (Settings > Apps). Restart the device. Perform a factory reset if issues persist.

7. SPECIFICATIONS

The following are the technical specifications for the Vontar X3 S905X3/4GB/32GB Android TV Box:

- **Model:** X3 S905X3/4GB/32GB
- **Operating System:** Android 9.0
- **Processor:** Amlogic S905X3
- **RAM:** 4GB
- **Internal Storage:** 32GB
- **Connectivity:** Wi-Fi, Ethernet, HDMI, USB 3.0, USB 2.0, MicroSD Card Slot
- **Dimensions:** 13.78 x 9.45 x 6.3 inches (Package Dimensions)
- **Item Weight:** 1.76 pounds (800 Grams)


- Color:** Colourful (Device exterior design)
- Manufacturer:** Vontar
- Item Model Number:** 62353
- ASIN:** B0CPPXYK

8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or contact Vontar customer service directly. Keep your proof of purchase for any warranty claims.

© 2025 Vontar. All rights reserved.

Related Documents - X3 S905X3/4GB/32GB

	<p>VONTAR TV Box Model Differences and Specifications - Shenzhen Yojia Technology</p> <p>Details on model differences for VONTAR TV Boxes manufactured by Shenzhen Yojia Technology Co., Ltd., including model names, FCC ID, and shared circuit/RF module information.</p>
	<p>AKAMATE AI Box User Manual: Wireless CarPlay, Android Auto, and Mirror Link Guide</p> <p>Comprehensive user manual for the AKAMATE AI Box, detailing setup for Wireless CarPlay, Android Auto, Mirror Link, SIM/TF card usage, and troubleshooting for car infotainment systems.</p>
	<p>User Manual - MXQ Android TV Box</p> <p>This user manual provides comprehensive information for the MXQ Android TV Box, covering package contents, detailed connection diagrams, step-by-step installation instructions, multi-screen interaction capabilities, and key technical features. It also includes essential FCC compliance and radiation exposure statements.</p>
	<p>BINIZE Android 13 AI Box User Guide: Wireless CarPlay, Android Auto, and Multimedia Features</p> <p>A comprehensive guide to the BINIZE Android 13 AI Box, covering setup, features like Wireless CarPlay and Android Auto, Bluetooth connectivity, SIM card usage, and troubleshooting.</p>
	<p>Hadex O885 Smart TV Box H96 MAX RK3318 User Manual</p> <p>Instructions for use for the Hadex O885 Smart TV Box H96 MAX with RK3318 processor, 4GB RAM, and 64GB ROM. Covers setup, connections, settings, troubleshooting, and warranty.</p>



[YAY OTT Box User Manual and Specifications](#)

Comprehensive guide to the YAY OTT Box, covering accessories, installation, remote control features, Android TV setup, technical specifications, and safety information.