

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [FurReal](#) /

› [furReal Daisy the Yoga Goat Interactive Toy Instruction Manual](#)

FurReal 28104

furReal Daisy the Yoga Goat Interactive Toy Instruction Manual

Model: 28104

Brand: FurReal

INTRODUCTION

The furReal Daisy the Yoga Goat is an interactive plush toy designed to provide engaging play with over 60 sound and motion combinations. This manual provides essential information for setup, operation, and maintenance of your toy.



Image of the furReal Daisy the Yoga Goat interactive plush toy, an 11-inch realistic plush goat wearing a green headband, accompanied by a small play water bottle.

PACKAGE CONTENTS

- 1 Interactive Toy Goat
- 1 Play Water Bottle

SAFETY INFORMATION

Warning: May contain small pieces. Not suitable for children under 3 years due to potential choking hazards.

SETUP

Battery Installation

The furReal Daisy the Yoga Goat requires 4 x AA batteries. These batteries are included with the toy. To install or replace batteries:

1. Locate the battery compartment on the toy's belly.
2. Using a Phillips head screwdriver (not included), open the battery compartment cover.
3. Insert 4 new AA batteries, ensuring correct polarity (+/-).
4. Replace the cover and tighten the screw.



Image illustrating the location of the battery compartment on the underside of the toy, typically secured with a screw.

OPERATING INSTRUCTIONS

Power On/Off

To begin play, locate the power switch on Daisy's belly and flip it to the 'ON' position.

Interactive Play Modes

Daisy features over 60 sound and motion combinations. Interact with her in the following ways:

- **Petting:** Pet Daisy's back to activate her. She will giggle, bleat, and say cute yoga phrases like 'Ohmmmm...'. Continue petting her back to watch her perform various yoga poses, including downward dog and bird dog. She may also make 'tooting' sounds during poses.



A hand gently petting Daisy's back, demonstrating how to initiate her interactive yoga poses and sounds.

- **Hydration:** Give Daisy a drink from the included play water bottle. Place the bottle to her mouth to hear fun gurgling sounds.



Daisy the Yoga Goat with the play water bottle positioned at her mouth, illustrating the hydration feature.

- **Meditation Mode:** For a calming experience, press and hold Daisy's back for 3 seconds. She will enter Meditation Mode, playing soothing music and making deep, cleansing breath sounds.



Daisy the Yoga Goat with her eyes closed, indicating meditation mode, accompanied by musical notes to represent soothing sounds.

Official video demonstrating the interactive features of furReal Daisy the Yoga Goat, including her yoga poses, sounds, and drinking action.

MAINTENANCE

Cleaning

To clean Daisy, gently wipe her surface with a damp cloth. Do not immerse the toy in water. Allow to air dry completely.

Storage

When not in use for extended periods, store Daisy in a dry, dust-free environment. Remove batteries if storing for several months to prevent leakage.

TROUBLESHOOTING

Problem	Solution
Toy does not respond.	Ensure the power switch is in the 'ON' position. Check battery installation and replace with fresh AA batteries if necessary.
Sounds are distorted or weak.	Replace batteries with fresh AA batteries.
Motions are not performing correctly.	Ensure the toy is on a flat, stable surface. Check for any obstructions to its movement. Replace batteries if motions are sluggish.

SPECIFICATIONS

- **Model Number:** 28104
- **Product Dimensions:** 12 x 8 x 13 inches
- **Item Weight:** 0.012 ounces
- **Manufacturer Recommended Age:** 4 - 8 years
- **Batteries:** 4 AA batteries (included)
- **Manufacturer:** Just Play



Image highlighting the 11.4-inch height of the furReal Daisy the Yoga Goat, providing a visual reference for its size.

WARRANTY AND SUPPORT


For warranty information or customer support, please refer to the contact details provided on the product packaging or visit the official FurReal website. Keep your purchase receipt as proof of purchase.



Manufacturer: Just Play

Brand: FurReal

Release Date: August 1, 2024

Related Documents - 28104

	<p>FurReal Cubby the Curious Bear Pet Care Guide</p> <p>Discover how to care for and play with your FurReal Cubby the Curious Bear. This guide provides instructions on battery installation, activation points, feeding, nighttime mode, and troubleshooting for the interactive plush toy.</p>
---	--

	<p>FurReal Cubby the Curious Bear Pet Care Guide</p> <p>A comprehensive guide for caring for and interacting with the FurReal Cubby the Curious Bear interactive plush toy, including features, operation, and troubleshooting.</p>
	<p>FurReal Veerev Panda Coco Interactive Toy Instructions</p> <p>User guide and instructions for the FurReal Veerev Panda Coco interactive toy, detailing how to play, its features, and useful tips.</p>
	<p>furReal Bella the Kitty Interactive Toy User Guide</p> <p>Comprehensive guide for the furReal Bella the Kitty interactive toy, covering setup, play modes, features, and care instructions. Learn how to activate Bella's various sounds and movements for interactive play.</p>
	<p>FurReal Cinnamon My Stylin' Pony Toy - User Guide</p> <p>Instructions and information for the FurReal Cinnamon My Stylin' Pony toy, including activation, features, and cleaning instructions.</p>
	<p>FurReal Walkalots Big Wags Tiger Toy - Instructions and Safety Information</p> <p>This document provides instructions and safety information for the FurReal Walkalots Big Wags Tiger toy. It includes details on surface cleaning, product features, and FCC compliance statements in multiple languages.</p>