

[Manuals.plus](#) /

› [Xsarius](#) /

› Xsarius IR and Bluetooth Remote Control for Q8 and Aimax User Manual

Xsarius Q8 and Aimax Remote Control

Xsarius IR and Bluetooth Remote Control User Manual

Models: Q8, Aimax

1. INTRODUCTION

This manual provides detailed instructions for the Xsarius IR and Bluetooth Remote Control, designed for use with Xsarius Q8 and Aimax devices. It covers setup, operation, maintenance, and troubleshooting to ensure optimal performance and user experience.

2. PRODUCT OVERVIEW

The Xsarius remote control combines both Infrared (IR) and Bluetooth connectivity, offering versatile control options. Key features include Google Voice Control and TV programming functions.



Figure 1: Front view of the Xsarius IR and Bluetooth Remote Control, showing all buttons including power, navigation, volume, channel, number pad, and dedicated app buttons.



Figure 2: Angled view of the Xsarius remote control, showcasing its overall design and button layout from a perspective.

2.1. Button Layout

The remote features a standard layout for easy navigation and control:

- **Power Button:** Located at the top, used to turn the device on/off.
- **Navigation Pad (OK button):** Central circular pad for menu navigation and selection.
- **Volume Up/Down:** Adjusts audio volume.
- **Channel Up/Down:** Changes channels.
- **Number Pad:** For direct channel input or other numerical entries.
- **Google Voice Assistant Button:** Activates voice control.
- **Dedicated App Buttons:** Quick access to popular applications like YouTube and Live TV.
- **Menu/Guide Buttons:** Access device menus and program guides.



Figure 3: Side profile of the Xsarius remote control, highlighting its ergonomic design.

3. SETUP

3.1. Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery cover.
3. Insert two AAA batteries (not included), ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Close the battery cover securely.

3.2. Pairing via Bluetooth

For full functionality, including Google Voice Control, the remote must be paired with your Xsarius Q8 or Aimax device via Bluetooth.

1. Ensure your Xsarius Q8 or Aimax device is powered on and connected to a display.
2. Navigate to the device's settings menu (usually under "Remotes & Accessories" or "Bluetooth Settings").
3. On the remote control, press and hold the **OK** button and the **Volume Down (-)** button simultaneously for 3-5 seconds until the LED indicator on the remote starts flashing.
4. On your Xsarius device, select the remote control from the list of available Bluetooth devices.
5. Once paired, the LED indicator on the remote will stop flashing and remain solid for a few seconds, then turn off.

If pairing fails, ensure the remote is close to the device and repeat the steps. The remote will function via IR for basic controls even without Bluetooth pairing.

4. OPERATING INSTRUCTIONS

4.1. Basic Navigation (IR Mode)

In IR mode, the remote control operates line-of-sight. Point the remote directly at your Xsarius device.

- Use the **Navigation Pad** to move through menus and select items with the **OK** button.
- Adjust volume with **VOL +/-** and change channels with **CH +/-**.
- The **Power** button controls the power state of your Xsarius device.

4.2. Bluetooth Functions

Once paired via Bluetooth, the remote offers enhanced features and does not require direct line-of-sight.

- **Google Voice Control:** Press the dedicated **Google Assistant** button (often depicted with a microphone icon or Google colors) and speak your commands clearly into the remote.
- **TV Programming Function:** This feature allows you to program certain buttons on the Xsarius remote to control basic functions of your television (e.g., TV Power, TV Volume). Refer to your Xsarius device's on-screen settings for specific instructions on how to configure these programmable buttons.

4.3. Dedicated App Buttons

Press the **YouTube** or **Live TV** buttons for quick access to these applications on your Xsarius device.

5. MAINTENANCE

5.1. Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Do not use abrasive cleaners, solvents, or alcohol, as these can damage the surface.

5.2. Battery Replacement

Replace batteries when the remote's response becomes sluggish or the LED indicator fails to light up. Always replace both batteries at the same time with new AAA batteries. Dispose of old batteries responsibly according to local regulations.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Remote not responding (IR)	Low batteries; Obstruction between remote and device; Remote not pointed correctly.	Replace batteries; Remove obstructions; Point remote directly at the device's IR receiver.
Bluetooth functions (e.g., Voice Control) not working	Remote not paired via Bluetooth; Bluetooth disabled on device; Low batteries.	Ensure remote is paired (refer to Section 3.2); Check Bluetooth settings on your Xsarius device; Replace batteries.
TV programming not working	Incorrect programming steps; Incompatibility with TV model.	Review the TV programming instructions in your Xsarius device's settings; Some TV models may not be fully compatible.

7. SPECIFICATIONS

- **Brand:** Xsarius
- **Model Name:** Q8 and Aimax Remote Control
- **Connectivity Technology:** Infrared (IR), Bluetooth
- **Compatible Devices:** Xsarius Q8, Xsarius Aimax
- **Special Features:** Google Voice Control, TV Programming Function, Ergonomic Design
- **Color:** Black
- **Maximum Range:** 10 Meters (Bluetooth)
- **Power Source:** 2x AAA Batteries (not included)

8. WARRANTY AND SUPPORT

Information regarding warranty coverage and customer support for the Xsarius IR and Bluetooth Remote Control is typically provided with your Xsarius Q8 or Aimax device, or can be found on the official Xsarius website. Please refer to those resources for detailed warranty terms and contact information for technical assistance.

Spare parts availability information is not available at this time.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question