

Manuals.plus /

› EasyKeys /

› EasyKeys Replacement Key for Sentry Safe/Schwab 313 Instruction Manual

## EasyKeys 313

# EasyKeys Replacement Key for Sentry Safe/Schwab 313 Instruction Manual

## INTRODUCTION

This manual provides essential instructions for the proper identification and use of your EasyKeys replacement key for Sentry Safe and Schwab 313 series locks. Please read this guide carefully to ensure correct application and functionality.

## PRODUCT OVERVIEW



*Image: A close-up of the EasyKeys replacement key, showing its brass construction and the key code.*

The EasyKeys replacement key is a custom-cut brass key designed for file cabinets, desks, and cubicles equipped with Sentry Safe or Schwab 313 series locks. It is also compatible with locks from manufacturers such as CompX Fort and Meilink that use the 313 code. This key is engineered for durability and a precise fit, ensuring reliable operation for securing your storage units.


- **Material:** Brass
- **Special Features:** Custom Cut, Durable

- **Lock Type:** Cam Lock
- **Recommended Use:** Securing safes, fire-resistant boxes, and storage units

## IDENTIFYING YOUR LOCK CODE

---

Before using your replacement key, it is crucial to verify that the lock code on your existing lock or key matches the 313 code of this replacement key. Lock codes are specific to manufacturers and key cuts can differ even if codes appear similar. Use the following methods to locate your lock code:



*Image: A diagram illustrating common locations to find a lock code, including on the key itself, the lock cylinder, an internal label, or a cabinet label.*

1. **On the Existing Key:** The code is often stamped directly onto the key blade or head.
2. **On the Lock Face:** The code may be engraved on the visible part of the lock cylinder.
3. **Inside/Behind the Lock:** For some locks, the code is on a label or stamped on the lock body, accessible when the drawer or door is open, or by removing the lock.
4. **On Cabinet/Door Label:** Check for a sticker or plate on the furniture itself, often near the lock mechanism.

If you are unable to locate the code or are unsure, it is recommended to consult a professional locksmith or contact EasyKeys support for assistance.

## USAGE

---

To use your EasyKeys replacement key:

1. **Insert the Key:** Gently insert the key into the lock cylinder. Do not force the key.
2. **Turn to Unlock/Lock:** Turn the key clockwise or counter-clockwise, depending on the lock mechanism, to engage or disengage the locking bolt.
3. **Remove the Key:** Once the lock is engaged or disengaged, return the key to its original insertion position (usually vertical) before removing it.

Ensure the key is fully inserted before attempting to turn it to prevent damage to both the key and the lock.

## MAINTENANCE

---

Proper maintenance can extend the life of your lock and key. Periodically, you may apply a small amount of graphite lubricant to the lock cylinder if you notice stiffness or difficulty turning the key.



*Image: A small tube of graphite lubricant, recommended for maintaining lock mechanisms.*

**Do not use oil-based lubricants** as they can attract dust and debris, leading to further issues. Apply sparingly and work the key in the lock several times to distribute the lubricant.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Key does not insert fully.	Obstruction in keyway, incorrect key orientation.	Check for debris in the keyway. Ensure the key is oriented correctly. Do not force.
Key inserts but does not turn.	Incorrect key code, stiff lock mechanism, internal damage.	Verify the lock code matches the key (313). Apply graphite lubricant. If issues persist, contact support.
Lock is difficult to operate.	Lack of lubrication, minor misalignment.	Apply graphite lubricant as described in the Maintenance section.



*Image: A magnifying glass, useful for closely inspecting the keyway or lock code for any obstructions or details.*

## SPECIFICATIONS

**Brand:** EasyKeys

**Model Number:** 313

**Compatible Manufacturers:** Sentry Safe, Schwab, CompX Fort, Meilink

**Material:** Brass

**Lock Type:** Cam

**Item Dimensions (L x W x H):** 0.5 x 0.5 x 1 inches

**Item Weight:** 0.25 Pounds

**Included Components:** 1 Key

## SUPPORT

For further assistance, questions, or if you encounter persistent issues with your EasyKeys replacement key, please contact EasyKeys customer support. You can find contact information on the official EasyKeys website or through your purchase platform.

**Note:** This product is from a small business brand. Your support is appreciated.